

SIMPLY CLEVER

ŠKODA



ŠKODA Fabia Owner's Manual



Layout of this Owner's Manual (explanations)

This Owner's Manual has been systematically designed to make it easy for you to search for and obtain the information you require.

Chapters, table of contents and subject index

The text of the Owner's manual is divided into relatively short sections which are combined into easy-to-read **chapters**. The chapter you are reading at any particular moment is always specified on the bottom right of the page.

The **Table of contents** is arranged according to the chapters and the detailed **Subject index** at the end of the Owner's Manual helps you to rapidly find the information you are looking for.






Direction indications

All direction indications such as "left", "right", "front", "rear" relate to the direction of travel of the vehicle.

Units of measurement

All values are expressed in metric units.

Explanation of symbols

-  Denotes a reference to a section with important information and safety advice in a chapter.
-  Denotes the end of a section.
-  Denotes the continuation of a section on the next page.
-  Indicates situations where the vehicle must be stopped as soon as possible.
-  Denotes a registered trademark.

Notes

WARNING

The most important notes are marked with the heading **WARNING**. These **WARNING** notes draw your attention to a **serious risk of accident or injury**.

CAUTION

A **Caution** note draws your attention to the possibility of damage to your vehicle (e.g. damage to gearbox), or points out general risks of an accident.



FoR the sake of the environment

An **Environmental** note draws your attention to environmental protection aspects. This is where you will, for example, find tips aimed at reducing your fuel consumption.



Note

A normal **Note** draws your attention to important information about the operation of your vehicle.

Preface

You have opted for a ŠKODA - our sincere thanks for your confidence in us.

You have received a vehicle with the latest technology and range of amenities. Please read this Owner's Manual carefully, because the operation in accordance with these instructions is a prerequisite for proper use of the vehicle.

If you have any questions about your vehicle, please contact a ŠKODA Service Partner.

We wish you much pleasure with your ŠKODA and pleasant motoring at all times.

Your ŠKODA AUTO a.s. (hereinafter referred to as ŠKODA)



The on-board literature

The on-board literature for your vehicle consists of this "**Owner's Manual**" as well as a "**Service schedule**" and the "**Help on the road**" brochure.

Depending on the vehicle model and equipment, other additional operating manuals and instructions may be provided (e.g. an operating manual for the radio).

If one of the publications listed above is missing, please contact a ŠKODA Service Partner.

The Owner's Manual

These operating instructions describe **all possible equipment variants** without identifying them as special equipment, model variants or market-dependent equipment.

Consequently, this vehicle does **not need to contain all of the equipment components** described in this Owner's manual.

The level of equipment of your vehicle refers to your purchase contract of the vehicle. For more information, contact your local ŠKODA retailer.

The **illustrations** can differ in minor details from your vehicle; they are only intended for general information.

The Service Plan:

- includes vehicle data including information on service work performed;
- is a record of services provided;
- is provided for entries relating to the mobility warranty (valid only for some countries);
- serves as warranty certificate of the ŠKODA dealer.

The service records are one of the conditions for warranty claims.

Please always present the Service schedule when you take your car to a ŠKODA specialist garage.

If the Service Schedule is missing or worn, please contact the ŠKODA specialist garage that regularly services your car. You will receive a duplicate, in which the previously carried out service work is confirmed by the ŠKODA specialist garage.

The Help on the Road brochure

The brochure contains the important emergency telephone numbers as well as telephone numbers and contact addresses of ŠKODA Service Partners in different countries.

Table of Contents

Abbreviations

Using the system

Cockpit _____	7
Overview _____	6
Instruments and Indicator Lights _____	8
Instrument cluster _____	8
Multifunction display (onboard computer) _____	12
MAXI DOT (information display) _____	15
Warning lights _____	17
Unlocking and locking _____	25
Vehicle key _____	25
Locking/unlocking the vehicle without central locking _____	26
Central locking system _____	27
Remote control _____	29
Anti-theft alarm system _____	31
Interior monitor and towing protection _____	31
Emergency locking of the doors _____	32
Boot lid _____	32
Electrical power windows _____	34
Electric sliding/tilting roof _____	36
Lights and visibility _____	38
Lights _____	38
Interior light _____	43
Visibility _____	44
Windscreen wipers and washers _____	44
Rear window _____	47
Seats and Stowage _____	49
Front seats _____	49
Head restraints _____	51
Rear seats _____	52

Boot _____	53
Variable loading floor in the luggage compartment (Combi) _____	57
Net partition (Combi) _____	58
Bicycle carrier in the luggage compartment _____	60
Roof rack system _____	62
Cup holders _____	63
Ashtray _____	64
Cigarette lighter, 12-volt power socket _____	64
Storage compartments _____	65
Clothes hooks _____	69
Parking ticket holder _____	69
Heating and air conditioning system _____	70
Heating and air conditioning system _____	70
Air outlet vents _____	71
Heating _____	71
Air conditioning system (manual air conditioning system) _____	73
Climatronic (automatic air conditioning system) _____	76
Starting-off and Driving _____	79
Starting and stopping the engine _____	79
Brakes and brake assist systems _____	81
Shifting (manual gearbox) _____	85
pedals _____	85
Parking aid _____	85
Cruise control system (CCS) _____	86
START/STOP _____	88
Automatic gearbox _____	90
Automatic gearbox _____	90
Communication _____	95
Mobile phones and two-way radio systems _____	95
Universal telephone preinstallation GSM II _____	95
Voice control _____	99
Multimedia _____	101

Safety

Passive Safety _____	103
General information _____	103
Correct seated position _____	104
Seat belts _____	107
Seat belts _____	107
Airbag system _____	111
Description of the airbag system _____	111
Front airbags _____	112
Side airbags _____	113
Head airbags _____	114
Deactivating airbags _____	115
Transporting children safely _____	117
Child seat _____	117

Driving Tips

Driving and the Environment _____	121
The first 1 500 km _____	121
Catalytic converter _____	121
Economic and environmentally friendly driving _____	122
Environmental compatibility _____	124
Driving abroad _____	125
Avoiding damage to your vehicle _____	125
Driving through water on the street _____	126
Towing a trailer _____	127
Towing a trailer _____	127

General Maintenance

Taking care of and cleaning the vehicle _____	129
Taking care of your vehicle _____	129

Inspecting and replenishing	136
Fuel	136
Engine compartment	138
Vehicle battery	145
Wheels and Tyres	150
Tyres	150
Accessories, changes and replacement of parts	157
Introductory information	157
Changes and impairments of the airbag system	157

Do-it-yourself

Do-it-yourself	158
First-aid kit and warning triangle	158
Fire extinguisher	158
Vehicle tool kit	158
Changing a wheel	159
Breakdown kit	162
Jump-starting	165
Towing the vehicle	166
Fuses and light bulbs	168
Fuses	168
Bulbs	171

Technical data

Technical data	177
Introductory information	177
Data on the vehicle sticker and the type plate	177
Dimensions	178
Specifications and engine oil capacity	179
Vehicle-specific details per engine type	180

Index

Abbreviations

Abbreviation	Definition
rpm	Engine revolutions per minute
ABS	Anti-lock brake system
AG	Automatic gearbox
TCS	Traction control
CO ₂ in g/km	discharged quantity of carbon dioxide in grams per driven kilometer
DPF	Diesel particle filter
DSG	Automatic double clutch gearbox
EDL	Electronic differential lock
ESC	Electronic Stability Control
kW	Kilowatt, measuring unit for the engine output
MG	Manual gearbox
MFD	Multifunction display
N1	Panel van intended exclusively or mainly for the transportation of goods
Nm	Newton meter, measuring unit for the engine torque
TDI CR	Diesel engine with turbocharging and common rail injection system
TSI	Petrol engine with turbocharging and direct injection




Fig.1 Cockpit

Using the system

Cockpit

Overview

1	Electrical power windows	34
2	Electric exterior mirror adjustment	48
3	Air outlet vents	71
4	Lever for the multifunction switch:	
	➤ Turn signal light, headlight and parking light, headlight flasher	42
	➤ Speed regulating system	86
5	Steering wheel:	
	➤ With horn	
	➤ With driver's front airbag	112
	➤ With pushbuttons for radio, navigation system and mobile phone	95
6	Instrument cluster: Instruments and warning lights	8
7	Lever for the multifunction switch:	
	➤ Multifunction display	12
	➤ Windscreen wiper and wash system	45
8	Switch for rear window heater	44
9	TCS switch	84
10	Air outlet vents	71
11	Switch for hazard warning lights	42
12	Warning light for the deactivated front seat passenger airbag	115
13	Depending on equipment fitted:	
	➤ Operating controls for the heating	71
	➤ Operating controls for the air conditioning system	73
	➤ Operating controls for Climatronic	76
14	Storage compartments on the front passenger side	66
15	Front passenger airbag	112
16	Key-operated switch for the front seat passenger airbag	115
17	Switch depending on equipment fitted:	
	➤ Boot lid remote release	33
	➤ Interior monitor	31

18	Fuse box in the dashboard	169
19	Light switch and headlamp beam adjustment	38, 41
20	Bonnet release lever	140
21	Lever for adjusting the steering wheel	80
22	Ignition lock	81
23	Depending on equipment fitted:	
	➤ Radio	
	➤ Navigation system	
24	Rocker switch for front left seat heating	50
25	Central locking system	29
26	Depending on equipment fitted:	
	➤ Gearshift lever (manual gearbox)	85
	➤ Selector lever (automatic gearbox)	91
27	Rocker switch for front right seat heating	50
28	Depending on equipment fitted:	
	➤ Ashtrays	64
	➤ Storage compartment	67
29	MDI	102

i Note

The arrangement of the controls and switches and the location of some items on right-hand drive models may differ from that shown in » Fig. 1. The symbols on the controls and switches are the same as for left-hand drive models.

Instruments and Indicator Lights

Instrument cluster

Introduction

This chapter contains information on the following subjects:

Overview	8
Engine revolutions counter	9
Speedometer	9
Coolant temperature gauge	9
Fuel gauge	9
Counter for distance driven	10
Service Interval Display	10
Digital clock	11
Recommended gear	11

! WARNING

- Concentrate fully at all times on your driving! As the driver you are fully responsible for road safety.
- Never operate the controls in the instrument cluster while driving, only when the vehicle is stationary!

Overview



Fig. 2 Instrument cluster

First read and observe the introductory information and safety warnings **!** on page 8.



- 1 Engine revolutions counter » page 9
- 2 Display:
 - > With counter for distance driven » page 10
 - > With service interval display » page 10
 - > With digital clock » page 11
 - > With multifunction display » page 12
 - > With information display » page 15
- 3 Speedometer » page 9
- 4 Coolant temperature gauge » page 9
- 5 Button for display mode:
 - > Setting the hours/minutes
 - > Activating/deactivating the second speed in mph or km/h
 - > Service interval - Display of the number of days, kilometres or miles remaining until the next Inspection Service ¹⁾
- 6 Button for:
 - > Reset trip counter for the distance driven
 - > Resetting Service Interval Display

¹⁾ Valid for countries where the values are indicated in British measuring units.

- › Set hours/minutes
- › Activate/deactivate display mode

7 Fuel gauge » page 9

Engine revolutions counter

 First read and observe the introductory information and safety warnings  on page 8.

The red scale of the rev counter **1** » Fig. 2 on page 8 indicates the range in which the engine control unit begins to limit the engine speed. The engine control unit restricts the engine speed to a steady limit.



You should shift into the next higher gear before the red scale of the revolution counter is reached, or move the selector lever into position D if your car is fitted with an automatic gearbox.

To maintain the optimum motor speed, observe the gearshift indicator » page 11.

For the sake of the environment

Shifting to a higher gear in good time helps to lower fuel consumption, minimises operating noise levels, protects the environment and contributes to a longer life and reliability of the engine.

Speedometer

 First read and observe the introductory information and safety warnings  on page 8.

Warning against excessive speeds

An audible warning signal will sound when the vehicle speed exceeds 120 km/h. The audible warning signal is switched off when the vehicle speed falls below this speed limit.

Note

This function is only valid for some countries.

Coolant temperature gauge

 First read and observe the introductory information and safety warnings  on page 8.

The coolant temperature gauge **4** » Fig. 2 on page 8 operates only when the ignition is switched on.

The following guidelines regarding the temperature ranges must be observed to avoid any damage to the engine.

Cold range

If the pointer is still in the left area of the scale it means that the engine has not yet reached its operating temperature. Avoid high speeds, full throttle and high engine loads.

The operating range

The engine has reached its operating temperature as soon as the pointer moves into the mid-range of the scale, for a normal style of driving. The pointer may also move further to the right at high engine loads and high outside temperatures.


CAUTION

Additional headlights and other attached components in front of the fresh air inlet impair the cooling efficiency of the coolant. There is then a risk of the engine overheating at high outside temperatures and high engine loads » page 19.

Fuel gauge

 First read and observe the introductory information and safety warnings  on page 8.

The fuel gauge **7** » Fig. 2 on page 8 only operates when the ignition is switched on.

The fuel tank has a capacity of about 45 litres. The indicator light in the instrument cluster lights up when the pointer reaches the reserve marking  » page 22.



CAUTION

Never drive until the fuel tank is completely empty! An irregular supply of fuel can lead to irregular engine running. Unburnt fuel may get into the exhaust system and damage the catalytic converter.

i Note

On some vehicles, the fuel gauge is shown in the display of the instrument cluster.


Counter for distance driven

 First read and observe the introductory information and safety warnings  on page 8.

The distance which you have driven with your vehicle is shown in kilometres (km). In some countries the measuring unit "mile" is used.

Daily trip counter (trip)

The daily trip counter indicates the distance which you have driven since it was last reset - in steps of 100 metres or 1/10 of a mile.

To reset the display of the daily trip counter, press button  » Fig. 2 on page 8 for longer.

Odometer

The odometer indicates the total distance in kilometres or miles which the vehicle has been driven.

Fault display

If there is a fault in the instrument cluster **Error** will appear continuously in the display. Ensure the fault is rectified as soon as possible by ŠKODA a specialist garage.

i Note

For vehicles fitted with the information display, if the display of the second speed is activated in mph or km/h, this driving speed is indicated instead of the counter for the total distance driven.

Service Interval Display







Fig. 3
Service Interval Display: Note

 First read and observe the introductory information and safety warnings  on page 8.

The display can vary depending on the equipment.


Service Interval Display

Before the next service interval a key symbol  and the remaining kilometres are indicated for 10 seconds after switching on the ignition » Fig. 3. At the same time, the remaining days until the next service interval are displayed.

The following is displayed in the information display:

Service in ... km or ... days.


The kilometre indicator or the days indicator reduces in steps of 100 km or, where applicable, days until the service due date is reached.


As soon as the due date for the service is reached, a flashing key symbol  and the text **Service** appears in the display for 20 seconds after the ignition has been switched on.

The following is displayed in the information display:

Service now!

Displaying the distance and days until the next service interval

You can use the button  to display the remaining distance and days until the next service interval » Fig. 2 on page 8.

A key symbol  and the remaining distance appear for 10 seconds in the display. At the same time, the remaining days until the next service interval are displayed.

On vehicles which are equipped with the information display, you can call up this display in the menu **Settings** » page 15. ▶

The following will be displayed in the information display for 10 seconds:

Service in ... km or ... days.

Resetting Service Interval Display

It is only possible to reset the Service Interval Display, if a service message or at least a pre-warning is shown in the instrument cluster display.

We recommend that this reset is completed by a ŠKODA specialist garage.

The ŠKODA specialist garage:

- Resets the memory of the display after the appropriate inspection
- Adds an entry to the Service Schedule
- Affixes the sticker with the entry of the following service interval to the side of the dashboard on the driver's side

Reset the service interval display by using the reset button **6** » Fig. 2 on page 8.

On vehicles which are equipped with the information display, you can reset the Service Interval Display in the menu **Settings** » page 15.

! CAUTION

We recommend that you do not reset the Service Interval Display yourself as this can result in the incorrect setting of the Service Interval Display, which can also cause possible problems with the operation of your vehicle.

i Note

- Never reset the display between service intervals, as this will result in the incorrect display.
- Information is retained in the Service Interval Display even after the vehicle battery is disconnected.
- If the instrument cluster is exchanged after a repair, the correct values must be entered in the counter for the Service Interval Display. This work is carried out by a ŠKODA specialist garage.
- After resetting the display with flexible service intervals, the displayed data is the same as that for a vehicle with fixed service intervals. We therefore recommend that the Service Interval Display is only reset by a ŠKODA Service Partner, who will reset the display with a vehicle system tester.
- For more information on the service intervals » *Service Plan*.

Digital clock

 First read and observe the introductory information and safety warnings **!** on page 8.

The clock is set with the buttons **5** and **6** » Fig. 2 on page 8.

Select the display that you wish to change with the button **5** and carry out the change with the button **6**.

On vehicles that are fitted with the information display, it is also possible to set the clock in the menu **Time** » page 15.

Recommended gear




Fig. 4
Recommended gear

 First read and observe the introductory information and safety warnings **!** on page 8.

The currently engaged gear **A** is shown in the instrument cluster display » Fig. 4.

In order to minimise the fuel consumption, a recommendation for shifting into another gear is indicated in the display.

If the control unit recognises that it is beneficial to change gear, an arrow **B** is shown in the display. The arrow points up or down, depending on whether you should shift into a higher or lower gear.

At the same time, the recommended gear is indicated instead of the currently engaged gear **A**.

! CAUTION

The driver is always responsible for selecting the correct gear in different driving situations, such as overtaking.

Multifunction display (onboard computer)

Introduction

This chapter contains information on the following subjects:

Memory	12
Operation	13
Multifunction display details	13
Warning against excessive speeds	14

The multifunction display can only be operated when the ignition is switched on. After the ignition is switched on, the function displayed is the one which you last selected before switching off the ignition.

The multi-functional indicator appears in the display » Fig. 5 on page 12 or in the information display » page 15 depending on the equipment fitted to your vehicle.

In vehicles with an information display » page 15, there is an option to fade out some of the information.

! WARNING

- Concentrate fully at all times on your driving! As the driver you are fully responsible for road safety.
- Do not only rely upon the information given on the outside temperature display that there is no ice on the road. Even at temperatures around +4 °C, black ice may still be on the road surface – warning, drive with care!

i Note

- In certain national versions the displays appear in the Imperial system of measures.
- If the display of the second speed is activated in mph, the current speed is not indicated in km/h on the display.

Memory




Fig. 5
Multifunction display

First read and observe the introductory information and safety warnings ! on page 12.

The multifunction display is equipped with two automatic memories. The selected memory is shown in the Display » Fig. 5.

The data of the single-trip memory (memory 1) is shown if a 1 appears in the display. A 2 shown in the display means that data relates to the total distance memory (memory 2).

Switching over the memory takes place with the button **B** » Fig. 6 on page 13 on the windshield wiper lever.

Single-trip memory (memory 1)

The single-trip memory collates the driving information from the moment the ignition is switched on until it is switched off. New data will also flow into the calculation of the current driving information if the trip is continued **within 2 hours** after switching off the ignition. If the trip is interrupted for **more than 2 hours**, the memory is automatically erased.

Total-trip memory (memory 2)

The total-trip memory gathers data from any number of individual journeys up to a total of 19 hours and 59 minutes driving or 1 999 kilometres driven, and on vehicles which are fitted with an information display up to a total of 99 hours and 59 minutes driving or 9 999 kilometres driven. The memory is deleted when either of these limits is reached and the calculation starts all over again.

Unlike the single-trip memory, the total-trip memory is not deleted after a period of interruption of driving of 2 hours.

i Note

All information in the memory 1 and 2 is erased if the battery of the vehicle is disconnected.

Operation





Fig. 6
Multifunction display: Control elements

 First read and observe the introductory information and safety warnings **i** on page 12.

The rocker switch **A** » Fig. 6 and the button **B** are located on the windscreen wiper lever.

Select memory

» Press the button **B** » Fig. 6.

Selecting functions

» Briefly press the rocker switch **A** » Fig. 6 up or down. This opens the individual functions of the multifunction display one after the other.

Resetting

» Select the desired memory.
» Press the button **B** » Fig. 6 for longer.

The following readouts of the selected memory will be set to zero by button **B**:

- » Average fuel consumption
- » Distance driven

- » Average speed
- » Driving time

Multifunction display details

 First read and observe the introductory information and safety warnings **i** on page 12.

Outside temperature

The current outside temperature is shown in the display.

If the outside temperature drops below +4 °C, a snow flake symbol (warning signal for ice on the road) appears before the temperature indicator and an audible signal will sound. After pressing the rocker switch **A** » Fig. 6 on page 13, the function which was shown last is indicated.

Driving time

The driving time which has elapsed since the memory was last erased, appears in the display. If you want to measure the driving time from a particular moment in time on, at this moment, reset the memory by setting the button **B** » Fig. 6 on page 13 to zero.

The maximum time indicated in both memories is 19 hours and 59 minutes and on vehicles which are fitted with an information display, it is 99 hours and 59 minutes. The indicator is set back to zero if this period is exceeded.

Current fuel consumption

The current fuel consumption level is shown in the display in litres/100 km¹⁾. You can use this information to adapt your driving style to the desired fuel consumption.

The display appears in litres/hour if the vehicle is stationary or driving at a low speed²⁾.

Average fuel consumption

The average fuel consumption since the memory was last erased is shown in the display in litres/100 km¹⁾ » page 12.

¹⁾ On some models in certain countries, the display appears in kilometres/litre.

²⁾ On some models in certain countries, the display appears in --,-- kilometres/litres if the vehicle is stationary.

If you wish to determine the average fuel consumption over a certain period of time, you must set the memory at the start of the new measurement to zero using the button **[B]** » Fig. 6 on page 13. After erasing the memory, no value appears in the display until you have driven approx. 300 m.

The display is updated regularly while you are driving.

Range

The estimated range in kilometres is shown on the display. It indicates the distance you can still drive with your vehicle based on the level of fuel in the tank and the same style of driving.

The display is shown in steps of 10 km. Once the fuel gauge pointer reaches the reserve marking, the range is displayed in 5 km.

The fuel consumption over the last 50 km is used to calculate the range. The range will increase if you drive in a more economical manner.

If the memory is set to zero (after disconnecting the battery), the fuel consumption of 10 ltr./100 km is calculated for the range; afterwards the value is adapted accordingly to the style of driving.

Distance travelled

The distance travelled since the memory was last erased is shown in the display » page 12. If you want to measure the distance travelled from a particular moment in time on, at this moment, reset the memory by setting the button **[B]** » Fig. 6 on page 13 to zero.

The maximum distance indicated in both memories is 1 999 km or 9 999 km on vehicles with an information display. The indicator is set back to zero if this period is exceeded.

Average speed

The average speed since the memory was last erased is shown in the display in km/hour » page 12. To determine the average speed over a certain period of time, set the memory to zero at the start of the measurement using button **[B]** » Fig. 6 on page 13.

After erasing the memory, no value appears in the display until you have driven approx. 300 m.

The display is updated regularly while you are driving.

Current speed

The current speed which is identical to the display of the speedometer **[3]** » Fig. 2 on page 8 is indicated on the display.

Oil temperature

If the oil temperature is lower than 50 °C or if a fault in the system for checking the oil temperature is present, only -.- is displayed instead of the oil temperature.

Warning against excessive speeds



First read and observe the introductory information and safety warnings **[!]** on page 12.

Adjust the speed limit while the vehicle is stationary

- › With button **[A]** » Fig. 6 on page 13, choose the menu point **Warning against excessive speeds**.
- › Press the button **[B]** to activate the ability to set the speed limit (value flashes).
- › Use the button **[A]** to set the required speed limit, e.g. 50 km/h.
- › Confirm the speed limit that was set with button **[B]**, or wait approx. 5 seconds until the setting is saved automatically (the value stops flashing).

This allows you to set the speed in 5 km/h intervals.

Adjusting the speed limit while the vehicle is moving

- › With button **[A]** » Fig. 6 on page 13, choose the menu point **Warning against excessive speeds**.
- › Drive at the desired speed, e.g. 50 km/h.
- › Press button **[B]** to accept the current speed as the speed limit (the value flashes).

If you wish to change the set speed limit, it is changed in 5 km/h intervals (e.g. the accepted speed of 47 km/h increases to 50 km/h or decreases to 45 km/h).

- › Confirm the speed limit that was set by pressing button **[B]** again, or wait approx. 5 seconds until the setting is saved automatically (the value stops flashing).

Change or delete speed limit

- › With button **[A]** » Fig. 6 on page 13, choose the menu point **Warning against excessive speeds**.
- › Pressing the button **[B]** deletes the speed limit.
- › Pressing the button **[B]** activates the ability to change the speed limit.

If the set speed limit is exceeded, an audible signal will sound as a warning. At the same time the message **Warning against excessive speeds** appears on the display with the set limit value.

The set speed limit value remains stored even after switching off the ignition.

MAXI DOT (information display)

Introduction

This chapter contains information on the following subjects:

Main menu	15
Settings	15
Door, boot lid and bonnet warning	16
Auto Check Control	16

The information display provides you with information on the **current operating state of your vehicle**. The information system also provides you with data (depending on the equipment installed in the vehicle) relating to the radio, mobile phone, multi-functional indicator, navigation system, the unit connected to the MDI input and the automatic gearbox » [page 90](#).

Lighting up of certain symbols is combined with an acoustic warning signal.

! WARNING

Concentrate fully at all times on your driving! As the driver you are fully responsible for road safety.

Main menu




Fig. 7
Windshield wiper lever: Controls
for the information display

First read and observe the introductory information and safety warnings ! on page 15.

➤ Activate the **Main menu** by pressing the rocker switch **A** » [Fig. 7](#) for longer.

➤ Individual menu items can be selected by means of the rocker switch **A**. When the pushbutton **B** is briefly pressed, the information you have selected is displayed.

The following information can be selected (depending on the equipment installed on the vehicle):

- **MFD** » [page 12](#)
- **Audio** » *Operating instructions for the radio*
- **Navigation** » *Operating instructions for the navigation system*
- **Phone** » [page 95](#)
- **Vehicle status** » [page 16](#)
- **Settings** » [page 15](#)

The menu items **Audio** and **Navigation** are only displayed when the factory-fitted radio or navigation system is switched on.

i Note

If the information display is not activated at that moment, the menu always shifts to one of the higher levels after 10 seconds.

Settings

First read and observe the introductory information and safety warnings ! on page 15.

You can change certain settings by means of the information display. The current setting is shown on the information display in the respective menu at the top below the line.

The following information can be selected (depending on the equipment installed on the vehicle):

- **Language**
- **MFD Data**
- **Time**
- **Winter tyres**
- **Units**
- **Alternative speed displayed**
- **Service**
- **Factory Setting**
- **Back**

Select the menu item **Back** to return to one level higher in the menu.

Language

You can set the language for the warning and information texts here.

MFD displays

Activate or deactivate certain displays of the multifunction display here.

Time

The time, time format (12 or 24 hour indicator) and the changeover between summer/winter time can be set here.

Winter tyres

Here, you can set the speed at which an audible signal should sound. This function is, for example, used for winter tyres where the maximum permissible speed is lower than the maximum speed of the vehicle.

When exceeding the speed, the following is shown on the information display:

Winter tyres max. speed ... km/h.

Units of measurement

The units for the temperature, consumption and distance driven can be set here.

Second speed

The display of the second speed in mph or in km/h can be switched on here¹⁾.

Service


Here you can have the remaining kilometres and days until the next service interval displayed, and reset the Service Interval Display.

Factory setting

After selecting the menu **Factory setting** the factory setting of the information display is restored.

Door, boot lid and bonnet warning



First read and observe the introductory information and safety warnings  on page 15.

If at least one door is open, or the boot or bonnet is open, the information display indicates the relevant **open** door or boot/bonnet.

An audible signal also sounds if the vehicle is travelling at more than 6 km/h.

Auto Check Control



First read and observe the introductory information and safety warnings  on page 15.

Vehicle condition




Certain functions and conditions of individual vehicle systems are checked continuously when the ignition is switched on and also while driving.

Some error messages and other information are displayed in the information display. The messages are displayed at the same time as the symbols in the information display or the warning lights in the instrument cluster [» page 17](#).


If there is at least one error message, the menu item **Vehicle status** is displayed in the menu. After selecting this menu the first of the error messages is displayed. Several error messages are shown on the display under the message e.g. **1/3**. This indicates that the first of a total of three error messages is being displayed.

As long as the operational faults are not rectified, the symbols are always indicated again. After they are displayed for the first time, the symbols continue to be indicated without any extra messages for the driver.

Warning symbols


	Engine oil pressure too low	» page 19
	Clutches of the automatic gearbox are too hot	» page 16
	Check engine oil level, engine oil sensor faulty	» page 19

Clutches of the automatic gearbox are too hot

A symbol  in the information display indicates that the temperature of the clutches of the automatic gearbox is too high.

The following is displayed in the information display:

Gearbox overheated. Stop! Owner's man.!

Stop the vehicle, switch off the engine, and wait until the symbol  disappears - risk of gearbox damage! You can continue your journey as soon as the symbol disappears.

¹⁾ Valid for countries where the values are indicated in British measuring units.

! WARNING

If you have to stop for technical reasons, then park the vehicle at a safe distance from the traffic, switch off the engine and activate the hazard warning light system » [page 42, Switches for the hazard warning light system.](#)








i Note



















- If warning messages are shown in the information display, you need to confirm these messages with the button **[B]** » [Fig. 7](#) on page 15 in order to call up the main menu.
- As long as the operational faults are not rectified, the symbols are always indicated again. After they are displayed for the first time, the symbols continue to be indicated without any extra messages for the driver.




Warning lights

Overview

The warning lights show certain functions/faults and may be accompanied by audible signals.

	Handbrake	» page 18
	Brake system	» page 18
	Seat belt warning light	» page 18
	Generator	» page 18
	Open door	» page 19
	Engine oil	» page 19
	Coolant temperature/coolant level	» page 19


	Electrohydraulic power steering	» page 20
	Electronic Stability Control (ESC)	» page 20
	Traction control (TCS)	» page 21
	Antilock brake system (ABS)	» page 21
	Rear fog light	» page 21
	Bulb failure	» page 21
	Exhaust inspection system	» page 21
	Glow plug system (diesel engine)	» page 22
	EPC fault light (petrol engine)	» page 22
	Diesel particle filter (diesel engine)	» page 22
	Fuel reserve	» page 22
	Airbag system	» page 23
	Tyre control display	» page 23
	Windscreen washer fluid level	» page 23
	Traction control (TCS) switched off	» page 23
	Turn signal (left/right).	» page 23
	Low beam	» page 23
	Fog lights	» page 24

	Speed regulating system	» page 24
	Selector lever lock	» page 24
	Main beam	» page 24

WARNING

- If illuminated warning lights and the corresponding descriptions and warning notes are not observed, this may result in severe injuries or major vehicle damage.
- The engine compartment of your car is a hazardous area. There is a risk of injuries, scalding, accidents and fire when working in the engine compartment, e.g. inspecting and replenishing oil and other fluids. It is essential to observe safety notes » page 138, *Engine compartment*.


Handbrake

The warning light  comes on if the handbrake is applied. An audible warning is also given if you drive the vehicle for at least 3 seconds at a speed of more than 6 km/h.

The following is displayed in the information display:

Release parking brake!

Brake system

The warning light  illuminates if the brake fluid level is too low or there is a fault in the ABS.





The following is displayed in the information display:

Brake fluid: Owner's manual!


Stop the vehicle, switch off the engine, and check the level of the brake fluid » page 144.


Further information » page 81, *Brakes and brake assist systems*.


WARNING

- If you have to stop for technical reasons, then park the vehicle at a safe distance from the traffic, switch off the engine and activate the hazard warning light system » page 42.
- The following guidelines should be observed when opening the bonnet and checking the brake fluid level » page 138, *Engine compartment*.
- If the warning light  is displayed simultaneously with warning light  » page 21, *Antilock brake system (ABS)*   **do not continue your journey!** Seek help from a ŠKODA specialist garage.
- A fault to the braking system can increase the vehicle's braking distance!

Seat belt warning light


The warning light  comes on after the ignition is switched on as a reminder for the driver to fasten the seat belt. The warning light only goes out if the driver has fastened his seat belt.

If the seat belt has not been fastened by the driver, a permanent warning signal sounds at vehicle speeds greater than 20 km/h and simultaneously the warning light  flashes.

If the seat belt is not fastened by the driver during the next 90 seconds, the warning signal is deactivated and the warning light  lights up permanently.

Further information » page 107, *Seat belts*.

Dynamo



If the warning light lights up  when the engine is running, the vehicle battery is not being charged.

Seek help from a ŠKODA specialist garage. The electrical system requires checking.


WARNING

- If you have to stop for technical reasons, then park the vehicle at a safe distance from the traffic, switch off the engine and activate the hazard warning light system » page 42.

! CAUTION

If the warning light  (cooling system fault) comes on in addition to the warning light  when driving, stop the vehicle immediately and switch the engine off - risk of engine damage!

Open door

The warning light  comes on if one or several doors are opened or if the boot lid is opened.

The warning light comes on even when the ignition is switched off. The warning light lights up for a maximum of 5 minutes.

! WARNING


If you have to stop for technical reasons, then park the vehicle at a safe distance from the traffic, switch off the engine and activate the hazard warning light system » [page 42](#).

Engine oil


The warning light  lights up red (low oil pressure)

The following is displayed in the information display:

Oil Pressure: Engine off! Owner's manual!

The warning light  comes on for a few seconds when the ignition is switched on¹⁾.

Stop the vehicle, switch off the engine, and check the level of the engine oil » [page 141](#).

Even if the oil level is correct,  **do not drive any further** if the warning light is flashing. Also do not leave the engine running at an idling speed.

Seek help from a ŠKODA specialist garage.

The warning light  lights up yellow (oil quantity too low)

The following is displayed in the information display:

Check oil level!

Stop the vehicle, switch off the engine, and check the level of the engine oil » [page 141](#), *Checking the engine oil level*.


An audible signal sounds as a warning signal.

The warning light will go out if the bonnet is left open for more than 30 seconds. If no engine oil has been replenished, the warning light will come on again after driving about 100 km.

The warning light  flashes yellow (engine oil level sensor faulty)

The following is displayed in the information display:

Oil sensor: Workshop!


If the engine oil level sensor is faulty, the warning light flashes  several times and an audible signal sounds when the ignition is turned on.

Seek help from a ŠKODA specialist garage.


! WARNING


If you have to stop for technical reasons, then park the vehicle at a safe distance from the traffic, switch off the engine and activate the hazard warning light system » [page 42](#).


! CAUTION

The red oil pressure light  is not an oil level indicator! One should therefore check the oil level at regular intervals, preferably after every refuelling stop.

Coolant temperature/coolant level

The indicator light  lights up until the engine reaches operating temperature²⁾. Avoid high speeds, full throttle and high engine loads.

If the warning light  lights up or flashes, either the coolant temperature is too high or the coolant level is too low.

¹⁾ The warning light  on vehicles fitted with an information display does not come on after switching the ignition on, but only if a fault exists or the engine oil level is too low.

²⁾ Not valid for vehicles with information display.



An audible signal sounds as a warning tone.

The following is displayed in the information display:

Check coolant! Owner's manual!

Stop the vehicle, switch off the engine, check the level of the coolant » [page 143](#), and refill the coolant if necessary » [page 143](#).

If the coolant is within the specified range, the increased temperature may be caused by an operating problem at the radiator fan. Check the fuse for the radiator fan, replace if necessary » [page 170](#), *Fuses in the engine compartment*.


Do not continue driving if the warning light   **does not go off even though the coolant level is correct and the fuse for the fan is in working order!**

Seek help from a ŠKODA specialist garage.

WARNING

- If you have to stop for technical reasons, then park the vehicle at a safe distance from the traffic, switch off the engine and activate the hazard warning light system » [page 42](#).
- Carefully open the coolant expansion bottle. If the engine is hot, the cooling system is pressurized - risk of scalding! It is therefore best to allow the engine to cool down before removing the cap.
- Do not touch the radiator fan. The radiator fan may switch itself on automatically even if the ignition is off.

Electrohydraulic power steering



The warning light  comes on for a few seconds when the ignition is switched on.

If the warning light after switching on the ignition or when driving lights up continuously, a fault exists in the electrohydraulic power steering. The power steering operates with reduced steering assist or does not function at all.


Seek help from a ŠKODA specialist garage.


Further information » [page 80](#).

Note

- If the yellow warning light  goes out when you restart the engine and drive for a short distance, it is not necessary to visit a ŠKODA specialist garage.
- If the vehicle battery has been disconnected and reconnected, the yellow warning light  comes on after switching on the ignition. The warning light should go out after driving a short distance.
- There is no power-assisted steering support when the vehicle is being towed without the engine running or when the power-assisted steering is defect. The vehicle is fully steerable however. There is however increased force required to turn the steering wheel.

Electronic Stability Control (ESC)

The warning light flashes  to show that the ESC is currently operating.



If the warning light  comes on immediately after you start the engine, the ESC might be switched off due to technical reasons. Switch the ignition off and on again. If the warning light does not light up after you switch the engine back on, the ESR is fully functional again.

If the warning light  lights up, there is a fault in the ESC.

The following is displayed in the information display:

Error: Electronic Stability Control (ESC)


Seek help from a ŠKODA specialist garage.

The ESC cannot be switched off, the button  » [page 84](#) only deactivates the TCS system and the warning light  in the instrument cluster lights up.


As the ESC operates in conjunction with the ABS, the ESP indicator light will also come on if the ABS system fails.


Further information » [page 83](#), *Stabilisation control (ESC)*.

Note

If the vehicle's battery has been disconnected and reconnected, the warning light  comes on after switching on the Ignition. The warning light should go out after driving a short distance.

Traction control system (TCS)

The warning light flashes  to show that the ASR is currently operating.

If the warning light  comes on immediately after starting the engine, the ASR can be switched off for technical reasons. Switch the ignition off and on again. If the warning light does not light up after you switch the engine back on, the ASR is fully functional again.

If the warning light  lights up, there is a fault in the ASR.

The following is displayed in the information display:


Error: traction control (ASR)

Seek help from a ŠKODA specialist garage.

The fact that the TCS system operates together with the ABS means that the TCS warning light will also come on if the ABS system is not operating properly.

Further information » [page 84](#), *Traction control system (TCS)*.

Note

If the vehicle's battery has been disconnected and reconnected, the warning light  comes on after switching on the ignition. The warning light should go out after driving a short distance.

Antilock brake system (ABS)

If the warning light  lights up, there is a fault in the ABS.




The following is displayed in the information display:

Error: ABS

The vehicle will only be braked by the normal brake system without the ABS.

Seek help from a ŠKODA specialist garage.


WARNING

- If you have to stop for technical reasons, then park the vehicle at a safe distance from the traffic, switch off the engine and activate the hazard warning light system » [page 42](#).
- If the warning light  » [page 18](#) is displayed simultaneously with the ABS warning light ,  **do not continue your journey!** Seek help from a ŠKODA specialist garage.
- A fault to the ABS system or the braking system can increase the vehicle's braking distance - risk of accident!

The rear fog light

The warning light  comes on when the rear fog lights are operating » [page 41](#).

Bulb failure


The warning light  comes on if a bulb is faulty:

- within 2 seconds of the ignition being switched on;
- when switching on the defective light bulb.


The following is displayed in the information display:

Check front-right dipped beam!

Note


The rear side lights and the licence plate lighting have several light bulbs. The indicator light  only lights up if all light bulbs of the licence plate lighting or the parking light (in one rear light) are defective. For this reason, regular check that these light bulbs are working correctly.


Exhaust inspection system


If the warning light  lights up, there is a fault in the exhaust inspection system. The engine control unit allows the vehicle to run in emergency mode.

Seek help from a ŠKODA specialist garage.

Glow plug system (diesel engine)


The warning light  comes on after the ignition has been switched on. The engine can be started immediately after the pre-glow warning light goes out.

There is a fault in the glow plug system if the warning light  **does not** come on at all or **lights up continuously**.

If the warning light  begins to **flash** while driving, a fault exists in the engine control. The engine control unit allows the vehicle to run in emergency mode.

Seek help from a ŠKODA specialist garage.


EPC fault light (petrol engine)


If the warning light  comes on or begins to flash while driving, a fault exists in the engine control unit. The engine control unit allows the vehicle to run in emergency mode.

Seek help from a ŠKODA specialist garage.



Diesel particulate filter (diesel engine)

The diesel particulate filter separates the soot particles from the exhaust. The soot particles collect in the diesel particulate filter where they are burnt on a regular basis.

If the warning light  lights up, soot has accumulated in the diesel particulate filter.


To clean the diesel particulate filter, the vehicle should be driven at an even speed of at least 60 km/h  at engine speeds of 1 800 - 2 500 rpm for at least 15 minutes or until the warning light goes out with the 4th or 5th gear engaged (automatic gearbox: position S) when the traffic situation permits it.

The warning light  only goes out after the diesel particulate filter has been successfully cleaned.

If the filter is not properly cleaned, the warning light  does not go out and the warning light  begins to flash.

The following is displayed in the information display:

Diesel particulate filter: Owner's manual


The engine control unit allows the vehicle to run in emergency mode. After switching the ignition off and on again the indicator light, the indicator light  also lights up.

Seek help from a ŠKODA specialist garage.

WARNING

- The diesel particle filter achieves very high temperatures. Therefore do not park in areas where the hot filter can come into direct contact with dry grass or other combustible materials - risk of fire!
- Always adjust your speed to suit weather, road, region and traffic conditions. The recommendations indicated by the warning light must not tempt you to disregard the national regulations for road traffic.

CAUTION

As long as the warning light  lights up, one must take into account an increased fuel consumption and in certain circumstances a power reduction of the engine.

Note

- To assist the combustion process of the soot particles, we recommend that regularly driving over short distances should be avoided.
- Using diesel fuel with an increased sulphur content can considerably reduce the life of the diesel particle filter. A ŠKODA specialist garage will be able to tell you which countries use only diesel fuel with high sulphur content.

Fuel reserve

The indicator light  will come on if the fuel level is less than 7 litres.

An audible signal sounds as a warning signal.

The following is displayed in the information display:

Please refuel! Range ... km

Note

The text in the information display goes out only after refuelling and driving a short distance.

Airbag system

If the warning light  lights up, there is a fault in the airbag system.

The following is displayed in the information display:

Error: Airbag

The functionality of the airbag system is also monitored electronically when one airbag has been switched off.


If a front, side or head airbag or belt tensioner has been switched off using the vehicle system tester:


> The warning light  lights up for 4 seconds after switching on the ignition and then flashes again for 12 seconds afterwards in 2 second intervals.

The following is displayed in the information display:

Airbag/belt tensioner deactivated!

If the airbag was switched off using the key-operated switch on the side of the dash panel on the passenger side:


> The warning light  comes on for 4 seconds after the ignition has been switched on.

> switching off the airbag is indicated in the middle of the dash panel by the lighting up of the yellow indicator light in display **PASSENGER AIR BAG OFF** : » [page 115](#).

WARNING

If there is a fault, have the airbag system checked immediately by a ŠKODA specialist garage. Otherwise, there is a risk of the airbag not being activated in the event of an accident.

Tyre control display


The warning light  lights up, if there is a substantial drop in inflation pressure in one of the tyres. Check and adjust the pressure in all tyres.

If the warning light  lights up, there is a fault in the system.


Seek help from a ŠKODA specialist garage.

Further information » [page 155](#), *Tyre control display*.

Note

If the battery has been disconnected, the warning light  illuminates after the ignition is switched on. The warning light should go out after driving a short distance.


Windscreen washer fluid level

If the windscreen washer fluid level is too low, the warning light  comes on. Top up with liquid » [page 145](#).

The following is displayed in the information display:

Top up wash fluid!

Switching off traction control system (TCS)

The ASR is switched off by pressing the button » [page 84](#) and the warning light  illuminates.

The following is displayed in the information display:

Traction control (ASR) deactivated.

Turn signal system

Either the left  or right  warning light flashes depending on the position of the turn signal lever.

If a turn signal light fails, the warning light flashes at twice its normal rate.

Switching off the hazard warning light system is switched on will cause all of the turn signal lights as well as both warning lights to flash.

Further information » [page 42](#), *Turn signal and main beam lever*.

Low beam

The warning light  comes on when low beam is selected » [page 38](#).


Fog lights

The warning light  comes on when the fog lights are operating » [page 40](#). ■


Speed regulating system

The warning light  comes on when the cruise control is operating » [page 86](#). ■

Selector lever lock

If the warning light  lights up, operate the brake pedal. This is necessary, to be able to move the selector lever from position **P** or **N** » [page 93](#). ■

Main beam

The warning light  comes on when the main beam or headlight flasher are selected » [page 42](#). ■

Unlocking and locking

Vehicle key

Introductory information




Fig. 8 Key without remote control/key with remote control (remote control key)

Two keys are provided with the vehicle. Depending on the equipment, your vehicle can be equipped with keys without radio remote control » Fig. 8 - [A] or with radio remote control » Fig. 8 - [B].

! WARNING

- Always withdraw the key whenever you leave the vehicle - even if it is only for a short time. This is particularly important if children are left in the vehicle. The children might otherwise start the engine or operate electrical equipment (e.g. electrical power windows) - risk of injury!
- Do not withdraw the ignition key from the ignition lock until the vehicle has come to a stop. The steering lock might otherwise engage unintentionally - risk of accident!

! CAUTION

- Each key contains electronic components; therefore it must be protected against moisture and severe shocks.
- Keep the groove of the keys absolutely clean. Impurities (textile fibres, dust, etc.) have a negative effect on the functionality of the locking cylinder and ignition lock.

i Note

Please contact a ŠKODA Service Partner if you lose a key as they can obtain a new one for you.

Replacing the battery in the remote control key




Fig. 9 Remote control key: Remove cover/remove battery

- Each remote control key contains a battery that is located under the cover [A] » Fig. 9. The battery needs replacing if red warning light » Fig. 8 on page 25 - [B] does not go on when you press a button on the remote control key. We recommend that you ask a ŠKODA Service Partner to replace the key battery. However, if you would like to replace the discharged battery yourself proceed as follows.
- Flip out the key.
 - Press off the battery cover with your thumb or using a flat screwdriver in the region of arrows [1] » Fig. 9.
 - Remove the discharged battery from the key by pressing the battery downwards in the region of arrow [2].
 - Insert the new battery. Ensure that the "+" symbol on the battery is facing upwards. The correct polarity is shown on the battery cover.
 - Place the battery cover on the key and press it down until it clicks into place. ▶

! CAUTION

- Pay attention to the correct polarity when changing the battery.
- The replacement battery must have the same specification as the original battery.

♻️ For the sake of the environment

Dispose of the used battery in accordance with national legal provisions.

i Note

- Please contact a ŠKODA Service Partner if you lose a key as they can obtain a new one for you.
- The system has to be synchronised, if the vehicle cannot be unlocked or locked with the remote control key after replacing the battery » [page 30](#).

Child safety lock




Fig. 10 Switching child safety lock on: for vehicles without or with central locking system

The child safety lock prevents the rear door from being opened from the inside. The door can only be opened from the outside.

You can switch the child safety lock on and off using the vehicle key.

Switching on

- On vehicles without central locking, turn the slot of the lock on the left-hand door anti-clockwise » [Fig. 10 - A](#) and clockwise on the right-hand door.
- On vehicles with central locking, turn the slot of the lock on the left-hand door clockwise » [Fig. 10 - B](#) and anti-clockwise on the right-hand door.

Switching off

- On vehicles without central locking, turn the slot of the lock on the left-hand door clockwise and anti-clockwise on the right-hand door.
- On vehicles with central locking, turn the slot of the lock on the left-hand door anti-clockwise and clockwise on the right-hand door.

Locking/unlocking the vehicle without central locking




Fig. 11 Securing knob in the front door/rear door

When you unlock/lock the door, the respective securing knob » [Fig. 11](#) will move upwards or downwards.

Unlocking from the outside

- Unlock the front door with the key » [page 28](#).

Unlocking from the inside

- Pull on the door opening lever.

Locking from the outside

- Lock the front door with the key » [page 28](#).

Locking from the inside

- Push the securing knob down » [Fig. 11](#).

! WARNING

Locked doors prevent unwanted entry into the vehicle from outside, for example at road crossings. Locked doors do, however, make it more difficult for rescuers to get into the vehicle in an emergency - danger to life!

i Note

- Lock the opened rear doors and front passenger door by closing them and pressing the securing knob.
- It is not possible to lock the opened driver's door using the securing knob. This prevents against inadvertently locking the key in the vehicle.

Central locking system

Introductory information

When using central locking or unlocking, **all** doors are locked or unlocked simultaneously. The boot lid is unlocked when opening. It can be opened by pressing the handle above the licence plate » [page 33](#), *Opening/closing*.

Warning light in the driver's door

After locking the vehicle, the warning light flashes for around 2 seconds in quick succession, afterwards it begins to flash evenly at longer intervals.

If the vehicle is locked and the safe securing system » [page 27](#) is not operating, the warning light in the driver door flashes for about 2 seconds fast, goes out and starts to flash evenly at longer intervals after about 30 seconds.

If the indicator light first flashes fast for about 2 seconds, then lights up for about 30 seconds continuously and then flashes slowly, there is a fault in the central locking system or in the interior monitor and in the towing protection » [page 31](#). Seek help from a ŠKODA specialist garage.

Convenience operation of windows

The windows can be opened and closed when unlocking and locking the vehicle » [page 35](#).


Individual settings

Opening a single door

This selection function makes it possible to only unlock the driver's door. The other doors remain locked and are only unlocked when the command is repeated.

Automatic locking and unlocking

All the doors and the boot lid are locked automatically once the car reaches a speed of about 15 km/h.

If the ignition key is withdrawn, the car is then automatically unlocked again. In addition, it is possible for the driver or front passenger to unlock the car by pressing the central locking button  » [page 29](#).

The doors can be unlocked and opened from the inside by a single pull on the opening lever of the respective door.

! WARNING

Locked doors prevent unwanted entry into the vehicle from outside, for example at road crossings. Locked doors do, however, make it more difficult for rescuers to get into the vehicle in an emergency - danger to life!

i Note

- Upon request you can have custom settings activated by a ŠKODA Service Partner.
- In the event of an accident in which the airbags are deployed, the locked doors are automatically unlocked in order to enable rescuers to gain access to the vehicle.
- Only the driver's door can be unlocked or locked using the key if the central locking system fails » [page 28](#). The other doors and the boot lid can be manually locked or unlocked.
 - Emergency locking of the door » [page 32](#).
 - Emergency unlocking of the boot lid » [page 33](#).

Safe securing system

The central locking system is equipped with a **safe securing system**. The door locks are blocked automatically if the vehicle is locked from the outside. The warning light flashes for around 2 seconds in quick succession, afterwards it begins to flash evenly at longer intervals. It is not possible to open the doors with the door handle either from the inside or from the outside. This acts as an effective deterrent for attempts to break into your vehicle.

The safe securing system can be deactivated within 2 seconds by double locking the vehicle.

If the safe securing system is not operating, the warning light in the driver door flashes for about 2 seconds fast, goes out and starts to flash evenly at longer intervals after about 30 seconds.

The safe securing system is activated again the next time the vehicle is unlocked and locked.

If the vehicle is locked and the safe securing system is deactivated, the door can be opened from the inside by a single pull on opening lever of the respective door.

! WARNING

If the vehicle is locked from the outside and the safe securing system is activated, there must not be any person in the vehicle as it is then no longer possible to open either a door or a window from the inside. The locked doors make it more difficult for rescuers to get into the vehicle in an emergency - hazard!

i Note

- The anti-theft alarm system is activated when the vehicle is locked even if the safe securing system is deactivated. The interior monitor is however not activated.
- After locking the vehicle, you will be informed that the safe securing system is activated by means of the message **CHECK DEADLOCK** on the instrument cluster display. On vehicles that are equipped with an information display, the following message will appear **Check deadlock! Owner's manual!** appears.

Unlocking the vehicle using the key




Fig. 12
Turning the key for unlocking
and locking the vehicle

- Turn the key in the locking cylinder of the driver's door in the direction of travel (unlocking position) **A** » Fig. 12.
- Pull the door handle and open the door.

- All the doors (only the driver's door on vehicles with anti-theft alarm system) are unlocked.
- The boot lid is then unlocked.
- The switched on interior lights come on over the door contact.
- The safe securing system is deactivated.
- The windows open while the key **is held** in the unlock position.
- The warning light in the driver door stops flashing if the car is not fitted with an anti-theft alarm system » page 31.

i Note

If the vehicle is equipped with an anti-theft alarm system, you must insert the key into the ignition lock and switch the ignition on within 15 seconds after unlocking the door in order to deactivate the anti-theft alarm system. The **alarm is triggered** if the ignition is **not switched on** within 15 seconds.

Locking the vehicle with the key

- Turn the key in the locking cylinder of the driver's door in the opposite direction of travel (lock position) **B** » Fig. 12 on page 28.
- All the doors and the boot lid are locked.
- The switched on interior lights will switch off over the door contact.
- The windows and the electric sliding/tilting roof close while the key **is held** in the lock position.
- The safe securing system is immediately activated.
- The warning light in the driver door begins flashing.

i Note

If the driver's door has been opened, the vehicle cannot be locked.

Vehicle locking/unlocking from the inside





Fig. 13
Centre console: Central locking
button

If the vehicle was not locked from the outside, you can also unlock and lock it with the rocker switch » Fig. 13 without the ignition switched on.

Locking all doors and the boot lid

➤ Press the button in the area  » Fig. 13. The symbol  in the button comes on.

Unlocking all doors and the boot lid

➤ Press the button in the area  » Fig. 13. The symbol  in the button is no longer illuminated.

The following applies if your vehicle has been locked using the central locking button.

- It is not possible to open the doors or the boot lid from the outside (safety feature, e.g. when stopping at traffic lights etc.).
- The doors can be unlocked and opened from the inside by a single pull on the opening lever of the respective door.
- If at least one door has been opened, the vehicle cannot be locked.
- In the event of an accident in which the airbags are deployed, the locked doors are automatically unlocked from the inside in order to enable rescuers to gain access to the vehicle.

! WARNING

The central locking system also operates if the ignition is switched off. Children should never be left unattended in the vehicle since it is difficult to provide assistance from the outside when the doors are locked. Locked doors make it difficult for rescuers to get into the vehicle in an emergency - hazard!

i Note

If the safe securing system is activated» page 27, the door opening lever and the central locking buttons do not operate.

Remote control

Introductory information

You can use the remote control key to:

- unlock and lock the vehicle,
- unlocking boot lid;
- open and close the windows » page 35, *Window convenience operation*.

The transmitter with the battery is housed in the handle of the remote control key. The receiver is located in the interior of the vehicle. The operating range of the remote control key is approx. 30 m. But this range of the remote control can be reduced if the batteries are weak.

The key has a fold-open key bit which can be used for unlocking and locking the car manually and also for starting the engine.

If a lost key is replaced or if the receiver unit has been repaired or replaced, the system must be initialised by a ŠKODA Service Partner. Only then can the remote control key be used again.

i Note

- The remote control is automatically deactivated when the ignition is switched on.
- The operation of the remote control may temporarily be affected by interference from transmitters close to the car and which operate in the same frequency range (e.g. mobile phone, TV transmitter).
- The battery must be replaced if the central locking or anti-theft alarm system does react to the remote control at less than 3 metres away » page 25.
- If the driver door is open, the vehicle cannot be locked using the remote control key.

Unlocking/locking




Fig. 14
Remote control key

Unlocking the vehicle

➤ Press the button **1** » Fig. 14.

Locking the vehicle

➤ Press the button **3** » Fig. 14.

Deactivating the safe securing system

➤ Press the button **3** » Fig. 14 twice within 2 seconds. Further information » page 27.

Unlocking the boot lid

➤ Press the button **2** » Fig. 14. Further information » page 33.

Folding out the key bit

➤ Press the button **4** » Fig. 14.

Folding in the key bit

➤ Press the button **4** » Fig. 14 and fold in the key bit.

Unlocking

The turn signal lights flash twice as confirmation that the vehicle has been unlocked. If the vehicle is unlocked using button **1** » Fig. 14 and none of the doors or the boot lid are opened within the next 30 seconds, the vehicle is automatically locked again and the safe securing system or anti-theft alarm system is reactivated. This function is intended to prevent the car being unlocked unintentionally.

In addition, when the car is unlocked, the electrically adjustable seats and exterior mirrors move into the position assigned to this key. The stored setting of driver seat and exterior mirrors is retrieved.

Locking



The turn signal lights flash once to confirm that the vehicle has been correctly locked.

If the doors or the boot lid remain open after the vehicle has been locked, the turn signal lights do not flash until they have been closed.

WARNING

If the car is locked from the outside and the safe securing system is activated, there must not be any person in the car as it is then not possible to open either a door or a window from the inside. The locked doors make it more difficult for rescuers to get into the vehicle in an emergency - hazard!

Note

- Only operate the remote control when the doors and boot lid are closed and the vehicle is in your line of sight.
- To avoid the car being locked inadvertently once in the car, the lock button  of the remote control must not be pressed before the key is inserted into the ignition lock. Should this happen, press the unlock button  of the remote control.

Synchronization

If the vehicle cannot be unlocked by actuating the remote control system then it is possible that the code in the key and the control unit in the vehicle are no longer synchronised. This can occur when the buttons on the radio-operated key are actuated a number of times outside of the operative range of the equipment or the battery on the remote control was replaced.

This means it is necessary to synchronise the code as follows:

- press any button on the remote control key;
- pressing of the button means that the door will unlock with the key within 1 minute.

Anti-theft alarm system

Introductory information

The anti-theft alarm system increases the level of protection against people seeking to break into the vehicle. The system triggers audible and visual warning signals if an attempt is made to break into the vehicle.

How is the alarm system activated?

The anti-theft alarm system is activated when the vehicle is locked with the radio remote control or the key in the driver's door. It is activated 30 seconds after locking the door.

How is the alarm system deactivated?

The alarm system is deactivated by pressing the unlock button on the radio remote control. The anti-theft alarm system is reactivated if the vehicle is not opened within 30 seconds after transmitting the radio signal.

If the vehicle is unlocked by inserting the key into the driver door, the key must be inserted into the ignition lock and the ignition switched on within 15 seconds of unlocking the door to deactivate the alarm system. The **alarm is triggered** if the ignition is **not switched on** within 15 seconds.

When is the alarm triggered?

The following security areas of the locked vehicle are monitored:

- bonnet;
- boot lid;
- doors;
- ignition lock;
- Vehicle inclination » page 31;
- Interior of the vehicle » page 31;
- A drop in voltage of the on-board power supply;
- Socket of the factory-fitted towing device.

An alarm is immediately triggered if either of the two battery terminals is disconnected while the anti-theft alarm system is activated.

How is the alarm switched off?

The alarm is switched off by unlocking the vehicle with the radio remote control or switching on the ignition.

Note

- The working life of the alarm siren is 5 years.
- Before leaving the car, it must be checked that all of the windows, doors and the electric sliding/tilting roof are properly closed to ensure the full functionality of the anti-theft alarm system.
- Coding of the radio remote control and the receiver unit precludes the use of the radio remote control from other vehicles.

Interior monitor and towing protection





Fig. 15
Button for interior monitor and towing protection

The interior monitor detects movements inside the car and then triggers the alarm.

Switching off

- Switch off the ignition.
- Open the driver door.
- Press the button  » Fig. 15 in the driver's door.
- Lock the vehicle within 30 seconds.

The interior monitor and the towing protection are switched on again automatically the next time the car is locked.

i Note

- Switch off the interior monitor and the towing protection if there is a possibility of the alarm being triggered by movements from (e.g. children or animals) within the vehicle interior or if the vehicle has to be transported (e.g. by train or ship) or towed.
- The opened glasses storage compartment reduces the effectiveness of the interior monitor. To ensure the full functionality of the interior monitor, the glasses storage compartment must always be closed before locking the vehicle.

Emergency locking of the doors




Fig. 16
Rear door: Emergency locking of the door

An emergency locking mechanism is located on the face side of the doors which have no locking cylinder, it is only visible after opening the door.

Locking

- Remove the panel **A** » Fig. 16.
- Insert the key into the slot **B** and turn it into the horizontal position in the direction of the arrow (mirror-inverted on the right doors).
- Replace the cover.

After closing the door, it no longer be opened from the outside. The door can be unlocked from the inside by pulling on the door handle again, and then opened from the outside.

Boot lid

Introduction

This chapter contains information on the following subjects:

Opening/closing	33
Automatic locking	33
Emergency unlocking	33

WARNING

- Ensure that the lock is properly engaged after closing the boot lid. Otherwise, the boot lid might open suddenly when driving even if the boot lid lock was closed - risk of accident!
- Never drive with the boot lid fully opened or slightly ajar otherwise exhaust gases may get into the interior of the vehicle - risk of poisoning!
- Do not press on the rear window when closing the boot lid, it could crack - risk of injury!

i Note

- **After closing the boot lid, it is automatically locked within 1 second and the anti-theft alarm system is activated.** This applies only if the vehicle was locked before closing the boot lid.
- The function of the handle above the licence plate is deactivated when starting off or at a speed of 5 km/hour or more for vehicles with central locking. The function of the handle is activated again when the vehicle has stopped and a door is opened.

Opening/closing







Fig. 17 Unlock the boot lid/boot lid handle

 First read and observe the introductory information and safety warnings  on page 32.

After unlocking the vehicle, you can open the lid by pushing the handle located above the licence plate.

Opening the boot lid for vehicles without central locking

➤ Press the button  in the driver's door » Fig. 17 - **A** and open the boot lid in the direction of arrow » Fig. 17 - **B**.

Opening the boot lid for vehicles with central locking

➤ Push the handle and lift the boot lid in the direction of the arrow » Fig. 17 - **B**.

Closing


➤ Pull down the boot lid and close it with a slight swing.

A handle which makes the closing easier is located on the inner panelling of the boot lid.


Automatic locking

 First read and observe the introductory information and safety warnings  on page 32.

If the vehicle was locked with the button  on the remote control key before the boot lid was closed, the lid is automatically locked as soon as it is closed.

The delayed automatic locking function of the boot lid can be activated on your vehicle. The following applies following activation of this function: If the boot lid was locked with the button  on the remote control key **2** » page 30, then it is possible to open the lid within a limited period of it being closed.

If you wish, a ŠKODA Service Partner can activate or deactivate the delayed automatic locking of the boot lid. The Service Partner will also provide any further information that is required.

There is a risk of unwanted entry into the vehicle before the boot lid is locked automatically. Always lock the vehicle using the button  on the remote control or with the key if no remote control is available » page 28.

Emergency unlocking





Fig. 18
Emergency unlocking of the boot lid

 First read and observe the introductory information and safety warnings  on page 32.

The boot lid can be unlocked manually if there is a fault in the central locking system.

Unlocking

- Fold the rear seat backrest forward » page 52, *Rear seats*.
- Insert a screwdriver or similar tool into the opening in the trim in the direction of the arrow **1** » Fig. 18 as far as the stop.
- Unlock the lock **3** under the trim in the direction of arrow **2**.
- Open the boot lid.

Electrical power windows

Introduction

This chapter contains information on the following subjects:

Opening/closing the windows	34
Force limiter of the electrical power windows	35
Window convenience operation	35
Operational faults	35

! WARNING

- If the vehicle is locked from the outside, do not leave anybody in the vehicle as it is not possible to open the windows from the inside in the event of an emergency.
- The system is fitted with a force limiter » page 35. If there is an obstacle, the closing process is stopped and the window goes down by several centimetres. The windows should nevertheless be closed carefully! Otherwise these can cause severe crushing injuries!
- It is recommended to deactivate the electrical power windows in the rear doors (safety pushbutton) **S** » Fig. 19 on page 34 when children are being transported on the rear seats.

! CAUTION

- Keep the windows clean to ensure the correct functionality of the electric windows.
- In the event that the windows are frozen, first of all eliminate the ice » page 132, *De-icing windows and exterior mirrors* and only then operate the electrical power windows. Otherwise, the electrical power window mechanism could be damaged.
- When leaving the locked vehicle make sure that the windows are closed at all times.

i Note

- After switching the ignition off, it is still possible to open or close the windows for approx. 10 minutes. The electrical power windows are only switched off completely once the driver's door or front passenger door are opened.
- When driving always use the existing heating, air conditioning and ventilation system for ventilating the interior of the vehicle. If the windows are opened, dust as well as other dirt can get into the vehicle and in addition the wind noise is more at certain speeds.
- At high speeds, you should keep the windows closed to prevent unnecessarily high fuel consumption.

Opening/closing the windows



Fig. 19 Buttons on the driver's door/in the rear doors

First read and observe the introductory information and safety warnings ! on page 34.

The electrical power windows can only be operated when the ignition is switched on.

Opening

- A window is opened by pressing lightly on the respective button in the door. The opening process stops when one releases the button.
- Additionally, the window can be opened automatically (fully open) by pressing the button to the stop. Renewed pressing of the button causes the window to stop immediately.

Closing

- A window is closed through pulling lightly on the respective button in the door. The closing process stops when one releases the button.

- Additionally, the window can be closed automatically (fully closed) by pulling the button to the stop. Renewed pulling of the button causes the window to stop immediately.

Buttons for the electrical power windows

- A** Button for electrical power window of the driver's door
- B** Button for electrical power window of the front passenger door
- C** Button for electrical power window of the rear right door
- D** Button for electrical power window of the rear left door
- S** Safety pushbutton

Safety pushbutton

The buttons for electrical power windows in the rear doors can be deactivated by pressing the safety pushbutton **S** » Fig. 19. The buttons for the electrical power windows in rear doors are activated again by pressing the safety pushbutton **S** again.

If the buttons for the rear doors are deactivated, the warning light  in the safety switch **S** lights up.

Note

The window lift mechanism is equipped with protection against overheating. Repeated opening and closing of the window can cause this mechanism to overheat. If this happens, it will not be possible to operate the window for a short time. You will be able to operate the window again as soon as the overheating protection has cooled down.

Force limiter of the electrical power windows

 First read and observe the introductory information and safety warnings  on page 34.

The electrical power windows are fitted with a force limiter. It reduces the risk of bruises or injuries when closing the windows.

If there is an obstacle, the closing process is stopped and the window goes down by several centimetres.

If the obstacle prevents the window from being closed during the next 10 seconds, the closing process is interrupted once again and the window goes down by several centimetres.

If you attempt to close the window again within 10 seconds of the window being moved down for the second time, even though the obstacle was not yet been removed, the closing process is only stopped. During this time it is not possible to automatically close the window. The force limiter is still switched on.

The force limiter is only switched off if you attempt to close the window again within the next 10 seconds - **the window will now close with full force!**

If you wait longer than 10 seconds, the force limiter is switched on again.

Window convenience operation


 First read and observe the introductory information and safety warnings  on page 34.

The electrical power windows can be opened and closed as follows when unlocking and locking the vehicle.

Opening

- Press and hold the unlock button  on the remote control key.
- Hold the key in the driver's lock in the unlock position.

Closing

- Press and hold the lock button  on the remote control key.
- Hold the key in the driver's lock in the lock position.

You can interrupt the opening or closing process for the windows immediately by releasing the key or the lock button.

Operational faults

 First read and observe the introductory information and safety warnings  on page 34.

Electrical power windows do not operate

If the battery has been disconnected and then reconnected while the window was opened, the electrical power windows will not operate. The system must be activated. Proceed as follows in order to re-establish the function:

- switch on the ignition;
- pull the top edge of the button in the driver's door to close the window;
- release the button;
- pull the relevant button upwards again for approx. 3 seconds.

Operation in winter

In the winter, ice accumulating on the surface of the window may cause there to be more resistance when closing the window. The window will stop and move back several centimetres.

It is necessary to deactivate the force limiter to close the window » page 35.

Electric sliding/tilting roof

Introductory information




Fig. 20
Control dial for the power sliding/tilting roof

The sliding/tilting roof is operated by means of the control dial » Fig. 20 and only functions when the ignition is switched on. The control dial has several positions.

The sliding/tilting roof can still be opened, closed and tilted for approx. 10 minutes after switching the ignition off. However, as soon as one of the front doors is opened it is no longer possible to operate the sliding/tilting roof.

i Note

If the battery has been disconnected and reconnected, it is possible that the sliding/tilting roof does not close fully. This is why the rotary switch must be set to the switch position **A** » Fig. 20 and pressed forward for about 10 seconds.

Using the system

Comfort position

» Turn the switch to position **C** » Fig. 20 on page 36.

Opening fully

» Turn the switch to position **B** » Fig. 20 on page 36 and hold it in this position (spring-tensioned position).

Tilting roof

» Turn the switch to position **D** » Fig. 20 on page 36.

Closing

» Turn the switch to position **A** » Fig. 20 on page 36.

Force limiter

The sliding/tilting roof is fitted with a force limiter. If an obstacle (e.g. ice) prevents closing, the sliding/tilting roof stops and opens completely. The sliding/tilting roof can be closed completely without the force limiter by turning the switch into position **A** » Fig. 20 on page 36 at the front for as long as it takes for the sliding/tilting roof to close completely » **!**

When the sliding/tilting roof is in the comfort position, the intensity of the wind noise is much less.

The sun screen is also opened automatically when the roof slides open.

! WARNING

Close the sliding/tilting roof carefully - risk of injury!

! CAUTION

During the winter it may be necessary to remove any ice and snow in the vicinity of the sliding/tilting roof before opening it to prevent any damage to the opening mechanism and seal.

Convenience operation

An open sliding/tilting roof can also be closed from the outside.

» Press and hold the lock button **(L)** on the remote control key or keep the key in the lock cylinder of the driver's door in the locked position » **!**

The closing operation stops immediately when you release the key or the lock button.

! WARNING

Close the sliding/tilting roof carefully - risk of injury! The force limiter does not operate with the convenience closing.

Emergency operation




Fig. 21 Point for positioning screwdriver/opening for positioning the key

The sliding/tilting roof can be closed or opened manually if the system is faulty. The emergency operation of the sliding roof is located underneath the glasses storage box [1] » page 67, *Glasses storage box*.

- Open the glasses storage box.
- Carefully insert an approximately 5 mm wide screwdriver into the slot in the positions shown by the arrows [1] » Fig. 21.
- Carefully fold the glasses storage box downwards by gently pressing down and turning the screwdriver.
- Insert an Allen key, SW 4, up to the stop into the opening [2] and close or open the sliding/tilting roof.
- Reinstall the glasses storage box by first inserting the plastic plugs and then pushing the entire part upwards.

Have the fault rectified by a ŠKODA specialist garage.

i Note

It is necessary after each emergency operation (using the Allen key) to move the sliding/tilting roof into the basic position. This is why the rotary switch must be set to the switch position [A] » Fig. 20 on page 36 and pressed forward for about 10 seconds.

Lights and visibility

Lights

Introduction

This chapter contains information on the following subjects:

Switching lights on and off	38
DAY LIGHT function (Daylight driving light)	39
Halogen projector headlights with cornering light function	39
Parking light	39
Tourist light	40
Fog lights	40
Fog lights with the function CORNER	40
Rear fog light	41
Headlight beam adjustment	41
Switches for the hazard warning light system	42
Turn signal and main beam lever	42

On models fitted with **right-hand steering** the position of certain switches differs from that shown in » Fig. 22 on page 38. The symbols which mark the switch positions are identical, however.

! WARNING

Never drive with only the side lights on! The side lights are not bright enough to light up the road sufficiently in front of you or to be seen by other oncoming traffic. Therefore always switch on the low beam when it is dark or if visibility is poor.

! CAUTION

- The activation of the lights should only be undertaken in accordance with national legal requirements.
- The driver is always responsible for the correct settings and use of the lights.

i Note

- If the light switch is in the position \Rightarrow , the ignition key is removed and the driver's door is open, an audible warning signal will sound. The audible warning signal is switched off by means of the door contact when the driver's door is closed (ignition off), however, the side lights remain on to illuminate the parked vehicle if necessary.
- In vehicles with separate lights for daylight driving lights (in the bumper below the main headlights) these lights also serve as side lights.
- In the event of cool or humid weather conditions, the headlights can be misted up from inside. The temperature difference between interior and external area of the headlight lenses is decisive. When the driving lights are switched on, the light outlet surfaces are free from mist after a short period, although the headlight lenses may still be misted up in the peripheral areas. It also concerns reverse light and turn signal lights. This mist has no influence on the life of the lighting system. ■

Switching lights on and off




Fig. 22 Dash panel: Light switch/fuse box: Switch for daylight driving lights

First read and observe the introductory information and safety warnings ! on page 38.

Switching on the parking light

- Turn the light switch » Fig. 22 - A to position \Rightarrow .

Switching on the low beam and main beam

- Turn the light switch » Fig. 22 - A to position \Rightarrow .
- Press the main beam lever forward in order to switch on the main beam » Fig. 26 on page 42.

Switching off lights (except daytime running lights)

- Turn the light switch » Fig. 22 - [A] to position 0.

DAY LIGHT function (Daylight driving light)





First read and observe the introductory information and safety warnings  on page 38.

Switching on

- Remove the cover on the fuse box on the left-hand side of the dash panel » page 169, *Fuses in the dash panel*.
- Turn the light switch into position 0 » Fig. 22 on page 38 - [A].
- Switch on the switch for daylight driving lights » Fig. 22 on page 38 - [B].

Switching off

- Remove the cover on the fuse box on the left-hand side of the dash panel » page 169, *Fuses in the dash panel*.
- Switch off the switch for daylight driving lights » Fig. 22 on page 38 - [B].
- Turn the light switch to the position Parking light  or Low beam  » Fig. 22 on page 38 - [A].

Activating daylight driving lights for vehicles with the START-STOP system

- Switch off the ignition.
- At the same time, slide the turn signal light lever upwards and hold it in this position for at least 3 seconds.
- Switch on the ignition - wait until the right-turn signal light flashes 4x.
- Switch off the ignition - an audible signal sounds which confirms the activation of the daylight driving lights.
- Release the turn signal lever.

Deactivating daylight driving lights for vehicles with the START-STOP system

- Switch off the ignition.
- At the same time, slide the turn signal light lever downwards and hold it in this position for at least 3 seconds.
- Switch on the ignition - wait until the left-turn signal light flashes 4x.
- Switch off the ignition - an audible signal sounds which confirms the deactivation of the daylight driving lights.
- Release the turn signal lever.

On vehicles with separate lights for daylight driving lights in the fog lights or in the front bumper, the parking lights and the licence plate light do not come on when activating the function daylight driving lights (neither front nor rear).

If the vehicle is not equipped with separate lights for daylight driving lights, the combination of the low beam, the parking lights (front and rear) including the licence plate light is used as daylight driving lights.

Halogen projector headlights with cornering light function



First read and observe the introductory information and safety warnings  on page 38.

For a better cornering illumination, the halogen projector headlights with cornering light function are set in the optimal position in line with the vehicle speed and the steering angle.



WARNING

If the halogen projector headlights with cornering light function are faulty, the headlights are automatically lowered to the emergency position, which prevents a possible dazzling of oncoming traffic. Thus the illuminated length of the road is shortened. Drive carefully and visit a ŠKODA specialist garage as soon as possible.

Parking light



First read and observe the introductory information and safety warnings  on page 38.

Parking light


- Switch off the ignition.
- Pull the turn signal light lever » Fig. 26 on page 42 upwards or downwards - the side light on the right or left side of the vehicle is switched.

Parking light on both sides


- Turn the light switch into the position  and lock the vehicle.



Note

- The parking light  can only be activated if the ignition is switched off.
- If the right or left turn signal light has been switched on and the ignition is switched off, the parking light is not automatically switched on.

Tourist light

 First read and observe the introductory information and safety warnings  on page 38.

Halogen projector headlights with cornering light function

This mode makes it possible to drive in countries with opposing traffic system (driving on the left/right) without dazzling the oncoming vehicles. When the mode "tourist light" is active, the side to side swivel of the headlights is deactivated.


Activating tourist light

Before activating the tourist light, the following conditions must be met.

Ignition switched off, light switched off (light switch in the position 0), control dial for the headlamp beam adjustment in the position -, no gear engaged or selector lever in the position N (automatic gearbox), tourist light deactivated.

> Switch on the ignition.

within 10 seconds of the ignition being switched on:

- > Turn the light switch to position  » page 38, *Switching lights on and off*.
- > Engage reverse gear (manual gearbox) or move the selector lever into the position R (automatic gearbox),
- > Turn the control dial for headlamp beam adjustment from the position - to the position 3 » page 41.


Deactivating tourist light

Before deactivating the tourist light, the following conditions must be met.

Ignition switched off, light switched off (light switch in the position 0), control dial for the headlamp beam adjustment in the position 3, no gear engaged or selector lever in the position N (automatic gearbox), tourist light activated.


> Switch on the ignition.

within 10 seconds of the ignition being switched on:

- > Turn the light switch to position  » page 38, *Switching lights on and off*.
- > Engage reverse gear (manual gearbox) or move the selector lever into the position R (automatic gearbox),
- > Turn the control dial for headlamp beam adjustment from the position 3 to the position - » page 41.

Further information » page 125, *Headlights*.



Note

When the "tourist light" mode is active, the warning light  flashes for 10 seconds each time the ignition is switched on.

Fog lights




Fig. 23
Dash panel: Light switch



 First read and observe the introductory information and safety warnings  on page 38.

Switching on

- > First of all, turn the light switch » Fig. 23 to position  or .
- > Pull the light switch to position .

The warning light  lights up in the instrument cluster when the fog lights are switched on » page 17.

Fog lights with the function CORNER



 First read and observe the introductory information and safety warnings  on page 38.

The fog lights with the function CORNER are designed to improve the illumination of the surrounding area near the vehicle when turning, parking, etc. ▶

The fog lights with the function CORNER are adjusted according to the steering angle or after switching on the turn signal light¹⁾ in the following circumstances:




- > the vehicle is stationary and the engine is running or it moves with a speed of maximum 40 km/h;
- > the daytime running lights are not switched on;
- > the low beam is switched on;
- > the fog lights are not switched on;
- > no reverse gear is engaged.

Rear fog light

 First read and observe the introductory information and safety warnings  on page 38.

Switching on

- > First of all, turn the light switch » Fig. 23 on page 40 to position  or .
- > Pull the light switch to position .

If the vehicle is not fitted with fog lights » page 40, the rear fog light is switched on by turning the light switch to the position  or  and is pulled out directly to the position . This switch does not have two positions, but only one position.

The warning light  lights up in the instrument cluster when the rear fog light is switched on » page 17.

Only the rear fog light on the trailer lights up if the vehicle has a factory-fitted towing device or a towing device from ŠKODA original accessories and it is driven with a trailer and the rear fog light switched on.

Headlight beam adjustment







Fig. 24
Dash panel: Lights and visibility

 First read and observe the introductory information and safety warnings  on page 38.

- > Turn the control dial » Fig. 24 to the desired width of illumination.

Settings

The positions correspond approximately to the following car load.

-  Front seats occupied, boot empty.
-  All seats occupied, boot empty.
-  All seats occupied, boot loaded.
-  Driver seat occupied, boot loaded.

CAUTION

Always adjust the headlight range adjustment in such a way that:

- it does not dazzle other road users, especially oncoming traffic;
- and the range is sufficient for safe driving.

Note

We recommend you adjust the headlight beam when the low beam is switched on.

¹⁾ If both switch on versions are conflicting, for example if the steering wheel is turned to the left and the right turn signal light is switched on, the turn signal light has the higher priority.

Switches for the hazard warning light system



Fig. 25
Dash panel: Switch for hazard warning lights

First read and observe the introductory information and safety warnings on page 38.

> Press switch » Fig. 25 to switch the hazard warning light system on or off. All the turn signal lights on the vehicle flash at the same time when the hazard warning light system is switched on. The warning light for the turn signals and the warning light in the switch also flash at the same time. The hazard warning light system can also be operated if the ignition is switched off.

The hazard warning light system is switched on automatically if an airbag is deployed in the event of an accident.

Note

The hazard warning light system must be switched on if, for example:

- you encounter a traffic congestion;
- your vehicle breaks down or an emergency situation occurs.

Turn signal and main beam lever




Fig. 26
Turn signal and main beam lever

First read and observe the introductory information and safety warnings on page 38.

The parking light and headlight flasher are also operated with the turn signal and main beam lever.

Right and left turn signal light

- > Push the lever » Fig. 26 upwards or downwards .
- > If you only wish to flash three times (the "convenience turn signal"), briefly push the lever to the upper or lower pressure point and release again.
- > Turn signal for changing lanes - to only flash briefly, move the lever up or down to the pressure point and hold it in this position.

Main beam

- > Switch on the low beam » page 38.
- > Press the lever » Fig. 26 in the direction of arrow .
- > The main beam is switched off by pulling the lever into the initial position in the direction of arrow .

Headlight flasher

- > Pull the lever » Fig. 26 towards the steering wheel (spring-tensioned position) in the direction of arrow - the main beam and the warning light in the instrument cluster come on.



Parking light

Description of the operation » page 39

CAUTION

Only use the main beam or the headlight flasher if other road users will not be dazzled. ▶

i Note

- The **turn signal system** only operates when the ignition is switched on. The corresponding warning light  or  in the instrument cluster also flashes.
- The turn signal is automatically cancelled after negotiating a curve.
- The warning light flashes at twice its normal rate if a bulb for the turn signal light fails.

Interior light

Interior lights at the front





Fig. 27
Interior lights at the front

Door contact switching mechanism (front and rear doors)

- Press switch **A** » Fig. 27 towards the middle of the light, the symbol  appears.

Switching the interior light on

- Press switch **A** » Fig. 27 towards the edge of the light, the symbol  appears.

Switching the interior light off

- Press the switch **A** » Fig. 27 in the middle position **O**.

Reading lights

- Press the switches **B** » Fig. 27 in order to switch the right or left reading light on or off.

On vehicles with central locking, the interior light is switched on for about 30 seconds when the vehicle is unlocked, when a door is opened or after withdrawing the ignition key (if the relevant switch is in the door contact position). The inner light goes out immediately after the ignition is switched on.

A time delay switch causes the inner lighting on vehicles without a central locking system stays on for a few seconds after the doors have been closed. The inner light goes out immediately after the ignition is switched on.

The interior lighting is switched off after about 10 minutes when a door has been left open in order to avoid discharging the battery of the vehicle.

Interior lights at the rear






Fig. 28 Interior lights at the rear: Version 1/Version 2

The interior light » Fig. 28 - **A** is actuated by moving the switch to the symbol , **O** or to the middle position .

The interior light » Fig. 28 **B** is actuated by pressing the switch which has two positions. In the one position, the interior light is switched on permanently; in the other (after pressing), it is switched on via the door contact switching mechanism.

The same principles apply for the interior lighting as for » page 43, *Interior lights at the front*.

Illuminated storage compartment on front passenger side

- When opening the flap of the storage compartment on the front passenger side the lighting in the storage compartment comes on.
- The light switches on automatically when the parking light is switched on and goes out when the flap is closed.

Boot light


The light comes on automatically when the boot lid is opened. If the lid remains open for more than about 10 minutes, the boot light switches off automatically.

Visibility

Rear window heater



Fig. 29
Switch for rear window heater

► The rear window heater is switched on or off by pressing the switch  » Fig. 29 the warning light in the switch comes on or goes out.

The rear window heater only operates when the engine is running.

The rear window heater **switches off** automatically after 7 minutes.



For the sake of the environment

The heating should be switched off as soon as the window is de-iced or free from mist. The reduced current consumption will have a favourable effect on fuel economy » page 124, *Saving electricity*.



Note

If the on-board voltage drops, the rear window heater switches off automatically, in order to provide sufficient electrical energy for the engine control » page 149, *Automatic load deactivation*.

Sun visors






Fig. 30
Sun visor: swivelling out

The sun visor for the driver or front passenger can be pulled out of the fixture and swivelled towards the door in the direction of the arrow  » Fig. 30.

The vanity mirrors in the sun visors are provided with covers. Push the cover in the direction of the arrow .

The purpose of the strap  is to store small, light objects, such as a notepad, etc.



WARNING

The sun visors must not be swivelled towards the side windows in the deployment area of the head airbags if any objects, such as ball-point pens, etc. are attached to them. This might result in injuries to the occupants if the head airbag is deployed.

Windscreen wipers and washers



Introduction

This chapter contains information on the following subjects:

Activating the windscreen wipers and washers	45
Headlight cleaning system	46
Replacing the windscreen wiper blades	46
Replacing the rear window wiper blade - Version 1	46
Replacing the rear window wiper blade - Version 2	47

The windshield wipers and the windshield washer system only operate if the ignition is switched on.

The rear window is wiped once if the windscreen wipers are on when reverse gear is selected.

Top up with windscreen wiper fluid » page 145.

! WARNING

- Properly maintained windscreen wiper blades are essential for clear visibility and safe driving » page 46.
- Do not use the windscreen washer system at low temperatures, without heating the windscreen beforehand. Otherwise the window cleaner could freeze on the windscreen and restrict the view to the front.

! CAUTION

- In cold temperatures and during the winter, check before the journey or before switching on the ignition that the wiper blades are not frozen to the windscreen. If the windscreen wipers are switched on when the blades are frozen to the windscreen, this may damage both the blades and windscreen wiper motor!
- If the ignition is switched off while the windscreen wipers are switched on, the windscreen wipers will continue wiping in the same mode after the ignition is turned back on. The windscreen wipers could freeze up in cold temperatures between the time the ignition was turned off and when it was turned back on again.
- Carefully detach frozen wiper blades from the front or rear window.
- Remove snow and ice from the windscreen wipers before driving.
- If the windscreen wipers are handled carelessly, there is a risk of damage to the windscreen.
- Replace the windscreen wiper blades once or twice a year for safety reasons. These can be purchased from a SKODA Service Partner.

i Note

- The windscreen washer nozzles for the windscreen are heated when the engine is running and the outside temperature is less than approx. +10 °C.
- The content of the windscreen washer fluid reservoir is 3.5 litres. On vehicles fitted with the headlight cleaning system, the volume is around 5.4 litres.
- The wiper blades should be cleaned on a regular basis with a windscreen cleaner to avoid any smears. The wiper blades should be cleaned with a sponge or cloth if they are heavily soiled by insect residues, for example.

Activating the windscreen wipers and washers




Fig. 31
Windscreen wiper lever



First read and observe the introductory information and safety warnings **i** on page 44.

Flick wipe

- If you only wish to wipe the windscreen **briefly**, push the lever into the spring-tensioned position **4** » Fig. 31.

Periodic wiping

- Position the lever upwards into position **1** » Fig. 31.
- Set the desired break between the individual wiper strokes with the switch **A**.

Slow wipe

- Position the lever upwards into position **2** » Fig. 31.

Fast wipe

- Position the lever upwards into position **3** » Fig. 31.

Automatic wipe/wash for windscreen

- Pull the lever towards the steering wheel into the spring-tensioned position **5** » Fig. 31, the wash system and the windshield wipers will operate.
- Release the lever. The windscreen wash system stops and the wiper continues for another 1 - 3 wiper strokes (depending on the period of spraying of the windscreen).

Wiping the rear window pane

- Push the lever away from the steering wheel into position **6** » Fig. 31 and the windscreen wiper will operate every 6 seconds.

Automatic wipe/wash for the rear window

- Push the lever away from the steering wheel into the spring-tensioned position **7** » Fig. 31, the windshield wiper and wash system will operate.

- Release the lever. The washer system stops and the wiper continues for another 1 to 3 wiper strokes (depending on the duration of the spraying process). The lever will stay in position after releasing it [6].

Switching windscreen wipers off

- Move the lever back into the home position [0] » Fig. 31.

Headlight cleaning system



First read and observe the introductory information and safety warnings [1] on page 44.

When the low beam or main beam are switched on, and the windscreen wiper lever is pulled into the position [5] » Fig. 31 on page 45, the headlights are sprayed briefly. To clean the headlights, the windshield is also sprayed after every five squirts.

You should remove stubborn dirt (such as insect residues) from the headlight lenses at regular intervals, for example when refuelling. The following guidelines must be observed » page 132, *Headlight lenses*.

To ensure the proper operation of the cleaning system during the winter, any snow should be removed from the washer nozzle fixtures and ice should be cleared with a de-icing spray.

! CAUTION

Never remove the nozzles from the headlight cleaning system by hand - risk of damage!

Replacing the windscreen wiper blades




Fig. 32
Windscreen wiper blade

B5L-0246



First read and observe the introductory information and safety warnings [1] on page 44.

Removing the wiper blade

- Fold the windscreen wiper arm away from the windscreen.
- Press the locking button [1] » Fig. 32 to unlock the wiper blade and pull off in the direction of the arrow [2].

Attaching the wiper blade

- Push the windscreen wiper blade until the stop and it locks in place.
- Check that the wiper blade is correctly attached.
- Fold the wiper arms back to the windscreen.

Windshield wiper blades in proper condition are essential to obtain good visibility. Wiper blades should not be allowed to become dirtied by dust, insect remains and preserving wax.

Juddering or smearing of the wiper blades could then be due to wax residues left on the windshield by vehicle washing in automatic vehicle wash systems. It is therefore important to **degrease** the lips of the windshield wiper blades after every pass through an **automatic vehicle wash system**.

Replacing the rear window wiper blade - Version 1




Fig. 33
Rear window wiper blade

B5J-0278



First read and observe the introductory information and safety warnings [1] on page 44.

Removing the wiper blade

- Fold the windscreen wiper arm away from the windscreen and position the wiper blade at a right angle to the wiper arm » Fig. 33.
- Hold the windscreen wiper arm at the top end with one hand.

- With the other hand unlock the locking button **A** in the direction of arrow and remove the wiper blade.

Attaching the wiper blade

- Position the wiper blade onto the wiper arm and lock the locking button **A** » Fig. 33.
- Check that the wiper blade is correctly attached.
- Fold the wiper arm back to the windscreen.

Replacing the rear window wiper blade - Version 2




Fig. 34
Rear window wiper blade



First read and observe the introductory information and safety warnings **I** on page 44.

Removing the wiper blade

- Fold the windscreen wiper arm away from the windscreen and position the wiper blade at a right angle to the wiper arm » Fig. 34.
- Hold the windscreen wiper arm at the top end with one hand.
- Unlock the locking button **1** with the other hand and remove the wiper blade in the direction of the arrow **2**.

Attaching the wiper blade

- Push the windscreen wiper blade until the stop and it locks in place.
- Check that the wiper blade is correctly attached.
- Fold the wiper arm back to the windscreen.

Rear window

Manual dimming interior mirror

Basic setting

- Pull the lever on the bottom edge of the mirror forward.

Dimming mirror

- Push the lever on the bottom edge of the mirror backwards.

Additional rear-view mirror




Fig. 35
Additional interior mirror

The additional interior mirror allows the driver a wider field of view of the rear seats.

Adjusting the angle

- Adjust the mirror in direction of arrow to the desired position.



WARNING

Concentrate fully at all times on your driving! As the driver you are fully responsible for the operation of your vehicle. Use the additional interior mirror only to such an extent that you are in full control of your vehicle at any time.

Exterior mirror




Fig. 36
Inner part of door: Rotary knob


Adjust the rear mirror before commencing to drive so that there is a clear view to the rear.

Heating of the external mirror


➤ Place the rotary knob into the position  » Fig. 36.

The exterior mirror heater only operates when the engine is running and up to an outside temperature of +20 °C.

Adjusting the left-hand exterior mirror

➤ Place the rotary knob into the position  » Fig. 36. The movement of the mirror surface is identical to the movement of the rotary knob.

Adjusting the right-hand exterior mirror

➤ Place the rotary knob into the position  » Fig. 36. The movement of the mirror surface is identical to the movement of the rotary knob.

! WARNING

- Convex (curved outward) exterior mirrors increase the field of vision. They do, however, make objects appear smaller in the mirror. These mirrors are therefore only of limited use for estimating distances to the following vehicles.
- Whenever possible use the interior mirror for estimating the distances to the following vehicles.

i Note

- Do not touch the surface of the exterior mirrors if the exterior mirror heater is switched on.
- If the power setting function fails at any time, the exterior mirrors can be set by hand by pressing on the edge of the mirror surface.
- Contact your ŠKODA specialist garage if there is a fault with the power setting of the exterior mirrors.

Seats and Stowage

Front seats

Introduction

This chapter contains information on the following subjects:

Adjusting the front seats - Version 1 _____	50
Adjusting the front seats - Variant 2 _____	50
Front seat heating _____	50

The driver's seat should be adjusted in such a way that the pedals can be fully pressed to the floor with slightly bent legs.

The seat backrest on the driver's seat should be adjusted in such a way that the upper point of the steering wheel can be easily reached with slightly bent arms.

Correct adjustment of the seats is particularly important for:

- safely and quickly reaching the controls;
- a relaxed, fatigue-free body position;
- **achieving the maximum protection offered by the seat belts and the airbag system.**

WARNING

- Only adjust the driver's seat when the vehicle is stationary - risk of accident!
- Caution when adjusting the seat! You may suffer injuries or bruises as a result of adjusting the seat without paying proper attention.
- The seat backrests must not be angled too far back when driving otherwise this will affect proper operation of the seat belts and of the airbag system - risk of injury!
- Never carry more people than the number of seats in the vehicle.
- Each occupant must correctly fasten the seat belt belonging to the seat. Children must be fastened » [page 117](#), *Transporting children safely with a suitable restraint system.*

WARNING (Continued)

- The front seats and the head restraints must always be adjusted to match the body size of the seat occupant as well as the seat belts must always be correctly fastened in order to provide an optimal protection for you and your occupants.
- Always keep your feet in the footwell when the car is being driven - never place your feet on the instrument panel, out of the window or on the surfaces of the seats. This is particularly important for the front seat passenger. You will be exposed to increased risk of injury if it becomes necessary to apply the brake or in the event of an accident. If an airbag is deployed, you may suffer fatal injuries when adopting an incorrect seated position!
- It is important for the driver and front passenger to maintain a distance of at least 25 cm from the steering wheel or dash panel. Not maintaining this minimum distance will mean that the airbag system will not be able to properly protect you - hazard!
- Ensure that there are no objects in the footwell as they may get caught behind the pedals when driving or applying the braking. You would then no longer be able to operate the clutch, brake or accelerate.
- Do not transport any objects on the front passenger seat except objects (e.g. child safety seat) provided for this purpose - risk of accident!

Note

After a certain time, play can develop within the adjustment mechanism of the backrest angle.

Adjusting the front seats - Version 1




Fig. 37
Control elements at the seat

First read and observe the introductory information and safety warnings on page 49.

Adjusting a seat in a forward/back direction

- Pull the lever » Fig. 37 up and push the seat into the desired position.
- Release the lever and push the seat until the lock clicks into place.

Adjusting height of seat

- To lift the seat, pull or pump the lever » Fig. 37 upwards.
- To lower the seat, push or pump the lever downwards.

Adjusting the angle of the seat backrest

- To adjust the angle of the backrest, relieve any pressure from the seat backrest (do not lean on it) and turn the handwheel » Fig. 37.

Adjusting the front seats - Variant 2




Fig. 38
Control elements at the seat



First read and observe the introductory information and safety warnings on page 49.

Adjusting a seat in a forward/back direction

- Pull the lever (in the middle area) » Fig. 38 up and push the seat into the desired position.
- Release the lever and push the seat until the lock clicks into place.

Adjusting height of seat

- To lift the seat, pull or pump the lever » Fig. 38 upwards.
- To lower the seat, push or pump the lever downwards.

Adjusting the angle of the seat backrest

- Remove the load on the seat backrest (do not lean on it), pull the lever » Fig. 38 towards the rear and set the desired angle of the seat backrest with the back.
- After releasing the lever , the seat backrest will remain in the set position.

Front seat heating



Fig. 39
Rocker switch for front seat heating



First read and observe the introductory information and safety warnings on page 49.

The seat backrests and seats can be heated electrically.

- By pressing the rocker switch in the position or switch on the front seat heating to 25 % or 100 % of its power output » Fig. 39.
- To switch off the heating shift the rocker switch into the horizontal position.

! WARNING

If, as an occupant, you have a subdued pain and/or temperature sensitivity, e.g. through medication, paralysis or because of chronic illness (e.g. diabetes), we recommend not to use the seat heating. This can lead to burns on the back, the posterior and the legs which are difficult to heal. If the seat heating is used, we recommend to make regular breaks in your journey when driving long distances, so that the body can recuperate from the stress of the journey. Please consult your doctor, who can evaluate your specific condition.

! CAUTION

- Do not kneel on the seats or otherwise apply pressure at specific points to avoid damaging the heating elements for the seat heaters.
- Do not use the seat heaters if the seats are not occupied by persons or if objects, such as a child seat, bag, etc., are fastened or stored on them. A fault of the heating elements in the seat heating can occur.
- Do not clean the seats using moisture » [page 134](#).

i Note

- The seat heating should only be switched on when the engine is running. This has a significant effect of saving on the battery capacity.
- If the on-board voltage drops, the seat heating is switched off automatically, in order to provide sufficient electrical energy for the engine control » [page 149](#), *Automatic load deactivation*.

Adjusting the height of a head restraint

- Grasp the side of the head restraint with both hands and push it upwards as required » [Fig. 40 - A](#).
- To move the head restraint downwards, press and hold the safety button » [Fig. 40 - B](#) with one hand and press the head restraint downwards with the other hand.

Removing and installing a head restraint

- Pull the head restraint out of the seat backrest as far as the stop.
- Press the locking button in direction of the arrow » [Fig. 40 - B](#) and pull the head restraint out.
- To re-insert the head restraint, push it far enough down into the seat backrest until the locking button clicks into place.

Best protection is achieved if the top edge of the head restraint is at the same level as the upper part of your head.

The head restraints must be adjusted to match the size of the seat occupant. Correctly adjusted head restraints together with the seat belts offer effective protection for the occupants » [page 104](#).

! WARNING

- The head restraints must be correctly adjusted in order to offer effective protection for the occupants in the event of an accident.
- Never drive with the head restraints removed - risk of injury!
- If the rear seats are occupied, the rear head restraint must not be in the lower position.

Head restraints




Fig. 40 Head restraint: adjusting/removing

Rear seats

Folding the seat backrest forwards




Fig. 41
Unlock the seat backrest

The luggage compartment can be increased in size by folding the seat backrests forward. The seat backrests can be folded forward individually on vehicles with divided rear seats.

Folding forward

- Before folding the rear seats forwards, adapt the position of the front seats in such a way that they are not damaged by the folded rear seats.
- Unlock the seat backrest by pressing the securing knob **A** » Fig. 41 and fold it forwards.
- Pull the head restraint out of the seat backrest.
- Fold the seat backrest completely forwards.

Folding backwards

- Push the head restraint into the slightly lifted seat backrest.
- Then push the seat backrest back into the upright position until the securing knob clicks into place - check by pulling on the seat backrest » **!**.
- Make sure that the red pin **B** is hidden.

! WARNING

- The belts and the belt locks must be in their original position after folding back the seat backrests - they must be ready to use.
- The seat backrests must be securely interlocked in position so that no objects in the boot can slide into the passenger compartment if there is sudden braking - risk of injury.
- Ensure that the rear seat backrests are properly engaged. It is only then that the three-point seat belt for the middle seat can reliably fulfil its function.

! CAUTION

Ensure that the seat belts are not damaged when operating the seat backrests. Under no circumstances must the rear seat belts be jammed by the folded back seat backrests.

i Note

On vehicles with an installed net partition housing, first fold back the left seat rest followed by the right one.

Folding the seat cushions forwards, removing




Fig. 42 Folding the seat cushions forwards and removing

The luggage compartment can be increased in size by folding the seat backrests forward or by removing the rear seats.

Folding forward

- Pull up the seat cushion in the direction of the arrow **1** » Fig. 42 and fold forwards in the direction of the arrow **2**.

Removing

- Fold the seat cushion forward.
- Press the wire clamps in the direction of the arrow » Fig. 42 - **B** and remove the seat cushion from its holder.

Install

- Press the wire clamp in the direction of the arrow » Fig. 42 - **B** and put it into the holder.
- Fold the seat cushion back into its original position.

Inserting head restraints in the seat cushions




Fig. 43
Rear seats: Inserting head restraints in the seat cushions

The rear head restraints can be inserted into the relevant holes of the folded forward seat cushions » Fig. 43.

Boot

Introduction

This chapter contains information on the following subjects:

Class N1 vehicles	54
Fastening elements	54
Folding hooks	54
Fixing nets	55
Boot cover	55
Further positions of the luggage compartment cover	56
Foldable boot cover (Combi)	56

Please observe the following for the purpose of maintaining good handling characteristics of your vehicle:

- Distribute loads as evenly as possible.
- Place heavy objects as far forward as possible.
- Attach the items of luggage to the lashing eyes or using the fixing net » page 54.

In the event of an accident, there is such a high kinetic energy which is produced by small and light objects that they can cause severe injuries. The magnitude of the kinetic energy is dependent on the speed at which the vehicle is travelling and the weight of the object. The speed at which the vehicle is travelling is in this case the more significant factor.

Example: In the event of a frontal collision at a speed of 50 km/h, an unsecured object with a weight of 4.5 kg produces an energy, which corresponds to 20 times its own weight. This means that it results in a weight of approx. 90 kg ". You can imagine the injuries that can occur, if this "object" flies through the interior compartment and hits an occupant.

! WARNING

- Store the objects in the boot and attach them to the lashing eyes.
- Loose objects in the passenger compartment can be thrown forward during a sudden manoeuvre or in case of an accident and can injure the occupants or other oncoming traffic. This risk is still increased, if the objects which are flying around are hit by a deployed airbag. In this case, the objects which are thrown back can injure the occupants - hazard.
- Please note that the handling properties of the vehicle may be affected when transporting heavy objects as the centre of gravity can be displaced - risk of accident! The speed and style of driving must be adjusted accordingly.
- If the items of luggage or objects are attached to the lashing eyes with unsuitable or damaged lashing straps, injuries can occur in the event of braking manoeuvres or accidents. To prevent items of luggage from being thrown forward, always use suitable lashing straps which must be firmly attached to the lashing eyes.
- The items carried in the boot must be stored in such a way that no objects are able to slip forward if any sudden driving or braking manoeuvres are undertaken - risk of injury!
- When transporting fastened objects which are sharp and dangerous in the boot that has been enlarged by folding the rear seats forward, ensure the safety of the passengers transported on the other rear seats » page 105, *Correct seated position for the occupants on the rear seats.*
- If the rear seat next to the folded forward seat is occupied, ensure maximum safety, e.g. by placing the goods to be transported in such a way that the seat is prevented from folding back in case of a rear collision.
- Never drive with the boot lid fully opened or slightly ajar otherwise exhaust gases may get into the interior of the vehicle - risk of poisoning!
- Under no circumstances, should the permissible axle loads and permissible gross weight of the vehicle be exceeded - risk of accident!
- Never transport people in the boot!



! CAUTION

Please ensure that the heating elements for the rear window heater are not damaged as a result of abrasive objects.

i Note

Tyre pressure must be adjusted to the load » [page 151](#), *Service life of tyres*.

Class N1 vehicles

 First read and observe the introductory information and safety warnings  on page 53.

On class N1 vehicles, which are not fitted with a protective grille, a lashing set which complies with the standard EN 12195 (1 - 4) must be used for fastening the load.

Fastening elements








Fig. 44 Boot: Lashing eyes and fastening elements

 First read and observe the introductory information and safety warnings  on page 53.

The boot provides the following fastening elements » [Fig. 44](#).

-  Lashing eyes for fastening items of luggage and fixing nets.
-  Fastening elements for fastening fixing nets.

! CAUTION

The maximum permissible load of the lashing eyes is 3.5 kN (350 kg).

i Note

The upper front lashing eyes are located underneath the folding rear seat backrest » [Fig. 44](#).

Folding hooks



Fig. 45
Boot: folding hooks

 First read and observe the introductory information and safety warnings  on page 53.

Folding hooks for attaching small items of luggage, such as bags etc., are provided on both sides of the boot » [Fig. 45](#).

! CAUTION

The maximum permissible load of the hook is 7.5 kg.

Fixing nets







Fig. 46 Fixing net: double horizontal pocket, floor fixing net/double vertical pockets

 First read and observe the introductory information and safety warnings  on page 53.

Fixing examples for a fixing net as a horizontal pocket, floor fixing net » Fig. 46 -  and a horizontal pocket » Fig. 46 - .

WARNING

Do not exceed the maximum permissible load of the fixing nets. Heavy objects are not secured sufficiently - risk of injury!

CAUTION

- The maximum permissible load of the fixing nets is 1.5 kg.
- Do not place any sharp objects in the nets - risk of damaging the net.

Boot cover






Fig. 47 Removing the boot cover




 First read and observe the introductory information and safety warnings  on page 53.

The boot cover can be removed if you wish to transport bulky goods.

Removing cover

- Unhook the support straps  » Fig. 47.
- Remove the cover from the holders  by lightly knocking on the underside of the cover in the area between the holders.

Installing the cover

- Place the cover on the contact surfaces of the side trim panel.
- The mounts of the cover  » Fig. 47 must be positioned above the holders  of the side trim panel.
- Interlock the cover by lightly knocking on the top side of the cover in the area between the holders.
- Hook the support straps  on the boot lid.

WARNING

No objects should be placed on the boot cover, the vehicle occupants could be endangered if there is sudden braking or the vehicle collides with something. ▶

! CAUTION

- When closing the boot lid, jamming and damage to the luggage compartment cover or the side trim panel can occur if handled in an unprofessional way. The following guidelines must be observed.
 - The mounts of the cover [3] » Fig. 47 must be interlocked in the holders of the side trim panel [2].
 - The items which are transported must not exceed the height of the luggage compartment cover.
 - The cover must not be jammed in the seal of the boot lid when it is in the opened position.
 - There must be no object in the gap between the opened cover and the rear backrest.

i Note

Opening the boot lid also lifts up the boot cover.

Further positions of the luggage compartment cover




Fig. 48 The luggage compartment cover: Stowed in the lower position/behind the rear seats

First read and observe the introductory information and safety warnings ! on page 53.

The luggage compartment cover can be attached to the following positions:

- In the lower position on the support elements » Fig. 48 - A » !;
- behind the rear seats » Fig. 48 - B.

! CAUTION

In this position » Fig. 48 - A the luggage compartment cover is designed to store small objects up to a weight of 2.5 kg.

Foldable boot cover (Combi)




Fig. 49 Boot: foldable boot cover/removing foldable boot cover

First read and observe the introductory information and safety warnings ! on page 53.

Pulling out

- Pull the foldable luggage compartment cover in direction of arrow [1] » Fig. 49 as far as the stop into the secured position.

Folding

- Press the cover in the handle area in the direction of the arrow [2], and the cover automatically rolls up into position.

Removing

- The fully folded luggage compartment cover can be removed to transport bulky goods by pressing on the side of the cross rod in the direction of the arrow [3] and taking it out by moving it in the direction of the arrow [4].

! WARNING

No objects should be placed on the foldable boot cover.

Variable loading floor in the luggage compartment (Combi)

Introductory information

The variable loading floor makes handling of bulky items of luggage easier.

! CAUTION

The maximum permissible load of the variable loading floor is 75 kg.

i Note

The room under the variable loading floor can be used to stow objects.

Dividing the boot with variable loading floor




Fig. 50
Dividing the boot with variable loading floor

- › Lift up the part with the holder and secure it by sliding it into the grooves marked with the arrows » Fig. 50.

Removing and installing the variable loading floor




Fig. 51 Fold up variable loading floor/remove

Removing

- › Unlock the variable loading floor by turning the locking bolts **A** to the left by around 180° » Fig. 51.
- › Fold up the loading floor by moving it in the direction of the arrow **B**.
- › Fold up the variable loading floor in the direction of the arrow **1** » Fig. 51 and remove by pulling in the direction of the arrow **2** » Fig. 51.

Install

- › Fold up the variable loading floor and place it on the carrier rails.
- › Fold out the variable loading floor.
- › Lock the variable loading floor by turning the locking bolt **A** to the right by approx. 180°.

! WARNING

Ensure that the carrier rails and variable loading floor are correctly fastened when installing the variable loading floor. If this is not the case, there is a risk of injury for the occupants.

Removing and installing carrier rails




Fig. 52 Slacken check points/remove carrier rails

Removing

- › Slacken the check points **B** » Fig. 52 on the carrier rails using the vehicle key or a flat screwdriver.
- › Grasp the carrier rail **A** at position **1** and slacken it by pulling in the direction of arrow. You can take out the removable storage compartments in order to facilitate the removal » page 68, *Storage compartments in the boot*.
- › Grasp the carrier rail **A** at position **2** and slacken it by pulling in the direction of arrow.
- › The carrier rail on the other side of the luggage compartment can be removed in the same way.

Install

- › Position the carrier rails on the sides of the boot.
- › Press both check points on each carrier rail **B** » Fig. 52 up to the stop.
- › Check the attachment of the carrier rails by pulling it.

! WARNING

Ensure that the carrier rails and variable loading floor are correctly fastened when installing the variable loading floor. If this is not the case, there is a risk of injury for the occupants.

Net partition (Combi)

Introduction

This chapter contains information on the following subjects:

Using the net partition behind the rear seats	59
Using the net partition behind the front seats	59
Removing and installing net partition housing	60

! WARNING

- The belt locks and the belts must be in their original position after folding back the seat cushions and backrests - they must be ready to use.
- The seat backrests must be securely interlocked in position so that no objects in the luggage compartment can slide into the passenger compartment if there is sudden braking - risk of injury!
- Ensure that the rear seat backrests are properly engaged. It is only then that the three-point seat belt for the middle seat can reliably fulfil its function.
- Ensure that the cross rod is inserted into the mounts **C** » Fig. 53 on page 59 or » Fig. 54 on page 59 in the front position!

Using the net partition behind the rear seats





Fig. 53 Pull out the net partition/roll up

 First read and observe the introductory information and safety warnings  on page 58.

Pulling out

- › Open the rear right door.
- › Fold down the rear seat backrests slightly forwards, which makes it possible to clear the access for removing the net partition.
- › Pull the net partition by the bracket **A** » Fig. 53 out of the housing **B** in direction of the holders **C**.
- › Insert the cross rod into one of the mounts **C** and push forwards.
- › In the same way, insert the cross rod into the mount **C** on the other side of the vehicle.
- › Then push the seat backrest back into the upright position until the securing knob clicks into place - check by pulling on the seat backrest.

Folding

- › First pull the cross rod back slightly on the one side and then on the other side and remove it from the mounts **C** » Fig. 53.
- › **Hold** the cross rod in such a way that the net partition can slowly roll up into the housing **B** without being damaged.

If you wish to use the entire boot, the foldable boot cover can be removed » page 56.

Using the net partition behind the front seats





Fig. 54 Pull out the net partition/roll up

 First read and observe the introductory information and safety warnings  on page 58.

Pulling out

- › Open the rear right door.
- › Fold the seat cushions and rear seat rests forward.
- › Pull the net partition by the bracket **A** » Fig. 54 out of the housing **B** in direction of the holders **C**.
- › Insert the cross rod into one of the mounts **C** and push forwards.
- › In the same way, insert the cross rod into the mount **C** on the other side of the vehicle.

Folding

- › First pull the cross rod back slightly on the one side and then on the other side and remove it from the mounts **C** » Fig. 54.
- › **Hold** the cross rod in such a way that the net partition can slowly roll up into the housing **B** without being damaged.
- › Fold the rear seats back into their original position.

Removing and installing net partition housing




Fig. 55
Rear seats: Net partition housing

First read and observe the introductory information and safety warnings on page 58.

Removing

- Open the rear right door.
- Fold the seat cushions and rear seat backrests forward – first the left and then the right backrest.
- Push the net partition housing **A** » Fig. 55 in the direction of the arrow **1** and remove it from the mount on the right seat rest in the direction of the arrow **2**.

Install

- Insert the recesses on the net partition housing into the mounts on the rear seat backrests.
- Push the net partition housing in the opposite direction of the arrow **1** as far as the stop.
- Fold the rear seats back into their original position.

Bicycle carrier in the luggage compartment

Introduction

This chapter contains information on the following subjects:

Install cross member	60
Install bicycle carrier	61
Put bicycle into the bicycle carrier	61
Secure the stability of the bicycles with a belt	61

WARNING

When transporting bicycles, ensuring the safety of the passengers is paramount.

CAUTION

Be careful when maneuvering the bicycle - risk of damage to the vehicle.

Install cross member




Fig. 56
Install cross member

First read and observe the introductory information and safety warnings on page 60.

- Remove the rollable luggage compartment cover » page 56; if necessary we recommend you remove the net partition » page 60.
- Remove the head rests from the rear seat rests and fold the rear seats forward » page 52.
- Undo the securing screws **C** » Fig. 56 and remove a little to unlock the holders **B**.
- Place the cross member **A** with the fixed part onto the left lashing eye and then place it on the right lashing eye with the removable part of the cross member **A**.
- Press the holders **B** until they latch. Tighten the securing screws **C**.
- Check how well the cross member is fastened by pulling on it.

Install bicycle carrier




Fig. 57
Install bicycle carrier

First read and observe the introductory information and safety warnings on page 60.

- Position the approved bicycle carrier on the cross member.
- Remove the screw » Fig. 57 a little and push the frame side rail (alu-part) towards the cross member until the socket latches.
- Insert the screw into the nut.
- Undo the screw on the movable part of the bicycle carrier and unscrew.
- Place the movable part of the fixture, depending on the size of the vehicle, in one of the possible positions so that the bicycle does not touch the boot lid. We recommend to place the moveable part of the fixture in such a position that 7 holes are visible between the screw and the moveable part.
- Insert the screw into the desired position and tighten.

Put bicycle into the bicycle carrier




Fig. 58 Put in the bicycle/example fastening the front wheel

First read and observe the introductory information and safety warnings on page 60.

- Remove the front wheel of the bicycle before installing it.
- Slacken the quick tension jack on the fixing axle of the bicycle carrier and adjust according to the width of the bicycle fork.
- Fit the bicycle fork onto the fixing axle and tighten with the quick tension jack » Fig. 58 - .
- Position the left pedal of the bicycle forward, in order to attach the front wheel more easily.
- Undo the screw » Fig. 57 on page 61 and push the bicycle carrier to the left together with the fastened bicycle to prevent a collision between the steering wheel and the side window of the luggage compartment.
- Carefully guide the boot lid downwards without letting go of it. Check whether there is sufficient room between the steering bars and the rear window. If necessary, adjust the position of the movable part of the bicycle carrier to prevent a collision » page 61.
- It is best to store the removed front wheel between the crank of the left pedal and the bicycle frame, attach it with a strap to the front fork » Fig. 58 - and/or to one of the fixing points.
- The second carrier is installed and the bicycle is secured in a similar way.

Secure the stability of the bicycles with a belt




Fig. 59 Securing bicycles

First read and observe the introductory information and safety warnings on page 60.

- To slacken the rubber part of the clamp, push both parts against each other and open the clamp.

- Position the clamp with the rubber part to the front (in direction of travel) as far as possible below the saddle support and close the clamp » Fig. 59 - [A].
- When transporting two bicycles, clamp the belt » Fig. 59 - [A] between the saddles by moving the bicycles apart.
- Hang the carabines at the ends of the belt into the lashing eyes behind the rear seats » Fig. 59 - [B].
- Pull the belt through the tensioning clasps on both sides in turn.
- If necessary, you can correct the position of the bicycles in the vehicle.

Roof rack system

Introduction

This chapter contains information on the following subjects:

Attachment points	_____	63
Roof load	_____	63

WARNING

- The items which you transport on the roof bar system must be reliably attached - risk of accident!
- Always secure the load with appropriate and undamaged lashing straps or tensioning straps.
- Distribute the load evenly over the roof rack system.
- The handling properties of your vehicle change when you transport heavy or bulky items on the roof bar system as a result of the displacement of the centre of gravity and the increased wind attack area - risk of accident! The style of driving and speed must therefore be adapted to the current circumstances.
- Avoid abrupt and sudden driving/braking manoeuvres.
- Adjust the speed and driving style to the visibility, weather, road and traffic conditions.
- The permissible roof load, permissible axle loads and gross permissible weight of your vehicle must not be exceeded under any circumstances - risk of accident!

CAUTION

- Only use roof rack systems approved by ŠKODA.
- If other roof rack systems are used or if the roof bars are not fitted correctly, any resulting damage to the vehicle is not covered by the warranty. It is therefore essential that the supplied fitting instructions for the roof rack system are observed.
- On models fitted with a power sliding/tilting roof, ensure that the opened sliding/tilting roof does not strike any items of luggage transported on the roof.
- Ensure that the boot lid does not hit the roof load when opened.
- The height of the vehicle changes after mounting a roof luggage rack system and the load that is secured to it. Compare the vehicle height with available clearances, such as underpasses and garage doors.
- Always remove the roof luggage rack system before entering an automated car wash.
- Ensure the roof aerial is not impaired by the secured load.

For the sake of the environment

The increased aerodynamic drag results in a higher fuel consumption.

Note

If the vehicle is not factory-equipped with a roof rack, it can be purchased from the ŠKODA Original Accessories.

Attachment points






Fig. 60
Attachment points for roof bars


 First read and observe the introductory information and safety warnings  on page 62.

Perform the assembly and disassembly according to the enclosed instructions.

CAUTION

Observe the information regarding the assembly and disassembly in the enclosed instructions. ■

Roof load

 First read and observe the introductory information and safety warnings  on page 62.

The maximum permissible roof load (including roof rack system) of **75 kg** and the maximum permissible total weight of the vehicle should not be exceeded.

The full permissible roof load cannot be used if a roof rack system with a lower load carrying capacity is used. In this case, the roof rack system must only be loaded up to the maximum weight limit specified in the fitting instructions. ■

Cup holders





Fig. 61 Cup holder

Two beverage containers can be placed into the recesses  » Fig. 61.

One beverage container can be placed into the recess .

WARNING

- Never put hot beverage containers in the cup holder. If the vehicle moves, they may spill - risk of scalding!
- Do not use any cups or beakers which are made of brittle material (e.g. glass, porcelain). This could lead to injuries in the event of an accident.

CAUTION

Do not leave open beverage containers in the cup holder during the journey. There is a risk of spilling e.g. when braking which may cause damage to the electrical components or seat upholstery. ■

Ashtray



Fig. 62 Centre console: Ashtray at the front/rear

Removing

- Pull out the ashtray » Fig. 62 upwards.

Install

- Insert the ashtray vertically.

! WARNING

Never place flammable objects in the ashtray - risk of fire!

! CAUTION

When removing do not hold the ashtray at the cover - risk of breakage.

Cigarette lighter, 12-volt power socket

Cigarette lighter



Fig. 63
Centre console: Cigarette lighter

Operating the cigarette lighter

- Press in the button of the cigarette lighter » Fig. 63.
- Wait until the button pops forward.
- Remove the cigarette lighter immediately and use.
- Place the cigarette lighter back into the socket.

! WARNING

- Take care when using the cigarette lighter! Improper use of the cigarette lighter can cause burns.
- The cigarette lighter also operates when the ignition is switched off or the ignition key withdrawn. Therefore never leave children unattended in the vehicle.

i Note

- The cigarette lighter socket can also be used as a 12Volt socket for electrical appliances » page 65.
- Further information » page 157, *Accessories, changes and replacement of parts.*

12-volt power socket



Fig. 64
Boot: Power socket

Overview of the 12-volt power socket

In the front centre console » Fig. 63 on page 64.

In the boot » Fig. 64.

Using the power socket

- Remove the cover from power socket or cigarette lighter, or open the cover for the power socket.
- Connect the plug for the electrical appliance to the socket.

Further information » page 157, *Accessories, changes and replacement of parts.*

! WARNING

- Improper use of the 12-volt power socket and the electrical accessories can cause fires, burns and other serious injuries.
- Never leave children unattended in the vehicle. The 12-volt power socket and any connected appliances can also be operated when the ignition is switched off or the ignition key is withdrawn.
- If the connected electric device becomes too hot, switch it off and disconnect it from the power supply immediately.

! CAUTION

- The 12-volt power socket can only be used for connecting approved electrical accessories with a total power uptake of up to 120 watt.
- Never exceed the maximum power consumption, otherwise the vehicle's electrical system can be damaged.
- Connecting electrical components when the engine is not running will drain the battery of the vehicle - risk of battery draining!

- Only use matching plugs to avoid damaging the 12-volt power socket.
- Only use accessories that have been tested for electromagnetic compatibility in accordance with the applicable directives.
- Before turning the ignition on or off, and before starting the car, switch off the device connected to the 12-volt power socket to prevent any damage caused by voltage fluctuations.
- Observe the operating instructions for the connected devices!

Storage compartments

Overview

The vehicle has the following storage compartments:

Storage compartments on the front passenger side	» page 66
Storage compartment on the driver's side	» page 66
Map pockets in the front seats	» page 66
Glasses storage box	» page 67
Storage compartment in centre console	» page 67
Storage compartment in the front seat	» page 67
Front armrest with storage compartment	» page 68
Storage compartments in the doors	» page 68
Storage compartments in the boot	» page 68
Flexible storage compartment	» page 69

! WARNING

- Do not place anything on the dash panel. These objects might slide or fall down when driving (when accelerating or cornering) and may distract you from concentrating on the traffic - risk of accident!
- When driving, ensure that no objects from the centre console or from other storage compartments can get into the driver's footwell. You would then no longer be able to apply the brakes, operate the clutch or accelerator - risk of accident!

Storage compartments on the front passenger side




Fig. 65
Dash panel: Storage compartments on the front passenger side

Open/close

- Pull the handle of the flap in the direction of the arrow » Fig. 65 and fold down the flap.
- Lift the lid upwards until it clicks into place.

A pin holder is located inside the lower flap.

! WARNING

The storage compartments must always be closed when driving for safety reasons.

Cooling the storage compartment on the front passenger side




Fig. 66
Storage compartment: Using cooling system

- Use the rotary switch » Fig. 66 to open/close the air supply.

Opening the air supply when the air conditioning system is switched on allows cooled air to flow into the storage compartment.

Opening the air inlet when the air conditioning system is on causes fresh or interior air to flow into the storage compartment.

We recommend closing the air supply if it is operated in heating mode or the cooling system for the storage compartment is not being used.

Storage compartment on the driver's side



Fig. 67
Dash panel: Storage compartment on the driver's side

The storage compartment below the light switch » Fig. 67.

Map pockets in the front seats



Fig. 68
Front seat rests: Map pockets

Map pockets are located on the rear of the seat backrests » Fig. 68.

The map pockets are intended for storage of maps, magazines, etc.

! WARNING

Never put heavy items in the map pockets - risk of injury!

! CAUTION

Do not put any large items such as bottles or sharp objects into the map pockets, as the pockets and the seat covers could be damaged.

Glasses storage box




Fig. 69
Detail of the headliner: Glasses storage box

➤ Press on the cover of the glasses storage box in the area of the bar. The compartment folds down » Fig. 69.

! WARNING

The compartment must only be opened when removing or inserting the spectacles and otherwise must be kept closed.

! CAUTION

- Do not put any heat-sensitive objects in the glasses storage box - they may be damaged.
- The maximum permissible load of the glasses compartment is 250 g.

Stowage compartment in centre console



Fig. 70
Centre console: Stowage compartment

The open stowage compartment in the centre console » Fig. 70.

Stowage compartment underneath the front passenger seat




Fig. 71
Front seat: Stowage compartment

- To open the lid, pull the handle » Fig. 71.
- When closing the lid, hold the handle until the compartment is closed.

! WARNING

The storage compartment must always be closed when driving for safety reasons.

! CAUTION

The storage compartment is designed for storing small objects of up to 1 kg. in weight.

Front armrest with storage compartment




Fig. 72 Armrest: Storage compartment/open storage compartment

Fold the armrest forwards

- Press the bottom button on the face end of the armrest » Fig. 72 - [A].
- Fold the arm rest forward and release the button again.

Opening the storage compartment

- Press the top button and fold the cover of the storage compartment upwards » Fig. 72 - [B].

i Note

The moving space of the arms can be restricted if the armrest is folded forwards. In city traffic the armrest should not be folded forwards.

Storage compartments in the doors




Fig. 73 Storage compartment: in the front door/in the rear door

A bottle holder is located in the area [B] » Fig. 73 of the storage compartment for the front doors.

! WARNING

Use the area [A] » Fig. 73 of the storage compartment only for storing objects which do not project so that the effectiveness of the side airbag is not impaired.

Storage compartments in the boot




Fig. 74
Boot: Storage compartments

The cover for the side compartment can be removed, thus enlarging the boot.

- Grasp the top part of the cover and carefully remove it in the direction of the arrow » Fig. 74.

! CAUTION

The storage compartments are designed for storing small objects of up to 2.5 kg. in weight in total.

Flexible storage compartment




Fig. 75
Flexible storage compartment

The flexible storage compartment » Fig. 75 can be built into the right-hand side of the luggage compartment.

Install

➤ Insert both ends of the flexible storage compartment into the openings of the right side trim panel of the boot and push it downwards until it locks.

Removing

- Grasp the flexible storage compartment on the two upper corners.
- Press the upper corners inwards and release the storage compartment by pulling upwards.
- Remove by pulling towards you.

! CAUTION

The storage compartment is designed for storing small objects with a maximum total weight of 8 kg.

i Note

If the variable loading floor » page 57 is installed in the luggage compartment, no flexible storage compartment can be installed.

Clothes hooks

The clothes hooks are located on the handle of the headliner above each of the rear doors.

! WARNING

- Ensure that any clothes hanging from the hooks do not impair your vision to the rear.
- Only use the hooks for hanging light items of clothing and ensure that there are no heavy or sharp-edged objects in the pockets.
- Do not use clothes hangers for hanging up items of clothing otherwise this may reduce the effectiveness of head airbags.

! CAUTION

The maximum permissible load of the hooks is 2 kg.

Parking ticket holder




Fig. 76
Windscreen: Parking ticket holder

The note holder is designed e.g. for attaching car park tickets.

! WARNING

The attached note has to always be **removed** before starting off in order not to restrict the driver's vision.

Heating and air conditioning system

Heating and air conditioning system

Introductory information

The heating effect is dependent upon the coolant temperature, thus full heat output only occurs when the engine has reached its operating temperature.

If the cooling system is switched on, the temperature and air humidity drops in the vehicle. The well-being of the occupants of the car is enhanced as a result of this particularly at high outside temperatures and a high air humidity. The system prevents the windows misting up during the cold season of the year.

It is possible to briefly activate recirculated air mode to enhance the cooling effect.

Please refer to the information regarding recirculated air mode for the air-conditioning system » [page 75](#) or for Climatronic » [page 77](#).

The air inlet in front of the windscreen must be free of ice, snow or leaves to ensure that the heating and cooling system operates properly.

After switching on the cooling **Condensation** from the evaporator of the air conditioning may drip down and form a puddle below the vehicle. This is quite normal and not an indication of a leak!

WARNING

- For your own safety and that of other road users, ensure that all the windows are free of ice, snow and misting. Please familiarize yourself about how to correctly operate the heating and ventilation systems, how to demist and defrost the windows, as well as with the cooling mode.
- Do not leave recirculated air mode on over a longer period of time, as "stale" air can cause fatigue of the driver and passengers, reduce attention levels and also cause the windows to mist up. The risk of having an accident increases. Switch off recirculated air mode as soon as the windows start to mist up.

Note

- The used air streams out through the vents in the boot.
- We recommend that you do not smoke in the vehicle when the recirculating air mode is operating since the smoke which is drawn at the evaporator from the interior of the vehicle forms deposits in the evaporator of the air conditioning system. This produces a permanent odour when the air conditioning system is operating which can only be eliminated through considerable effort and expense (replacement of compressor).
- To ensure that the heating and air conditioning systems work properly, do not block up the air outlet vents with any objects.

Using the air conditioning system economically

The compressor on the air conditioning system uses power from the engine when in cooling mode which will effect the fuel consumption.

It recommended to open the windows or the doors of a vehicle for which the interior has been strongly heated through the effect of direct sunlight in order to allow the heated air to escape.

The cooling system should not be switched on while travelling when the window is open.

If the desired interior temperature can also be achieved without activating the cooling system, fresh air mode should be selected.



For the sake of the environment

Pollutant emissions are also reduced when fuel is saved.

Operational problems

If the cooling system does not operate at outside temperatures higher than +5 °C, there is a problem in the system. The reasons for this may be.

- One of the fuses has blown. Check the fuse and replace if necessary » [page 168](#).
- The cooling system has switched off automatically for a short time because the coolant temperature of the engine is too hot » [page 9](#).

If you cannot rectify the functional fault yourself, or the cooling capacity decreases, the cooling system must be switched off. Seek help from a ŠKODA specialist garage.

Air outlet vents




Fig. 77 Air outlet vents

Open the air outlet vents 3 and 4

➤ Turn the vertical wheel (air vents 3) » Fig. 77 or the horizontal wheel (air outlet nozzles 4) into position 2.

Close air outlet vents 3 and 4

➤ Turn the vertical wheel (air vents 3) » Fig. 77 or the horizontal wheel (air outlet nozzles 4) into position 0.

Change air flow of air outlet vents 3 and 4

- In order to change the strength of the air flow, swivel the horizontal lamellas with the aid of the moveable adjuster » Fig. 77.
- In order to change the lateral direction of the air flow, swivel the vertical lamellas with the aid of the moveable adjuster.

Set the air supply to the individual vents with the air distribution control [C] » Fig. 78 on page 71. Air outlet vents 3 » Fig. 77 and 4 can also be opened or closed individually.

Warmed, unwarmed or cooled air will flow out of the air outlet vents according to the setting of the regulator of the heating or the air conditioning system and the atmospheric conditions.

Heating

Using the system




Fig. 78 Heating: Control elements

Setting temperature

- Turn the control dial [A] » Fig. 78 to the right to increase the temperature.
- Turn the control dial [A] to the left to decrease the temperature.

Controlling blower

- Turn the blower switch [B] » Fig. 78 into one of the positions, 1 to 4, to switch the blower on.
- Turn the blower switch [B] into position 0 to switch the blower off.
- If you wish to shut off the fresh air supply, use the button [1] » page 73, in section *Recirculated air mode*.

Regulating the air distribution

- The direction of the inlet air flow is controlled with air distribution regulator [C] » Fig. 78 » page 71.

All controls apart from the blower switch [B] » Fig. 78 can be set to any desired intermediate position.






The blower should always be on to prevent the windows from misting up. ▶

i Note

If the air distribution is positioned towards the windows, the total amount of air is used to defrost the windows and thus no air will be fed to the footwell. This can lead to restriction of the heating comfort. ■

Set heating

Recommended basic settings of the heating controls for the respective operating modes:

Set-up	Setting of the control dial			Button 1	Air outlet vents 4
	A	B	C		
Defrosting the windshield and side windows	To the right up to the stop	3		Do not switch on	Open and align with the side window
Free windshield and side windows from mist	Desired temperature	2 or 3		Do not switch on	Open and align with the side window
The fastest heating	To the right up to the stop	3		Briefly switch on	Opening
Comfortable heating	Desired temperature	2 or 3		Do not switch on	Opening
Fresh air mode - ventilation	To the left up to the stop	Desired position		Do not switch on	Opening

i Note

- Controls **A** » Fig. 78 on page 71, **B**, **C** and the button **1**.
- Air outlet vents **4** » Fig. 77 on page 71.
- We recommend that you leave the air outlet vents **3** » Fig. 77 on page 71 in the opened position. ■

Recirculated air mode



Recirculated air mode prevents polluted air outside the vehicle from getting into the vehicle, for example when driving through a tunnel or when standing in a traffic jam.

Switching on

- Press the button  **1** » Fig. 78 on page 71 and the warning light in the button illuminates.

Switching off

- Press the button  **1** » Fig. 78 on page 71 again - the warning light in the button goes out.

Recirculated air mode is switched off automatically if the air distribution control **C** » Fig. 78 on page 71 is turned to position . Recirculated air mode can be switched on again from this setting by repeatedly pressing the button . ▶

! WARNING

Do not leave recirculated air mode on over a longer period of time, as "stale" air can cause fatigue of the driver and passengers, reduce attention levels and also cause the windows to mist up. The risk of having an accident increases. Switch off recirculated air mode as soon as the windows start to mist up.

Air conditioning system (manual air conditioning system)

Introductory information

The cooling system only operates if the button **AC** **2** » Fig. 79 on page 73 is pressed, and the following conditions are met:

- › engine running;
- › outside temperature above approx. +2 °C;
- › blower switch switched on (positions 1 to 4).

Under certain circumstances, air at a temperature of about 5 °C can flow out of the vents when the cooling system is switched on. Lengthy and uneven distribution of the air flow out of the vents and large differences in temperature, for example when getting out of the vehicle, can result in chills in sensitive persons.

i Note

We recommend that you have the air conditioning system cleaned by a ŠKODA specialist garage once every year.

Using the system




Fig. 79 The air conditioning system: Control elements

Setting temperature

- › Turn the control dial **A** » Fig. 79 to the right to increase the temperature.
- › Turn the control dial **A** to the left to decrease the temperature.

Controlling blower

- › Turn the blower switch **B** » Fig. 79 into one of the positions, 1 to 4, to switch the blower on.
- › Turn the blower switch **B** into position 0 to switch the blower off.
- › Press the button **1** to close the fresh air supply » Fig. 79.


Regulating the air distribution

- › The direction of the inlet air flow is controlled with air distribution regulator **C** » Fig. 79 » page 71.

Switching the cooling system on and off

- › Press the button **AC** **2** » Fig. 79 and the warning light in the button illuminates.
- › Pressing the button **AC** **2** again switches off the cooling system - the indicator light in the button goes out.

i Note

- The whole heat output will be needed to defrost the windscreen and side windows. No warm air will be fed to the footwell. This can lead to restriction of the heating comfort.
- The warning light  lights after activation, even if not all of the conditions for the function of the cooling system have been met » [page 73](#), *Introductory information*. The operational readiness of the cooling system is signalled when the warning light in the button lights up. ■

Setting the air conditioning system

Recommended basic settings of the control elements of the air conditioning system for the respective operating modes:

Set-up	Setting of the control dial			Button		Air outlet vents 4
	A	B	C	1	2	
Defrost/defog windscreen and side windows ^{a)}	Desired temperature	3 or 4		Do not switch on	Automatically switched on	Open and align with the side window
The fastest heating	To the right up to the stop	3		Briefly switch on	Switched off	Opening
Comfortable heating	Desired temperature	2 or 3		Do not switch on	Switched off	Opening
The fastest cooling	To the left up to the stop	briefly 4, then 2 or 3		Briefly switch on ^{b)}	Activated	Opening
Optimal cooling	Desired temperature	1, 2 or 3		Do not switch on	Activated	Open and align to the roof
Fresh air mode - ventilation	To the left up to the stop	Desired position		Do not switch on	Switched off	Opening

^{a)} We recommend that you do not use this setting in countries with high humidity levels. This can result in heavy cooling of the window glass and the following fogging from outside.

^{b)} Under certain conditions, recirculated air mode » page 75 may come on automatically; the warning light will then light up in the button.

Note

- Controls **A** » Fig. 79 on page 73, **B**, **C** and buttons **1** and **2**.
- Air outlet vents **4** » Fig. 77 on page 71.
- We recommend that you leave the air outlet vents **3** » Fig. 77 on page 71 in the opened position.

Switching off

- Press the button **1** » Fig. 79 on page 73 again - the warning light in the button goes out.

Recirculated air mode is switched off automatically if the air distribution control **C** » Fig. 79 on page 73 is turned to position . Recirculated air mode can be switched on again from this setting by repeatedly pressing the button .

WARNING

Do not leave recirculated air mode on over a longer period of time, as "stale" air can cause fatigue of the driver and passengers, reduce attention levels and also cause the windows to mist up. The risk of having an accident increases. Switch off recirculated air mode as soon as the windows start to mist up.

Recirculated air mode

Recirculated air mode prevents polluted air outside the vehicle from getting into the vehicle, for example when driving through a tunnel or when standing in a traffic jam.

Switching on

- Press the button **1** » Fig. 79 on page 73 and the warning light in the button illuminates.

Climatronic (automatic air conditioning system)

Introductory information

The Climatronic maintains fully automatically a convenience temperature. This is achieved by automatically varying the temperature of the air flow, the blower stages and air distribution. The system also takes sunlight into account, which eliminates the need to alter the settings manually. The **automatic mode** » page 77 ensures maximum well-being of the occupants at all times of the year.

Description of Climatronic system

The cooling system only operates if the following conditions are met:

- › engine running;
- › outside temperature above approx. +2 °C;
- › (AC) 18 » Fig. 80 on page 76 switched on.

The AC compressor is switched off at a high coolant temperature in order to provide cooling at a high load of the engine.

Recommended setting for all periods of the year.

- › Set the desired temperature, we recommend 22 °C.
- › Press the button (AUTO) 12 » Fig. 80 on page 76.
- › Move the air outlet vents 3 » Fig. 77 on page 71 and 4 so that the air flow is directed slightly upwards.

Switching between Celsius and Fahrenheit

Press and hold the buttons (AUTO) and (AC) » Fig. 80 on page 76 at the same time. The information in the desired temperature measuring unit appears in the display.

i Note

We recommend that you have the Climatronic system cleaned by a ŠKODA specialist garage once every year.

Overview of the control elements




Fig. 80 Climatronic: Control elements

The buttons/control dial

- 1 Setting the interior temperature

The displays

- 2 Display of selected interior temperature
- 3 Degrees Celsius or Fahrenheit
- 4 Automatic air conditioning mode
- 5 De-mist or de-ice the windshield
- 6 Direction of air flow
- 7 Recirculated air mode
- 8 Cooling system on/off
- 9 Set blower speed

The buttons/control dial

- 10 Setting the blower speed
- 11 Interior temperature sensor
- 12 Automatic mode
- 13 De-mist or de-ice the windshield
- 14 Air flow to the windows
- 15 Air flow to head
- 16 Air flow in the footwell

- 17 Recirculated air mode
- 18 Switch cooling system on/off

i Note

The interior temperature sensor **11** » Fig. 80 is located in the bottom part of the device. Do not stick anything on or cover the sensor, otherwise it could have an unfavourable effect on the Climatronic.

Automatic mode

The automatic mode is used in order to maintain a constant temperature and to demist the windows in the interior of the car.

Switching automatic mode on

- Set a temperature between +18 °C and +29 °C.
- Move the air outlet vents **3** » Fig. 77 on page 71 and **4** so that the air flow is directed slightly upwards.
- Press the button **(AUTO)** **12** » Fig. 80 on page 76; **AUTO** is shown in the display.

Automatic mode is switched off by pressing one of the buttons for the air distribution or by increasing/decreasing the blower speed. The temperature is nevertheless regulated.

Setting temperature

- The required interior temperature can be set with the control dial **1** » Fig. 80 on page 76 after switching on the ignition.


The interior temperature can be set between +18 °C and +29 °C. The interior temperature is regulated automatically within this range. If you select the temperature below +18 °C, "LO" appears in the display. If you select the temperature higher than +29 °C, "HI" appears in the display. In both limit positions the Climatronic operates at maximum cooling or heating capacity, respectively. The temperature is not controlled in this case.

Lengthy and uneven distribution of the air flow out of the vents (especially around the feet) and large differences in temperature, for example, when getting out of the vehicle, can cause susceptible individuals to catch a cold.


Recirculated air mode

Recirculated air mode prevents polluted air outside the vehicle from getting into the vehicle, for example when driving through a tunnel or when standing in a traffic jam.

Switching on

- Press the button **()** **17** » Fig. 80 on page 76; the symbol  appears in the display.


Switching off

- Press the button **()** **17** » Fig. 80 on page 76 again and the symbol  disappears from the display.

! WARNING

Do not leave recirculated air mode on over a longer period of time, as "stale" air can cause fatigue of the driver and passengers, reduce attention levels and also cause the windows to mist up. The risk of having an accident increases. Switch off recirculated air mode as soon as the windows start to mist up.

i Note

If recirculated air mode is switched on for around 15 minutes, the symbol  will begin to flash in the display as a sign that the recirculated air mode is switched on long-term. If the recirculated air mode is not switched off, the symbol flashes for around 5 minutes.

Controlling blower

The Climatronic system controls the blower stages automatically in line with the interior temperature. However, the blower stages can be manually adapted to suit your particular needs.

- Turn the control dial **10** » Fig. 80 on page 76 to the left (reduce blower speed) or right (increase blower speed).

If the blower is switched off, the Climatronic system is switched off.

! WARNING

- "Stale air" may result in fatigue in the driver and occupants, reduce attention levels and also cause the windows to mist up. The risk of having an accident increases.
- Do not switch off the Climatronic system for longer than necessary.
- Switch on the Climatronic system as soon as the windows mist up.

Defrosting windscreen

Switching on

➤ Press the button  » Fig. 80 on page 76.

Switching off

➤ Once again press the button  » Fig. 80 on page 76 or the button .

The temperature control is controlled automatically. More air flows out of the air outlet vents **1** » Fig. 77 on page 71 and **2**.

Starting-off and Driving

Starting and stopping the engine

Introduction

This chapter contains information on the following subjects:

Adjusting the steering wheel position _____	80
Electrohydraulic power steering _____	80
Electronic immobiliser _____	80
Ignition lock _____	81
Starting engine _____	81
Switching off the engine _____	81

WARNING

- Never adjust the steering wheel when the vehicle is moving only when the vehicle is stationary!
- Maintain a distance of 25 cm **[1]** to the steering wheel » Fig. 81 on page 80 - **[B]**. Not maintaining this minimum distance will mean that the airbag system will not be able to properly protect you - hazard!
- The lever for adjusting the steering wheel must be locked whilst driving so that the position of the steering wheel cannot accidentally change during the journey - risk of accident!
- If the steering wheel is adjusted further towards the head, the protection provided by the driver airbag in the event of an accident is reduced. Check that the steering wheel is aligned to the chest.
- When driving, hold the steering wheel with both hands firmly on the outer edge in the 9 o'clock and 3 o'clock position. Never hold the steering wheel in the 12 o'clock position or in any other way (e.g. in the middle or inner edge of the steering wheel). In such cases, you could injure the arms, hands and head when the driver airbag is deployed.
- When driving, the ignition key must always be in the position **[2]** » Fig. 82 on page 81 (ignition switched on) without the engine running. This position is indicated by the warning lights coming on. If this is not the case, it could result in unexpected locking of the steering wheel - risk of accident!

WARNING (Continued)

- Only pull the ignition key from the ignition lock when the vehicle has come to a complete stop (by applying the handbrake). Otherwise the steering wheel could block - risk of accident!
- When leaving the vehicle, the ignition must always be removed. This is particularly important if children are left in the vehicle. Otherwise the children could, for example, start the engine - risk of accident or injury!
- Never leave the engine running in unventilated or closed rooms. The exhaust gases of the engine contain besides the odorless and colourless carbon monoxide a poisonous gas - hazard! Carbon monoxide can cause unconsciousness and death.
- Never leave the vehicle unattended with the engine running.
- Never switch off the engine before the vehicle is stationary - risk of accident!

CAUTION

- You will place great stresses on the power steering system if the steering is turned to full lock when the vehicle is stationary. Turning the steering to full lock in such a situation will be accompanied by noises. Never leave the steering wheel at full lock for more than 15 seconds when the engine is running - risk of damaging the power steering!
- The starter may only be operated (ignition key position **[3]** » Fig. 82 on page 81), if the engine is not running. The starter or engine can be damaged if the starter is activated when the engine is running.
- Let go of the ignition key as soon as the engine starts otherwise the starter could be damaged.
- Avoid high engine revolutions, full throttle and high engine loads as long as the engine has not yet reached its operating temperature - risk of damaging the engine!
- Do not tow start the engine - danger of damaging the engine! On vehicles with a catalytic converter, unburnt fuel may get into the catalytic converter where it may ignite. This in turn may damage the catalytic converter. The battery from another vehicle can be used as a jump-start aid » page 165, *Jump-starting*.
- Do not switch the engine off immediately at the end of your journey after the engine has been operated over a prolonged period at high loads but leave it to run at an idling speed for about 1 minute. This prevents any possible accumulation of heat when the engine is switched off. ▶



For the sake of the environment

Do not warm up the engine while the vehicle is stationary. If possible, start your journey as soon as the engine has started. Through this the engine reaches its operating temperature more rapidly and the pollutant emissions are lower.

i Note

- The engine can only be started with a genuine ŠKODA key with the matching code.
- The engine running noises may louder at first be louder for a short time after starting the cold engine. This is quite normal and is not an operating problem.
- After switching off the ignition, the radiator fan can intermittently continue to operate for approx. 10 minutes.
- If the engine does not start up after a second attempt, the fuse for the fuel pump may have a fault. Check the fuse and replace, if necessary » [page 168](#), *Fuses* or seek assistance from a ŠKODA specialist garage.
- We recommend **locking the steering wheel** whenever leaving the vehicle. This acts as a deterrent against the attempted theft of your car.

Adjusting the steering wheel position




Fig. 81 Adjustable steering wheel: Lever below the steering column/safe distance to the steering wheel



First read and observe the introductory information and safety warnings **i** on page 79.

The height and forward/back position of the steering wheel can be adjusted.

- First of all adjust the driver's seat » [page 49](#), *Front seats*.
- Pull the lever below the steering wheel down » [Fig. 81 - A](#).

- Adjust the steering wheel to the desired position (with regard to the height and forward/back position).
- Push the lever upwards to the stop.


Electrohydraulic power steering



First read and observe the introductory information and safety warnings **i** on page 79.

The power steering enables you to steer the vehicle with less physical force.

It is still possible to fully steer the vehicle if the power steering fails or if the engine is not running (vehicle being towed in). However, greater physical effort is required to turn the steering wheel.

If there is a fault in the power steering, the warning light then lights up in the instrument cluster  » [page 17](#), *Warning lights*.

Electronic immobiliser



First read and observe the introductory information and safety warnings **i** on page 79.

An electronic chip is integrated in the head of the key. The immobiliser is deactivated with the aid of this chip when the key is inserted in the ignition lock. The electronic immobiliser is automatically activated when the ignition key is withdrawn from the lock.

The engine will not start if a non-authorized ignition key is used.

The following is displayed in the information display:

Immobilizer active.

Ignition lock




Fig. 82
Positions of the vehicle key in
the ignition lock

First read and observe the introductory information and safety warnings on page 79.

Petrol engines

- Ignition switched off, engine off, the steering can be locked
- Ignition switched on
- Starting engine

Diesel engines

- Fuel supply interrupted, ignition switched off, engine switched off, the steering can be locked.
- Heating glow plugs on, ignition switched on
- Starting engine

To **lock the steering**, with the ignition key withdrawn, turn the steering wheel until the steering locking pin engages audibly.

If the **steering is locked** and the key cannot or can only be turned with difficulty into the position » Fig. 82, move the steering wheel back and forth and the steering lock will unlock.

Starting engine

First read and observe the introductory information and safety warnings on page 79.

Vehicles with a **diesel engine** are equipped with a glow plug system. The pre-glow warning light comes on after the ignition has been switched on. The engine should be started immediately after the preglow warning light goes out.

You should not switch on any major electrical components during the heating period otherwise the vehicle battery will be drained unnecessarily.

Procedure for starting the engine

- Before starting the engine, place the gearshift lever into neutral or place the selector lever in the position **P** or **N** and firmly put on the handbrake.
- Fully depress and hold the clutch pedal, switch on the ignition » Fig. 82 on page 81 and start - do not operate the accelerator. Depress the clutch pedal until the engine starts.
- Let go of the key as soon as the engine starts. After letting go, the vehicle key will return to position .
- If the engine does not start within 10 seconds, abort the start-up process and turn the key to position . Repeat the start-up process after approx. half a minute.
- Release the handbrake before starting off.

Switching off the engine

First read and observe the introductory information and safety warnings on page 79.

Switch off the engine by turning the ignition key into position » Fig. 82 on page 81.

Brakes and brake assist systems

Introduction

This chapter contains information on the following subjects:

Information for braking	82
Handbrake	83
Stabilisation control (ESC)	83
Antilock brake system (ABS)	84
Traction control system (TCS)	84
Electronic Differential Lock (EDS and XDS)	84▶


! WARNING

- The brake booster only operates when the engine is running. Greater physical effort for braking is required when the engine is switched off - risk of accident!
- Depress the clutch pedal when stopping or braking a vehicle with a petrol engine and manual transmission in the low rev range. If you fail to do so, the functionality of the brake booster can be impaired - risk of accident!
- If a front spoiler, full wheel trim, etc. is mounted retrospectively, it must be ensured that the air supply to the front wheel brakes is not reduced. Otherwise, the functionality of the brake system could be impaired - risk of accident!
- Please note that the handbrake must be fully released. A handbrake which is only partially released can result in the rear brakes overheating, which can have a negative effect on the operation of the brake system - risk of accident!
- Never leave children unattended in the vehicle. The children might, for example, release the handbrake or take the vehicle out of gear. The vehicle might then move off - risk of accident!
- A lack of fuel can cause irregular engine running or cause the engine to shut down. The brake assist systems would then be without function - risk of accident!
- Adjust the speed and driving style to the current visibility, weather, road and traffic conditions. The increased safety offered by the brake assist systems must not tempt you to take greater risks than otherwise - risk of an accident!
- The normal braking system is still fully functional if there is an ABS fault. Visit a ŠKODA specialist garage immediately and adjust your style of driving according to the damage to the ABS as you will not know how great the damage is and the limitation it is placing on the braking efficiency.

! CAUTION


- Observe the recommendations on the new brake pads » [page 121](#).
- Never let the brakes slip with light pressure on the pedal if braking is not necessary. This causes the brakes to overheat and can also result in a longer braking distance and excessive wear.
- All four wheels must be fitted with the same tyres approved by the manufacturer to ensure the brake assist systems operate correctly.

i Note

- If the brakes are applied in full and the control unit for the braking system considers the situation to be dangerous for the following traffic, the brake light flashes automatically. After the speed was reduced below around 10 km/h or the vehicle was stopped, the brake light stops flashing and the hazard warning light system switches on. The hazard warning light system is switched off automatically after accelerating or driving off again.
- Before negotiating a steep downhill section, reduce the speed, shift down into the next lower gear (manual gearbox) or select a lower drive position (automatic gearbox). As a result, the braking effect of the engine will be used, reducing the load on the brakes. Any additional braking should be completed intermittently, not continuously.
- Changes to the vehicle (e.g. to the engine, brakes, chassis or another combination of tyres and wheels) can influence the functionality of the brake assist systems » [page 157](#), *Accessories, changes and replacement of parts*.
- If a fault occurs in the ABS system, the ESC, ASR and EDL and XDS also do not work. A warning light  » [page 21](#) comes on if a fault occurs in the ABS system.

Information for braking



First read and observe the introductory information and safety warnings  on [page 81](#).

Wear-and-tear

The wear of the brake pads is dependent on the operating conditions and driving style. The brake pads wear more quickly if a lot of journeys are completed in towns and over short distances or if a very sporty style of driving is adopted. If operated under **severe conditions**, the thickness of the brake pads must be checked by a ŠKODA specialist garage before the next service appointment.

Wet roads or road salt

The performance of the brakes can be delayed as the brake discs and brake pads may be moist or have a coating of ice or layer of salt on them in winter. The brakes are cleaned and dried by applying the brakes several times.


Corrosion

Corrosion on the brake discs and dirt on the brake pads occur if the vehicle has been parked for a long period and if you do not make much use of the braking system. If the brake system is not used much or if there is corrosion on the surface, we recommend cleaning the brake discs by firmly applying the brakes from a fairly high speed. ▶

Faults in the brake surface

If it is found that the braking distance has suddenly become longer and that the brake pedal can be depressed further, the brake system may be faulty. Visit a SKODA specialist garage immediately and adjust your style of driving appropriately as you will not know how great the damage is.

Low brake fluid level

An insufficient level of brake fluid may result in problems in the brake system. The level of the brake fluid is monitored electronically » [page 18, Brake system](#) .

Brake booster

The brake booster increases the pressure generated with the brake pedal. The brake booster only operates when the engine is running.

Handbrake




Fig. 83
Centre console: Handbrake




First read and observe the introductory information and safety warnings  on page 81.

Apply

» Pull the handbrake lever firmly upwards.

Loosening

- » Pull the handbrake lever up slightly and **at the same time** push in the locking button » [Fig. 83](#).
- » Move the lever right down while pressing the lock button.

The handbrake warning light  lights up when the handbrake is applied, provided the ignition is on.


Stabilisation control (ESC)




First read and observe the introductory information and safety warnings  on page 81.

The ESC is automatically activated after starting the engine. The ESC helps to maintain control of the vehicle in situations where it is being operated at its dynamic limits, such as a sudden change to the direction of travel. The risk of skidding is reduced and your car thus offers greater driving stability depending on the conditions of the road surface.



The direction which the driver wishes to take is determined based on the steering angle and the speed of the vehicle and is constantly compared with the actual behaviour of the vehicle. In the event of deviations, such as if the car starts to skid, the ESC automatically brakes the appropriate wheel.

During an intervention of the system, the warning light  flashes in the instrument cluster.

In the event of an ESC fault, the ESC warning light illuminates in the instrument cluster  » [page 20](#).

The following systems are integrated into the **electronic stabilisation control (ESC)**:

- » Antilock brake system (ABS),
- » Traction control (TCS),
- » Electronic Differential Lock (EDL and XDS);
- » Brake assist,
- » Uphill start assist.

It is not possible to deactivate ESC. You can only use the button  » [Fig. 84](#) on page 84 to switch off ASR. The TCS warning light  lights up in the instrument cluster when the TCS is switched off.

Hydraulic brake assist

The brake assist system is activated by the very quick operation of the brake pedal (e.g. in the event of danger). It increases the braking effect and helps to shorten the braking distance. To achieve the shortest possible braking distance, the brake pedal must be applied firmly and held in this position until the vehicle has come to a complete standstill.

The ABS is activated faster and more effectively with the intervention of the brake assist system.

The brake assist function is automatically switched off when the brake pedal is released.

Uphill start assist

The uphill start assist makes it easier to start off on steep hills. The system holds the brake pressure produced by the activation of the brake pedal for approx. 2 seconds after the brake pedal is released. The driver can therefore move his foot from the brake pedal to the accelerator pedal and start off on the slope, without having to actuate the handbrake. The brake pressure drops gradually the more you operate the accelerator pedal. If the vehicle does not start off within 2 seconds, it starts to roll back.

The uphill start assist is active as of a 5 % slope, if the driver door is closed. It is always active on slopes when in forward or reverse start off. When driving downhill, it is inactive.

Antilock brake system (ABS)



First read and observe the introductory information and safety warnings  on page 81.

ABS prevents the wheels locking when braking. Thus helping the driver to maintain control of the vehicle.

The intervention of the ABS is noticeable from the **pulsating movements of the brake pedal** which is accompanied by noises.


Do not reduce the pressure on the brake pedal during the intervention of the ABS. The ABS deactivates if the brake pedal is released. Never interrupt the application of the brakes during the intervention of the ABS!

Traction control system (TCS)



Fig. 84
TCS button




First read and observe the introductory information and safety warnings  on page 81.

The TCS is automatically activated after starting the engine. If the wheels are slipping, the TCS adapts the engine speed to the conditions of the road surface. The TCS makes it much easier to start off, accelerate and climb steep hills even if the conditions of the road surface are unfavourable.



The TCS should normally always be switched on. It may be advisable to switch off the system in certain exceptional circumstances, such as:

- when driving with snow chains;
- when driving in deep snow or on a very loose surface;
- when it is necessary to "rock a vehicle free" when it has got stuck.

Ensure the TCS is switched on again afterwards.

During an intervention of the system, the TCS warning light  flashes in the instrument cluster.

The TCS warning light  [» page 23](#) lights up in the instrument cluster when there is a fault on the TCS.

You can switch the TCS off and on again as you wish by pressing the button  [» Fig. 84](#). The TCS warning light  lights up in the instrument cluster when the TCS is switched off.

Electronic Differential Lock (EDS and XDS)



First read and observe the introductory information and safety warnings  on page 81.

If one of the wheels starts to spin, the EDL system brakes the spinning wheel and transfers the driving force to the other wheels. This ensures the stability of the vehicle and a quick journey.

The EDL switches off automatically if unusually severe stresses exist in order to avoid excessive heat generation in the disc brake on the wheel which is being braked. The vehicle can continue to be driven and has the same characteristics as a vehicle not fitted with EDL. The EDL switches on again automatically as soon as the brake has cooled down.

XDL function (Fabia RS and Fabia Estate RS only)

XDL is an extension to the electronic differential lock. XDL does not respond to traction, but to the relief of the inner front wheel during fast cornering. The active brake intervention on the brake of the inner wheel prevents it from spinning. Thus, the traction is improved and the vehicle continues to follow the desired track.

Shifting (manual gearbox)




Fig. 85
Shift pattern of the 5-speed manual gearbox

Always depress the clutch pedal fully when changing gear, to prevent excessive wear of the clutch.

The gearshift indicator must be observed when changing gear » [page 11, Recommended gear](#).

Only engage reverse gear when the vehicle is stationary. Depress the clutch pedal and hold it fully depressed. Wait a moment before reverse gear is engaged to avoid any shift noises.

The reversing light will come on once reverse gear is engaged, provided the ignition is on.

! WARNING

Never engage reverse gear when driving - risk of accident!

i Note

If not in the process of changing gear, do not leave your hand on the gearshift lever while driving. The pressure from the hand can cause the gearshift mechanism to wear excessively.

pedals

The operation of the pedals must not be hindered under any circumstances!

In the driver's footwell, only a footmat, which is attached to the two corresponding attachment points, may be used.

Only use footmats from the range of ŠKODA Original Accessories, which are fitted to two attachment points.

! WARNING

No objects are allowed in the driver's footwell - risk of obstruction or limitation in operating the pedal!

Parking aid




Fig. 86
Parking aid: Range of sensors

The parking aid determines the distance between the rear bumper and an obstacle with the aid of ultrasound sensors. The sensors are integrated in the rear bumper.

Range of sensors

The clearance warning begins at a distance of about 160 cm from the obstacle (area **A** » Fig. 86). The interval between the warning signals becomes shorter as the clearance is reduced.

A continuous tone sounds from a distance of approx. 30 cm (area **B**) - danger area. **You should not reverse any further after this signal sounds!**

On vehicles with a factory-fitted radio or navigation system, the distance to the obstacle is simultaneously graphically illustrated on the display, refer to the operating instructions for the radio or navigation system.

On vehicles with a factory-fitted towing device, the border of the danger area starts (continuous tone) 5 cm further away from the vehicle. The length of the vehicle can be increased with an installed detachable towing device.

On vehicles with a factory-fitted towing device, the rear sensors are deactivated when towing a trailer.

Activating/deactivating the parking aid

The parking aid is activated automatically when **reverse gear** is engaged and the ignition is turned on. This is confirmed by a brief audible signal.

The parking aid is deactivated by removing the reverse gear.

WARNING

- The parking aid is not a substitute for the driver paying proper attention and it is always the driver's responsibility to take care when reversing the vehicle or carrying out similar manoeuvres. Pay particular attention to small children and animals as they are not recognised by the parking aid sensors.
- Before reversing or parking, check that there is no small obstacle, such as a rock, thin post, trailer drawbar etc., in front of or behind the vehicle. Such obstacles may not be recognised by the parking aid sensors.
- Under certain circumstances, surfaces of certain objects and types of clothing cannot reflect the signals from the parking aid. Thus, these objects or people who wear such clothing are not recognised by the parking aid sensors.
- External sound sources can have a detrimental effect on the parking aid. Under unfavourable conditions, objects or people may not be recognised.

Note

- If a warning signal sounds for about 3 seconds after activating the system and there is no obstacle close to your car, this indicates a system fault. Have the fault rectified by a ŠKODA specialist garage.
- The sensors must be kept clean (free of ice, etc.) to enable the parking aid to operate properly.
- If the parking aid is activated and the selector lever of the automatic gearbox is in the position **P**, the warning signal is interrupted (the vehicle cannot move).


Cruise control system (CCS)

Introduction

This chapter contains information on the following subjects:

Storing a speed	87
Changing a stored speed	87
Switching off the cruise control system temporarily	87
Switching off the cruise control system completely	87

The cruise control system (CCS) maintains a constant speed, more than 30 km/h, once it has been set, without you having to depress the accelerator pedal. This is only possible within the range which is permitted by the power output and braking power of the engine.

The warning light  illuminates in the instrument cluster when the cruise control system is activated.

WARNING

- For safety reasons, the cruise control system must not be used in dense traffic or on unfavourable road surfaces (such as icy roads, slippery roads, loose gravel) - risk of accident!
- The saved speed may only be resumed if it is not too high for the current traffic conditions.
- Always switch off the cruise control system after use to prevent unintentional use of the system.

CAUTION

- Always depress the clutch pedal if switching to the neutral position (vehicle with a manual gearbox) when the cruise control system is switched on! Otherwise the engine can rev up unintentionally.
- The cruise control system is not able to maintain a constant speed when driving in areas with steeper gradients. The weight of the vehicle increases the speed at which it travels. Therefore, shift to a lower gear in good time or slow the vehicle down by applying the foot brake. ▶

i Note

It is not possible on vehicles fitted with an automatic gearbox to switch on the cruise control system if the selector lever is in the position **P**, **N** or **R**.

Storing a speed




Fig. 87
Turn signal and main beam lever:
Rocker switch and switch of the
cruise control system

First read and observe the introductory information and safety warnings **i** on page 86.

Storing a speed

- Turn the switch **A** » Fig. 87 into the **ON** position.
- After the desired speed has been reached, press the rocker button **B** into the **SET** position.

After you have released the rocker button **B** out of the position **SET**, the speed you have just stored is maintained at a constant speed without having to depress the accelerator.

Changing a stored speed

First read and observe the introductory information and safety warnings **i** on page 86.

Increasing the speed with the accelerator

- Depress the accelerator to increase the speed.
- Release the accelerator to reduce the speed back down to the preset speed.

However, if the saved speed is exceeded by more than 10 km/h for a period of more than 5 minutes by depressing the accelerator, the stored speed is deleted from the memory. The speed must then be saved again.

Increasing the speed with the rocker button **B**

- Press the rocker button **B** » Fig. 87 on page 87 into the **RES** position.
- The speed will increase continuously, if the rocker button is pressed and held in the **RES** position. Release the rocker button once the desired speed is reached. The set speed is then stored in the memory.

Decreasing the speed

- The stored speed can be **reduced** by pressing the rocker button **B** » Fig. 87 on page 87 into the position **SET**.
- The speed will decrease continuously, if the rocker button is pressed and held in the **SET** position. Release the rocker button once the desired speed is reached. The set speed is then stored in the memory.
- If the rocker button is released at a speed of less than 30 km/h, the speed is not stored and the memory is erased. The speed must then be stored again by pressing the rocker button **B** in the position **SET** after increasing the speed of the vehicle to more than 30 km/h.

The speed can also be reduced by depressing the brake pedal, which temporarily deactivates the system.

Switching off the cruise control system temporarily

First read and observe the introductory information and safety warnings **i** on page 86.

The cruise control system is **temporarily switched off** by pressing the switch **A** » Fig. 87 on page 87 into the spring-tensioned position **CANCEL** or by depressing the brake or clutch pedal.

The set speed remains stored in the memory.

Briefly press the rocker button **B** into the position **RES** to **resume** the stored speed after the clutch or brake pedal is released.

Switching off the cruise control system completely

First read and observe the introductory information and safety warnings **i** on page 86.

- Turn the switch **A** » Fig. 87 on page 87 into the **OFF** position.

START/STOP



Fig. 88
Centre console: Button for the
START-STOP system

The START-STOP system helps you to save fuel while at the same time reducing harmful exhaust emissions and CO₂ emissions.

The function is automatically activated each time the ignition is switched on.

In the start-stop mode, the engine automatically switches to the vehicle's idle phase, e.g. when stopped at traffic lights.

Information regarding the current state of the START-STOP system is indicated in the display of the instrument cluster.

Automatic engine shut down (stop phase)

- Stop the vehicle (where necessary, apply the handbrake).
- Take the vehicle out of gear.
- Release the clutch pedal.

Automatic renewed engine restart (start phase).

- Depress the clutch pedal.

Switching the START-STOP system on and off

The START/STOP system can be switched on/off by pressing the button



When start-stop mode is deactivated, the warning light in the button lights up.

If the vehicle is in the stop phase when manually switching off the system, the engine starts immediately.

The START-STOP system is very complex. Some of the procedures are hard to check without servicing. The general conditions for the proper functioning of the START-STOP system are listed in the following overview.

Conditions for the automatic engine shut down (stop phase)

- The gearshift lever is in Neutral.
- The clutch pedal is not depressed.
- The driver has fastened the seat belt.
- The driver's door is closed.
- The bonnet is closed.
- The vehicle is at a standstill.
- The factory-fitted towing device is not electrically connected to a trailer.
- The engine is at operating temperature.
- The charge state of the vehicle battery is sufficient.
- The stationary vehicle is not on a steep slope or a steep downhill section.
- The engine speed is less than 1 200 rpm.
- The temperature of the vehicle battery is not too low or too high.
- There is sufficient pressure in the braking system.
- The difference between the outdoor- and the set temperature in the interior is not too great.
- The vehicle speed since the last time the engine was switched off was greater than 3 km/h.
- No cleaning of the diesel particle filter takes place » page 22.
- The front wheels are not turned excessively (the steering angle is less than 3/4 of a steering wheel revolution).

Conditions for an automatic restart (start phase)

- The clutch is depressed.
- The max./min. temperature is set.
- The defrost function for the windscreen is switched on.
- A high blower stage has been selected.
- The START STOP button is pressed.

Conditions for an automatic restart without driver intervention

- The vehicle moves at a speed of more than 3 km/h.
- The difference between the outdoor- and the set temperature in the interior is too great.
- The charge state of the vehicle battery is not sufficient.
- There is insufficient pressure in the braking system.

If the driver's seat belt is removed for more than 30 seconds or the driver's door is opened during stop mode, the engine must be started manually with the key. The following messages in the instrument cluster display must be observed. ▶

Messages in the instrument cluster display (valid for vehicles without Information display)

ERROR START STOP	Error in the START-STOP system
START STOP NOT POSSIBLE	Automatic engine shut down is not possible.
START STOP ACTIVE	Automatic engine shut down (stop phase)
SWITCH OFF IGNITION	Switch off the ignition.
START MANUALLY	Start the engine manually.

WARNING

- The brake servo unit and power steering only operate if the engine is running.
- Never let the vehicle roll with the engine switched off.

CAUTION

Deactivate the START-STOP system before driving through water on the street » [page 126](#).

Note

- Changes to the outdoor temperature can have an effect on the internal temperature of the vehicle battery even after several hours. If the vehicle remains outdoors for a long time in minus temperatures or in direct sunlight, it can take several hours until the internal temperature of the vehicle battery reaches a suitable temperature for proper operation of the START STOP system.
- If the Climatronic is running in automatic mode, under certain conditions, the engine may not switch off automatically. ■

Automatic gearbox

Automatic gearbox

Introduction

This chapter contains information on the following subjects:

Introductory information	90
Starting-off and driving	91
Selector lever positions	91
Manual shifting of gears (Tiptronic)	92
Selector lever lock	93
Kickdown function	93
Dynamic shift programme	93
Emergency programme	94
Selector lever-emergency unlocking	94



WARNING

- Do not depress the accelerator if changing the position of the selector lever when the vehicle is stationary and the engine is running - risk of accident!
- Never move the selector lever into position **R** or **P** when driving - risk of an accident!
- When the engine is running and the vehicle is stationary, it is necessary to hold the car with the brake pedal in all the positions of the selector lever (except **P** and **N**) since the power transmission is never completely interrupted, also not when the engine is idling - the vehicle creeps.
- The selector lever must be placed into position **P** and the handbrake firmly applied before the bonnet can be opened and work on the running engine can be completed - risk of accident! The safety guidelines must always be observed » [page 138](#), *Engine compartment*.



WARNING (Continued)

- If stopping on a hill (downhill gradient), never try to maintain the vehicle stationary with the gear engaged by means of the "accelerator pedal", i.e. by letting the clutch slip. This can lead to overheating of the clutch. If there is a risk of overheating of the clutch due to overload, the clutch is opened automatically and the vehicle rolls backward - risk of accident!
- If you have to stop on a slope, depress and hold the brake pedal to prevent the vehicle from rolling back.
- On a smooth or slippery road surface using the kickdown function can cause the driven wheels to spin - risk of skidding!

CAUTION

- The double clutch on the automatic gearbox DSG is equipped with an overload protection. If the uphill function is used when the vehicle is stationary or driving slowly uphill, the thermal stress on the clutches is increased.
- If the clutch system overheats, the symbol  is shown in the information display along with the message **Gearbox overheated. Stop! Owner's man.!** appears. An audible signal sounds as a warning signal. Stop the vehicle, switch off the engine, and wait until the symbol  disappears - risk of gearbox damage! You can continue your journey as soon as the symbol disappears.

Introductory information

 **First read and observe the introductory information and safety warnings  on page 90.**

Shifting up and down through the gears is performed automatically. The gearbox can also be switched to **Tiptronic** mode. This mode makes it possible for you to also shift gears manually » [page 92](#).

The engine can only be **started** when the selector lever is in position **P** or **N**. If the selector lever is not in the **P** or **N** positions when locking the steering, switching the ignition on or off or when leaving the engine on, the following message will appear in the Information display **Move selector lever to position P/N!** or, in the instrument cluster display: → **P/N**.

At temperatures below -10 °C the engine can only be started in the selector lever position **P**¹⁾.

¹⁾ Applies to DSG.

When parking on a level road surface, it suffices to engage selector lever position **P**. When parking on a slope, the handbrake should be applied firmly before the park position is selected. This ensures that there is no excessive pressure on the lock mechanism and that it is subsequently easier to move the selector lever out of position **P**.

If the selector lever position **N** is accidentally selected while driving, it is first necessary to release pressure on the accelerator pedal and wait for the idling speed of the engine to be reached before the selector lever can be engaged in the drive position.

Starting-off and driving

 First read and observe the introductory information and safety warnings  on page 90.

Starting off

- Firmly depress and hold the brake pedal.
- Press the Shiftlock button (button in the selector lever handle), move the selector lever into the desired position » page 91 and then release the Shiftlock button.
- Wait a moment until the gearbox has shifted (a slight engagement nudge can be felt)¹⁾.
- Release the brake pedal and accelerate.

Stop

- The selector lever position **N** does not have to be selected when stopping for a short time, such as at a cross roads. It is sufficient to hold the vehicle stationary using the foot brake. The engine can, however, be allowed just to idle.

Parking

- Depress the brake pedal.
- Firmly apply the handbrake.
- Press and Shiftlock button in the selector lever, move the selector lever to **P** and then release the Shiftlock button.

¹⁾ Applies to AG.

Selector lever positions





Fig. 89 Selector lever/information display: Selector lever positions

 First read and observe the introductory information and safety warnings  on page 90.

The current selector lever position is indicated in the information display of the instrument cluster  » Fig. 89.

- Parklock

The driven wheels are locked mechanically in this position.

The Parklock must only be engaged when the vehicle is stationary.

If you wish to move the selector lever into/out of this position, the Shiftlock button in the selector lever handle and the brake pedal must be actuated at the same time.

If the battery is used, the selector lever cannot be moved out of the position **P**.

- Reverse gear

Reverse gear must only be engaged when the vehicle is stationary and the engine is idling.

The brake pedal must be depressed and at the same time the Shiftlock must be pressed, if you wish to obtain the selector lever positions **R**, **P** or **N**.

When the ignition is switched on and the selector lever is in position **R**, the reverse lights will come on.

N - Neutral

The transmission is in Neutral in this position.

The brake pedal must be depressed to move the selector lever out of the position **N** (if the lever is in this position for longer than 2 seconds) into the position **D** or **R** when the vehicle is travelling at less than 5 km/h or the vehicle is stationary and the ignition is switched on.

D - Position for driving forward (normal programme)

When the selector lever is in this position, the forward gears are automatically shifted up and down in line with the engine load, vehicle speed and dynamic shift programme.

The brake pedal must be depressed to move the selector lever into position **D** from **N** when the vehicle is travelling at less than 5 km/h or is stationary.

Under certain circumstances (e.g. when driving in mountainous regions or when towing a trailer) it may be beneficial to select the manual shift programme » page 92 for a short time in order to adapt the gearbox ratios manually to the driving situations.

S - Position for driving forward (sports programme)

Shifting up later into a higher gear makes it possible to fully exploit the power potential of the engine. The gearbox also then shifts down at higher engine speeds as in the position **D**.

The Shiftlock on the selector lever grip must be pressed when moving the selector lever out of the position **D** into the position **S**.

Manual shifting of gears (Tiptronic)



Fig. 90 Selector lever and multifunction steering wheel



First read and observe the introductory information and safety warnings **I** on page 90.

Tiptronic mode makes it possible to manually shift gears with the selector lever or multifunction steering wheel.

Switching to manual shifting

➤ Push the selector lever to the right out of position **D**. The selector lever position you have engaged is indicated in the information display of the instrument cluster together with the engaged gear **1** » Fig. 89 on page 91 on the right.

Shifting up gears

➤ Press the selector lever forwards **+** » Fig. 90.

➤ Pull the right rocker switch **+** towards the multifunction steering wheel.

Shifting down gears

➤ Press the selector lever backwards **-** » Fig. 90.

➤ Pull the left rocker switch **-** towards the multifunction steering wheel.

Temporarily switching to manual shifting

➤ If the selector lever is in position **D** or **S**, pull the left rocker switch **-** or the right rocker switch **+** towards the multifunction steering wheel.

➤ Manual shifting switches off if the rocker switches **-** or **+** are not actuated for some time. You can also switch off the temporary switch-over to manual shifting by pressing the right rocker switch **+** for more than 1 second.

It is possible to switch to manual shifting when the car is stationary and when driving.

When accelerating, the gearbox automatically shifts up into the higher gear just before the maximum permissible engine speed is reached.

If a lower gear is selected, the gearbox does not shift down until there is no risk of the engine overrevving.

If you operate the kickdown function, the gearbox shifts into a lower gear in line with the vehicle speed and engine speed.

i Note



The kickdown function is also available when manually shifting gears.

Selector lever lock



First read and observe the introductory information and safety warnings  on page 90.

Automatic selector lever lock

With the ignition on, the selector lever is locked when it is in the positions **P** and **N**. The brake pedal must be depressed to move the selector lever out of this position. The warning light  » page 24, *Selector lever lock*  illuminates in the instrument cluster as a reminder for the driver when the selector lever is in the positions **P** and **N**.

The selector lever is not locked when quickly moving across the position **N** (e.g. from **R** to **D**). This, for example, helps to rock out a vehicle that is stuck. The selector lever lock will click into place if the lever is in the **N** position for more than 2 seconds without the brake pedal being pressed.

The selector lever lock is only active if the vehicle is stationary or moving at speed of less than 5 km/hour. The lock is switched off automatically into position **N** when the car is travelling at a higher speed.

Shiftlock button

The Shiftlock button in the handle of selector lever prevents certain selector lever positions being engaged inadvertently. The selector lever lock is cancelled when the Shiftlock button is pressed.

Ignition key withdrawal lock¹⁾

After the ignition is switched off, the ignition key can only be withdrawn if the selector lever is in the position **P**. If the ignition key is withdrawn, the selector lever is blocked in position **P**.

Kickdown function



First read and observe the introductory information and safety warnings  on page 90.


The kickdown function provides you with maximum acceleration power.

When the accelerator pedal is fully depressed, the kickdown function is activated in the desired driving program. This function has precedence over the driving programme and serves for maximum acceleration of the vehicle when exploiting the

maximum power potential of the engine without taking into account the current selector lever position (**D**, **S** or **Tiptronic**). The gearbox shifts down to one or several gears in line with the driving state and the vehicle accelerates. The gearbox does not shift up into the highest gear until the engine has reached its maximum revolutions for this gear range.

Dynamic shift programme



First read and observe the introductory information and safety warnings  on page 90.

The automatic gearbox of your vehicle is controlled electronically. Shifting up and down through the gears is performed automatically on the basis of pre-defined driving programmes.

Adopting a **moderate style of driving** will cause the gearbox to select the most economical driving programme. Shifting up into a higher gear as soon as possible and shifting down as late as possible will have a favourable effect on your fuel consumption.



When adopting a **sporty style of driving** with rapid movements of the accelerator pedal combined with sharp acceleration, frequent changes in speed and exploiting the top speed of the car, the gearbox will adjust to this style of driving once the accelerator pedal (kickdown function) is depressed and will shift down earlier, frequently by several gears in comparison to a moderate style of driving.

Selecting the most appropriate driving programme for the particular style of driving is a continuous process. Irrespective of this it is, however, possible to switch or shift down into a dynamic shift programme by depressing the accelerator rapidly. The gearbox shifts down into a lower gear in accordance with the speed, therefore enabling rapid acceleration (e.g. when overtaking) without the accelerator pedal having to be depressed into the kickdown range. The original programme will be reactivated to match your particular style of driving once the gearbox has shifted up again.

When driving in hilly regions, the gears are selected to match uphill and downhill sections. This avoids the gearbox frequently shifting up and down when negotiating an uphill stretch. When driving downhill, it is possible to shift down into the Tiptronic position, in order to exploit the engine brake torque.

¹⁾ Only valid for some countries.

Emergency programme

 First read and observe the introductory information and safety warnings  on page 90.

An emergency programme exists in the event of a fault in the system.

The gearbox operates in a corresponding emergency programme if there are functional faults in the gearbox electronics. All of the display elements illuminate or go out.

A functional fault can have the following effect:

- The gearbox only shifts into certain gears;
- The reverse gear **R** cannot be used,
- The manual shift programme is switched off in emergency mode.

Note

If the gearbox has switched to emergency mode, drive to a ŠKODA specialist garage to have the fault rectified.

Selector lever-emergency unlocking




Fig. 91
Selector lever-emergency unlocking

 First read and observe the introductory information and safety warnings  on page 90.

In case of interruption of the power supply (e.g. flat vehicle battery, defective fuse) or defect of the selector lever lock, the selector lever can no longer be shifted from the position **P** in the normal way and the vehicle can no longer be moved. The selector lever must be unlocked in case of emergency.

- Firmly apply the handbrake.
- Carefully pull up the front left and right cover.

- Pull up rear cover.
- Use a finger to press the yellow plastic part in the direction of the arrow » Fig. 91.
- Simultaneously press the Shiftlock button in the handle of the selector lever and shift the lever into the position **N** (if the selector lever is shifted back into the position **P**, it is blocked again).

Communication

Mobile phones and two-way radio systems

ŠKODA permits the operation of mobile phones and two-way radio systems with a professionally installed external aerial and a maximum transmission power of up to 10 watts.

Please refer to a ŠKODA Service Partner for information about the possibilities of installing and operating mobile phones and two-way radio systems that have a transmission power of more than 10 W.

Operating mobile phones or two-way radio systems may interfere with the functionality of the electronic systems in your vehicle.

The reasons for this are as follows:

- no external aerial;
- external aerial incorrectly installed;
- transmission power greater than 10 watts.

! WARNING

- Concentrate fully at all times on your driving! As the driver you are fully responsible for road safety. Use the telephone system only to such an extent that you are in full control of your vehicle at any time.
- The national regulations for using a mobile phone in a vehicle must be observed.
- If a mobile phone or a two-way radio system is operated in a vehicle without an external aerial or an external aerial which has been installed incorrectly, this can increase the strength of the electromagnetic field inside the vehicle.
- Two-way radio systems, mobile phones or mounts must not be installed on airbag covers or within the immediate deployment range of the airbags.
- Never leave a mobile phone on a seat, on the dash panel or in another area, from which it can be thrown during a sudden braking manoeuvre, an accident or a collision - risk of injury.
- In the event of air transport, the Bluetooth® function for the hands-free system must be switched off by a specialist garage.

i Note

- We recommend that the installation of mobile phones and two-way radio systems in a vehicle be carried out by a ŠKODA Service Partner.
- Not all mobile phones that enable Bluetooth® communication are compatible with the universal telephone preinstallation GSM II. You can ask an authorised ŠKODA Service Partner whether your telephone is compatible with the universal telephone preinstallation GSM II.
- The range of the Bluetooth® connection to the hands-free system is restricted to the vehicle interior. The range is dependent on local factors, e.g. obstacles between the devices and mutual interferences with other devices. If your mobile phone is in a jacket pocket, for example, this can lead to difficulties when establishing a connection with the hands-free-system or transferring data.

Universal telephone preinstallation GSM II

Introductory information

The universal telephone preinstallation GSM II (hands-free system) includes a convenience mode for the mobile phone via voice control, the multifunction steering wheel, the adapter, radio or the navigation system.

The universal telephone preinstallation GSM II comprises the following functions.

- Phone Phonebook » [page 96](#).
- Convenience operation of the telephone via the multifunction steering wheel » [page 96](#).
- Managing telephone calls via the adapter » [page 97](#).
- Operation of the telephone via the information display » [page 99](#).
- Voice control of the telephone » [page 99](#).
- Music playback from the telephone or other multimedia units » [page 101](#).

All communication between a mobile phone and your vehicle's hands-free system is established with the help of Bluetooth® technology. The adapter serves only for charging the telephone and for transmitting the signal to the vehicle's external aerial.

i Note

The following guidelines must be observed » [page 95](#), *Mobile phones and two-way radio systems*.

Phone Phonebook

A phone phonebook is part of the hands-free system. This phone phonebook can be used depending on the type of mobile phone.

After the first connection of the telephone, the system begins to load the phone book from the phone and the SIM card into the memory of the control unit.

Each time the telephone has established a new connection with the hands-free system, an update of the relevant phone book is performed. The updating can take a few minutes. During this time the phone book, which was stored after the last update was completed, is available. Newly stored telephone numbers are only shown after the updating has ended.

The update is interrupted if a telephone event (e.g. incoming or outgoing call, voice control dialogue) occurs during the updating procedure. After the telephone event has ended, the updating starts anew.

The internal phonebook provides 2 500 free memory locations. Each contact can contain up to 4 numbers.

If the number of contacts loaded exceeds 2 500, the phone book is not complete. ■

Operating the phone on the multifunction steering wheel











Fig. 92
Multifunction steering wheel:
Mobile phone operation

The driver can set the basic functions of the telephone by simply operating the buttons located on the steering wheel so that he can concentrate on the traffic situation without being distracted as little as possible by operating the telephone » Fig. 92.

This applies only if your vehicle has been equipped with the universal telephone preinstallation (hands-free system) at the factory.

If the side lights are switched on, the buttons and the symbols  and  on the multifunction steering wheel are illuminated.

Button	Action	Operation
	Press briefly	Accept call, terminate call, entry in the main menu of the telephone, list of selected numbers
	Press button for a long period of time	Reject call, last dialed number ^{a)} , switch on/off voice control ^{b)}
	Press briefly	Switch on/off voice control
	Turn upwards	Increase volume
	Turn downwards	Decrease volume

^{a)} Valid for vehicles with the Amundsen+ navigation system.

^{b)} Valid for vehicles without the Amundsen+ navigation system. ■

Inserting the mobile phone and adapter




Fig. 93
Universal telephone preinstallation

Only one telephone mount is factory-fitted. An adapter for the mobile phone can be purchased from ŠKODA Original Accessories.

Install

- First of all push the adapter **A** in the direction of the arrow » Fig. 93 up to the stop into the mount. Then press the adapter slightly downwards, until it locks securely into position.
- Insert the mobile phone into the adapter **A** (as specified in the instructions from the manufacturer of the adapter).

Removing

- Simultaneously press the locks on the mount » Fig. 93 and remove the adapter with the mobile phone.

! CAUTION

Taking the mobile phone out of the adapter during the call can lead to interruption of the connection. When removing the mobile phone, the connection to the factory-fitted antenna is interrupted, which reduces the quality of the transmitting and receiving signal. The charging of the mobile phone battery is also interrupted.



Managing telephone calls with the help of the adapter



Fig. 94 Principle sketch: Adapter with one button/adapter with two buttons

Function overview of the  » Fig. 94 (PTT - "push to talk") button on the adapter:

- Switch on/off voice control;
- Accept/end a call.

Some adapters include the button  **A** » Fig. 94 in addition to the button . After pressing this button for 2 seconds, the number 112 (Emergency call) is dialled.

Connecting the mobile phone to the hands-free system

To connect a mobile phone with the hands-free system, the two devices must be paired. Detailed information on this is provided in the operating instructions for your mobile phone.

The following steps must be carried out for the connection.

- Activate Bluetooth® and the visibility of your mobile phone on your telephone.
- Switch on the ignition.
- Select the menu **Phone - New user** in the information display and wait until the control unit has completed the search.
- Select your mobile phone from the menu of the units found.
- Confirm the PIN¹⁾.

¹⁾ Depending on the Bluetooth® version on the mobile phone, an automatically generated 6-digit PIN is either displayed or the PIN **1234** has to be entered manually.

- If the hands-free system announces (as standard **SKODA_BT**) on the display of the mobile phone, enter the PIN¹⁾ within 30 seconds and wait, until the connection is established²⁾.
- After terminating the connection, confirm the creation of a new user profile in the information display.

If there is no free space available to create a new user profile, delete an existing user profile.

During the connecting procedure, no other mobile phone may be connected with the hands-free system.

Up to four mobile phones can be paired with the hands-free system, whereby only one mobile phone can communicate with the hands-free system.

The visibility of the hands-free system is automatically switched off 3 minutes after the ignition is switched on and is also deactivated when the mobile phone has connected to the hands-free system.

Restoring the visibility of the hands-free system

If you have not managed to connect your mobile phone with the hands-free system within 3 minutes of switching on the ignition, the visibility of the hands-free system can be reestablished for 3 minutes in the following ways.

- By turning the ignition off and on.
- By turning voice control off and on.
- Via the information display in the menu item **Bluetooth - Visibility**.

Creating a connection with an already paired mobile phone

After switching on the ignition, the connection is automatically established for the already paired mobile phone²⁾. Check on your mobile phone if the automatic connection has been established.

Disconnecting the connection

- By withdrawing the ignition key.
- By disconnecting the hands-free system in the mobile phone.
- By disconnecting the user in the information display in the menu **Bluetooth - User**.

¹⁾ Depending on the Bluetooth[®] version on the mobile phone, an automatically generated 6-digit PIN is either displayed or the PIN **1234** has to be entered manually.

²⁾ Some mobile phones have a menu, in which the authorisation for establishing a Bluetooth[®] connection is completed by inputting a code. If the authorisation input is required, it must always be performed when re-establishing the Bluetooth connection.

Solving connection problems






If the system announces **No paired phone found**, check the operating state of the mobile phone.

- Is the mobile phone switched on?
- Is the PIN code entered?
- Is Bluetooth[®] active?
- Is the visibility of the mobile phone active?
- Has the mobile phone already been paired with the hands-free system?

Note

- If a suitable adapter is available for your mobile phone, only use your mobile phone in the adapter inserted in the telephone mount so that the radiation in the vehicle drops to a minimum.
- Placing the mobile phone in the adapter inserted in the telephone mount ensures optimum sending and receiving power.

Symbols in the information display

Symbol	Importance
	Charge status of the phone battery ^{a)}
	Signal strength ^{a)}
	a phone is connected to the hands-free system.
	The hands-free system is visible to other devices.
	A multimedia unit is connected to the hands-free system.

^{a)} This function is only supported by some mobile phones.

Operate the telephone via the information display

The following menu points can be selected in the menu **Phone**.

- **Phone book**
- **Dial number**¹⁾
- **Call register**
- **Voice mailbox**
- **Bluetooth**¹⁾
- **Settings**²⁾
- **Back**

Phone book

In the menu point **Phone book** is the list of the loaded contacts from the telephone memory and the SIM card of the mobile phone.

Dial number

Any telephone number can be entered in the menu point **Dial number**. The required numbers must be selected one after the other using adjustment wheel and confirmed by pressing the adjustment wheel. You can select numbers **0 - 9**, symbols **+**, *****, **#**, and functions **Cancel**, **Call**, and **Delete**.

Call register

The following menu items can be selected in the menu item **Call register**.

- **Missed calls**
- **Dialled numbers**
- **Received calls**

Voice mailbox

In the menu **Voice mailbox**, it is possible to set the number of the voice mailbox¹⁾ and then dial the number.

Bluetooth

The following menu items can be selected in the menu **Bluetooth**.

- **User** - the overview of the stored users
- **New user** - Search for new mobile phones that are in the reception range
- **Visibility** - Switching on the visibility of the telephone unit for other devices

- **Media player**
 - **Active device**
 - **Paired devices**
 - **Search**
- **Phone name** - the possibility to change the name of the telephone unit (pre-set SKODA UHV)

Settings

The following menu items can be selected in the menu **Settings**.

- **Phone book**
 - **Update**¹⁾
 - **List**
 - **Surname**
 - **First name**
- **Ring tone**

Back

Return in the Start menu of the telephone.

Voice control

Dialogue

The period of time during which the system is ready to receive voice commands and to carry them out is called a dialogue. The system gives audible feedback and guides you if necessary through the relevant functions.

Optimum understanding of the voice commands depends on several factors.

- Speak with a normal tone of voice without intonation and excessive pauses.
- Avoid a bad pronunciation.
- Close the doors, windows and sliding roof, to reduce or stop disturbing exterior noise.
- It is recommended to speak louder at higher speeds, so that the tone of your voice is louder than the increased surrounding noise.
- During the dialogue, limit additional noise in the vehicle, e.g. passengers talking at the same time.
- Do not speak, if the system makes an announcement.

¹⁾ On vehicles fitted with the Amundsen+ navigation system, this function can be accessed via the navigation system menu; refer to the operating instructions for the Amundsen+ navigation system.

²⁾ This function is not available in vehicles fitted with the Amundsen+ navigation system.



The microphone for voice control is inserted in the moulded headliner and directed to the driver and front passenger. Therefore the driver and the front passenger can operate the equipment.

Entering a phone number

The telephone number can be entered as a continuous series of individually spoken digits (the whole number at once) or in the form of digital blocks (separated by short pauses). After each order of digits (separation through brief voice pause) all of the digits detected up to now are repeated by the system.

The digits **0 - 9**, symbols **+**, *****, **#** are permitted. The system detects no continuous digit combinations such as twenty-three, but only individually spoken digits (two, three).

Switching on voice control



- by briefly pressing the button  on the adapter» Fig. 94 on page 97,
- by briefly pressing the button  on the multi-function steering wheel » page 96, *Operating the phone on the multifunction steering wheel.*

Switching off voice control

If the system is currently playing a message, the message that is currently being played will have to be stopped:

- by briefly pressing the button  on the adapter;
- by briefly pressing the button  on the multifunction steering wheel.

If the system expects a voice command, you can end the dialogue yourself:

- with the **CANCEL** voice command;
- by pressing the button  on the adapter;
- by briefly pressing the button  on the multifunction steering wheel.

Note

- The dialogue of an incoming call is immediately interrupted.
- The voice control is only possible in vehicles fitted with a multifunction steering wheel with telephone control or a phone mount and adapter.

Voice commands

Basic voice commands

Voice command	Action
HELP	After this command the system repeats all possible commands.
CALL XYZ	This command calls up the contact from the phone book.
PHONE BOOK	After this command, for example, the phone book can be repeated back to you, a voice entry for the contact can be updated or deleted, etc.
CALL HISTORY	Lists of dialled numbers, missed calls, etc.
DIAL NUMBER	After this command, a telephone number can be entered to establish a connection with the requested party.
REDIAL	After this command the system calls the last dialled number.
MUSIC^{a)}	Play music from the mobile phone or another paired device.
FURTHER OPTIONS	After this command the system offers additional context-dependent commands.
SETTINGS	Selection for setting Bluetooth [®] , dialogue etc.
CANCEL	The dialogue is ended.

^{a)} On vehicles fitted with the Amundsen+ navigation system, this function can be accessed via the navigation system menu; refer to the operating instructions for the Amundsen+ navigation system.

If a voice command is not detected, the system answers with **"Sorry?"** and a new entry can be completed. After the 2nd error the system repeats the aid. After the 3rd error the answer **"Cancelled"** is given and the dialogue is ended.

Store voice recording of a contact

If automatic name recognition does not work reliably for some contacts, you can choose to save your own voice entry for the contact in the menu **Phone book - Voice Tag - Record**.

Your own voice entry can also be saved using the voice control in the menu **FURTHER OPTIONS**.

Multimedia

Music playback via Bluetooth®

The universal telephone preinstallation GSM II makes it possible to play back music via Bluetooth® from the devices such as MP3 player, mobile phone or notebook.

To ensure the music can be played back via Bluetooth®, it is necessary to connect the terminal device with the hands-free system in the menu **Phone - Bluetooth - Media player**.

The music playback process is performed on the connected device.

The universal telephone preinstallation GSM II ensures that the music played back via the hands-free system can be controlled with the remote control » [page 100](#), *Voice commands*.

i Note

The device being connected must support the Bluetooth® A2DP profile; refer to the operating instructions for the relevant device being connected.

Operating the radio and navigation system on the multifunction steering wheel




Fig. 95
Multifunction steering wheel:
control buttons

The radio and navigation system can of course still be operated on the devices. A description is included in the relevant operating instructions.

If the side lights are switched on, the buttons on the multifunction steering wheel are illuminated.

The buttons apply for the respective operating mode of the current radio or navigation system.

The following functions can be completed by pressing or turning the buttons.

The multifunction steering wheel comprises buttons for setting the basic functions for the factory-fitted radio and navigation system » [Fig. 95](#).

Button	Action	Radio, traffic information	CD/MP3/Navigation
1	Press briefly		Switch off/on tone
1	Press button for a long period of time		Switch the unit on/off
1	Turn upwards		Increase volume
1	Turn downwards		Decrease volume
2	Press briefly	Switch to the next stored radio station Interruption of the traffic report	Changing to the next title
2	Press button for a long period of time	Search forwards	Fast forward

Button	Action	Radio, traffic information	CD/MP3/Navigation
3	Press briefly	Switch to the previous stored radio station Interruption of the traffic report	Changing to the previous title
3	Press button for a long period of time	Search backwards	Fast rewind

i Note

- The functions of button **1** are different for vehicles fitted with a universal telephone preinstallation GSM II » [page 96](#).
- The loudspeakers in the vehicle are adjusted to the power output of the radio and navigation system of 4x20°W.

AUX-IN and MDI inputs

The AUX-IN input is located below the front armrest and is marked with **AUX**.

The MDI input is located beneath the storage compartment on the front passenger side.

The AUX-IN and MDI inputs are used to connect external audio sources (e.g. iPod or mp3 player) and to play back music from these devices via the factory-fitted radio or navigation system.

For a description of use, refer to the operating instructions for the relevant radio or navigation system.

Safety

Passive Safety

General information

Introduction

This chapter contains information on the following subjects:

Safety equipment _____	103
Before setting off _____	103
What influences the driving safety? _____	104

In this section you will find important information, tips and notes on the subject of passive safety in your vehicle. We have combined everything here which you should be familiar with, for example, regarding seat belts, airbags, child seats and safety of children. It is therefore important, in particular, to comply with the notes and warnings in this section for your own interest and in the interest of those travelling with you.

WARNING

- This chapter contains important information on how to use the vehicle for the driver and his occupants. You will find further information on safety, which concerns you and those travelling with you, in the following chapters of this Owner's Manual.
- The complete on-board literature should always be in the vehicle. This applies in particular, if you rent out or sell the vehicle.

Safety equipment

 First read and observe the introductory information and safety warnings  on page 103.

The following list contains part of the safety equipment in your vehicle:

- › three-point seat belts for all the seats;
- › belt force limiters for the front seats;

- › belt tensioners for front seats;
- › seat belt height adjusters for front seats;
- › Front airbag for the driver and the front seat passenger;
- › side airbags;
- › head airbags;
- › anchoring points for child seat using the ISOFIX system;
- › anchoring points for child seat using the TOP TETHER system;
- › head restraints adjustable for height;
- › adjustable steering column.

The specified safety equipment works together, in order to optimally protect you and those travelling with you in accident situations. The safety equipment does not protect you or the people travelling with you, if you or your occupants adopt an incorrect seated position or the equipment is not correctly adjusted or used.

Before setting off


 First read and observe the introductory information and safety warnings  on page 103.

For your own safety and the safety of the people travelling with you, please pay attention to the following points before setting off.

- › Ensure that the lighting and the turn signal system are functioning properly.
- › Check the tyre inflation pressure.
- › Ensure that all of the windows offer good visibility to the outside.
- › Secure all items of luggage » page 53.
- › Ensure that no objects can obstruct the pedals.
- › Adjust the mirrors, the front seat and head restraint to your body size.
- › Advise your passengers to adjust the head restraints to their body size.
- › Protect children in suitable child seats with correctly fastened seat belts » page 117, *Transporting children safely*.
- › Adopt the correct seated position » page 104. Tell your passengers to assume the correct seated position.
- › Correctly fasten the seat belt. Also inform passengers to fasten the seat belt correctly » page 107.

What influences the driving safety?



First read and observe the introductory information and safety warnings  on page 103.

The driver is fully responsible for himself and his occupants. If your driving safety is effected, you place yourself and the oncoming traffic at risk.

The following guidelines must therefore be observed.

- ▶ Do not get distracted from concentrating on the traffic situation, e.g. by your passengers or mobile phone calls.
- ▶ Never drive when your driving ability is impaired, e.g. through medication, alcohol, drugs.
- ▶ Keep to the traffic regulations and the permissible speed limit.
- ▶ Always adjust the driving speed to the road, traffic and weather conditions.
- ▶ Take regular breaks on long journeys – at least every two hours.

Correct seated position



Introduction

This chapter contains information on the following subjects:

Correct seated position for the driver	105
Correct seated position for the front passenger	105
Correct seated position for the occupants on the rear seats	105
Examples of an incorrect seated position	105



WARNING

- The front seats and the head restraints must always be adjusted to match the body size of the seat occupant as well as the seat belts must always be correctly fastened in order to provide an optimal protection for you and your occupants.
- Always assume the correct seated position before setting off and do not change this position while driving. Also advise your passengers to adopt the correct seated position and not to change this position while the car is moving.



WARNING (Continued)

- If the occupant adopts an incorrect seated position, he is exposed to life-threatening injuries, in case he is hit by a deployed airbag.
- If the occupants on the rear seats are not sitting upright, the risk of injury is increased due to incorrect routing of the seat belt.
- The driver must maintain a distance of at least 25 cm to the steering wheel. The front passenger must maintain a distance of at least 25 cm to the dash panel. Not maintaining this minimum distance will mean that the airbag system will not be able to properly protect you - hazard!
- When driving, hold the steering wheel with both hands firmly on the outer edge in the 9 o'clock and 3 o'clock position. Never hold the steering wheel in the 12 o'clock position or in any other way (e.g. in the middle or inner edge of the steering wheel). In such cases, you could severely injure the arms, hands and head when the driver airbag is deployed.
- The seat backrests must not be angled too far back when driving otherwise this will affect proper operation of the seat belts and of the airbag system - risk of injury!
- Ensure that there are no objects in the driver's footwell as they may get caught behind the pedals when driving or applying the braking. You would then no longer be able to operate the clutch, brake or accelerate.
- Always keep your feet in the footwell when the car is being driven - never place your feet on the instrument panel, out of the window or on the surfaces of the seats. You will be exposed to increased risk of injury if it becomes necessary to apply the brake or in the event of an accident. If an airbag is deployed, you may suffer fatal injuries when adopting an incorrect seated position!

Correct seated position for the driver




Fig. 96 The correct distance of the driver to the steering wheel/The correct head restraint adjustment

 First read and observe the introductory information and safety warnings  on page 104.

For your own safety and to reduce the risk of injury in the event of an accident, we recommend the following setting.

- Adjust the steering wheel so that the distance **A** » Fig. 96 between the steering wheel and your chest is at least 25 cm.
- Adjust the driver's seat in the forward/back direction so that the pedals can be fully depressed with slightly bent legs.
- Adjust the seat backrest so that the highest point of the steering wheel can be reached with your arms at a slight angle.
- Adjust the head restraint so that the top edge **B** of the head restraint is at the same level as the upper part of your head.
- Correctly fasten the seat belt » page 107, *Seat belts*.

Driver seat adjustment » page 50, *Adjusting the front seats - Version 1* or » page 50, *Adjusting the front seats - Variant 2*.

Correct seated position for the front passenger

 First read and observe the introductory information and safety warnings  on page 104.

For the safety of the front passenger and to reduce the risk of injury in the event of an accident, we recommend the following setting.

- Position the front passenger seat back as far as possible. The front passenger must maintain a distance of at least 25 cm to the dash panel so that the airbag offers the greatest possible safety if it is deployed.
- Adjust the head restraint so that the top edge **B** » Fig. 96 on page 105 » page 105 of the head restraint is at the same level as the upper part of your head.
- Correctly fasten the seat belt » page 107, *Seat belts*.

In exceptional cases the front passenger airbag can be deactivated » page 115, *Deactivating airbags*.

Front passenger adjustment » page 50, *Adjusting the front seats - Version 1*.

Correct seated position for the occupants on the rear seats

 First read and observe the introductory information and safety warnings  on page 104.

To reduce the risk of injury in the event of a sudden braking manoeuvre or an accident, the occupants on the rear seats must observe the following.

- Adjust the head restraint so that the top edge **B** » Fig. 96 on page 105 » page 105 of the head restraint is at the same level as the upper part of your head.
- Correctly fasten the seat belt » page 107, *Seat belts*.
- Use a suitable child restraint system if transporting children in the vehicle » page 117, *Transporting children safely*.

Examples of an incorrect seated position

 First read and observe the introductory information and safety warnings  on page 104.

Seat belts offer their optimum protection only if the webbing of the seat belts is properly routed. Incorrect seated positions considerably reduce the protective functions of the seat belts and therefore increase the risk of injury due to an incorrect routing of the seat belt. The driver is fully responsible for himself and passengers, especially children. Never allow a passenger to adopt an incorrect seated position when the car is moving.

The following list contains examples of which seated positions can cause serious injuries or death. This list is not complete, however we would like you to familiarise yourself with this subject.

Therefore, while the car is moving never:

- > stand up in the vehicle;
- > stand up on the seats;
- > kneel on the seats;
- > tilt the seat backrest fully to the back;
- > lean against the dash panel;
- > lie on the rear seat bench;
- > only sit on the front area of the seat;
- > sit to the side;
- > lean out of the window;
- > put the feet out of the window;
- > put the feet on the dash panel;
- > put the feet on the seat upholstery;
- > transport somebody in the footwell;
- > have the seat belt not fastened when driving;
- > be in the boot.



Seat belts

Seat belts

Introduction



Fig. 97
Driver wearing seat belt

This chapter contains information on the following subjects:

The physical principle of a frontal collision	108
Fastening and unfastening seat belts	109
Seat belt height adjuster on the front seats	110
Belt tensioners	110

Seat belts that are fastened correctly offer good protection in the event of an accident. They reduce the risk of an injury and increase the chance of survival in the event of a major accident.

Correctly fastened seat belts hold occupants of the car in the correct seated position » Fig. 97.

The seat belts reduce the kinetic energy (energy of motion) to a considerable extent. They also prevent uncontrolled movements which, in turn, may well result in severe injuries.

The occupants of a vehicle who have fastened and correctly adjusted their seat belt, profit to a major extent from the fact that the kinetic energy is optimally absorbed by the belts. The structure of the front end of the vehicle and other passive safety measures, such as the airbag system, also contribute to reducing the kinetic energy. The energy produced is thus absorbed and there is less risk of injury.

Particular safety aspects must be observed when transporting children in the vehicle » page 117, *Transporting children safely*.

! WARNING

- Fasten your seat belt before each journey - even when driving in town! This also applies to the people seated at the rear - risk of injury!
- Expectant women must also always wear a seat belt. This is the only way of ensuring optimal protection for the unborn child » page 109, *Fastening and unfastening seat belts*.
- Adjust the height of the belt in such a way that the shoulder part of the belt is roughly positioned across the middle of your shoulder - on no account across your neck.
- Always ensure that the webbing of the seat belts is properly routed. Seat belts which are not correctly adjusted can themselves cause injuries even in minor accidents.
- The maximum protection which seat belts can offer is only achieved if you are correctly seated » page 104, *Correct seated position*.
- The seat backrests of the front seats must not be tilted too far to the rear otherwise the seatbelts can lose their effectiveness.
- The belt webbing must not be jammed in-between at any point or twisted, or chafe against any sharp edges.
- A seat belt which is hanging too loose can result in injuries as your body is moved forward by the kinetic energy produced in an accident and is then suddenly held firm by the belt.
- The belt webbing must not run across solid or fragile objects (e.g. spectacles, ball-point pens, keys etc.) as this may be a cause of injuries.
- No two persons (also not children) should ever use a single seat belt together.
- The lock tongue should only be inserted into the lock which is the correct one for your seat. Wrong use of the safety belt will reduce its capacity to protect and the risk of injury increases.
- The slot of the belt tongue must not be blocked by paper or similar objects otherwise the belt tongue will not lock in place properly.
- Many layers of clothing and loose clothing (e. g. a winter coat over a jacket) do not allow you to be correctly seated and impairs proper operation of the seat belts.
- It is prohibited to use clamps or other objects to adjust seat belts (e. g. for shortening the belts for smaller persons).

! WARNING (Continued)

- The seat belts for the rear seats can only fulfil their function reliably when the seat backrests are correctly locked into position » page 52.
- The belt webbing must always be kept clean. Soiled belt webbing may impair proper operation of the inertia reel » page 135.
- The seat belts must not be removed or changed in any way. Do not attempt to repair the seat belts yourself.
- Check the condition of all the seat belts on a regular basis. If any damage to the seat belts, seat belt tongue, inertia reel or the lock is detected, the relevant seat belt must be replaced by a specialist garage.
- Damaged seat belts which have been subjected to stress in an accident and were therefore stretched, must be replaced - this is best done by a specialist garage. The anchorage points of the belts must also be inspected. The anchorage points for the belts should also be checked.

i Note

The national legal requirements must be observed when using seat belts.

The physical principle of a frontal collision






Fig. 98 Driver without a fastened seat belt/rear seat passenger without a fastened seat belt

 First read and observe the introductory information and safety warnings  on page 107.

The physical principle of a frontal collision can be explained quite simply.

As soon as the vehicle is moving, so-called kinetic energy (the energy of motion) is produced both in terms of the car as well as in terms of the occupants. The magnitude of this kinetic energy depends essentially on the speed at which the vehicle is travelling and on the weight of the vehicle including the occupants. The greater the speed and weight increase, the greater the amount of energy which has to be absorbed in the event of an accident.

The speed of the vehicle is, nevertheless, the most important factor. Doubling the speed of the vehicle from 25 km/h up to 50 km/hour increases the kinetic energy four times.

The common opinion that it is possible to support your body in a minor accident with your hands, is incorrect. Even in a collision at only a low speed, the forces acting on the body are such that it is no longer possible to support your body.

Even if you only drive at a speed of 30 km/h to 50 km/h, the forces that your body is exposed to in the event of an accident can exceed a tonne (1 000 kg).

In the event of a frontal collision, occupants of the car not wearing a seat belt, are thrown forward and strike in an uncontrolled way parts of the interior of the car, such as steering wheel, dash panel or windscreen » Fig. 98 - A. In certain circumstances you could even be thrown out of the vehicle, which could cause life threatening or even fatal injuries.

It is also important that rear seat occupants fasten their seat belts as they will otherwise be thrown through the vehicle in an uncontrolled manner in the event of an accident A rear seat passenger who has not fastened the seat belt is a danger not only to himself but also for those seated at the front » Fig. 98 - B.

Fastening and unfastening seat belts




Fig. 99 Fastening/unfastening the seat belt




Fig. 100 Routing of belt webbing over the shoulders and the lap belt/Routing of belt webbing for an expectant mother

 First read and observe the introductory information and safety warnings  on page 107.

Fasten

- Correctly adjust the front seat and head restraint before fastening the seat belt » page 51.
- Use the lock tongue to slowly pull the webbing over your chest and pelvis.
- Insert the lock tongue into the belt buckle » Fig. 99 - [A] that is part of the seat until it clicks into place.
- Pull on the belt to check that it has engaged correctly in the lock.

A plastic knob in the belt webbing holds the belt tongue in a position which is easy to get hold of.

It is important that the belt webbing is properly routed to ensure seat belts offer the maximum protection. The shoulder part of the seat belt must never run across the neck but must roughly run over the middle of the shoulder and fit snugly against the chest. The lap part of the belt must run across the pelvis, must not be positioned across the stomach and must always fit snugly » Fig. 100 - [C].

Expectant women must also always wear a seat belt. This is the only way of ensuring optimal protection for the unborn child. On expectant mothers, the lap part of the belt must be positioned as low as possible on the pelvis to avoid exerting any pressure on the lower abdomen » Fig. 100 - [D].

Release

Release the seat belt only when the vehicle is stationary.

- Press the red button in the belt buckle » Fig. 99 - [B], the lock tongue pops out.
- Manually guide the belt back so that it is easier to fully roll up the webbing, the seat belt does not twist.

Belt inertia reel

Each seat belt is equipped with an inertia reel. This inertia reel offers you complete freedom of movement if the belt is unreeled slowly. If the brakes are applied suddenly, the inertia reel will block. The belts also block when the car accelerates, when driving downhill and when cornering.

CAUTION

When releasing the seatbelt ensure that the tongue of the lock does not damage the door trim or other parts of the interior.

Seat belt height adjuster on the front seats






Fig. 101
Front seat: Seat belt height adjuster

 First read and observe the introductory information and safety warnings  on page 107.

The seat belt height adjuster makes it possible to adjust the routing of the front seat belts in the area of the shoulder to the body size.

- Press the height adjuster and move up or down in the desired direction » Fig. 101.
- Then pull firmly on the belt to ensure that the seat belt height adjuster has correctly locked in place.

Belt tensioners

 First read and observe the introductory information and safety warnings  on page 107.

Safety for the driver and front passenger **wearing their seat belts** is enhanced by the belt tensioners fitted to the inertia reels of the front three-point seat belts.

The three-point seat belts are automatically tensioned in the event of a frontal collision of a certain severity. The belt tensioners can also be deployed if the seat belts are not fastened.

The fastened three-point seat belts are automatically tensioned in the event of a frontal or side collision of a certain severity.

Belt tensioners are not activated in the event of minor frontal collisions, side and rear-end collisions, in the case of a rollover and also not in accidents in which no major forces are produced from the front.

WARNING

- Any work on the belt tensioner system including removal and installation of system components because of other repair work, must only be carried out by a specialist garage.
- The protective function of the system is only adequate for a single accident. If the belt tensioners have been deployed, it is then necessary to replace the entire system.


Note

- Smoke is generated when the belt tensioners are deployed. This is not an indication of a fire in the vehicle.
- When disposing of the vehicle or parts of the belt tensioner system, it is important to comply with national legal requirements. ŠKODA Service Partners are familiar with these regulations and will be able to provide you with detailed information.

Airbag system

Description of the airbag system

Introductory information





The operational readiness of the airbag system is monitored electronically. The airbag warning light  comes on for a few seconds each time the ignition is switched on » [page 23](#).

The airbags inflate in fractions of a second and at a high speed to offer additional protection in the event of an accident.

The airbag system (according to vehicle equipment) consists of:

- › an electronic control unit;
- › Front airbags for the driver and front seat passenger » [page 112](#);
- › side airbags » [page 113](#);
- › head airbags » [page 114](#);
- › an airbag warning light in the instrument cluster » [page 23](#);
- › a key switch for the front seat passenger airbag » [page 115](#);
- › an warning light in the middle of the dash panel to indicate the front seat passenger airbag is switched off » [page 115](#).

A fault in the airbag system exists if:

- › the warning light  does not illuminate when the ignition is switched on;
- › the warning light  does not go out 3 seconds after the ignition is switched on;
- › the warning light  goes out and comes on again after the ignition is switched on;
- › the warning light  comes on or flashes when driving;
- › the warning light in the middle of the dash panel for the deactivated front seat passenger airbag flashes.

WARNING

- The airbag is not a substitute for the seat belt, but instead forms part of the complete passive vehicle safety concept. **Please note that an airbag can only offer you optimal protection in combination with a seat belt which is fastened.**
- To ensure passengers are protected with the greatest possible effect when the airbag is deployed, the front seats must be correctly adjusted to match the body size » [page 104](#), *Correct seated position*.
- If you do not fasten the seat belts when driving, lean too far forward or adopt an incorrect seated position, you are exposing yourself to increased risk of injury in the event of an accident.
- If there is a fault, have the airbag system checked immediately by a ŠKODA specialist garage. Otherwise, there is a risk of the airbag not being activated in the event of an accident.
- No modifications of any kind must be made to parts of the airbag system. Any work on the airbag system including the installation and removal of system components due to other repair work (e.g. removal of the steering wheel) must only be carried out by a ŠKODA specialist garage.
- Never make any changes to the front bumper or bodywork.
- It is prohibited to manipulate individual parts of the airbag system as this might result in the airbag being deployed.
- The protective function of the airbag system is sufficient for only one accident. The airbag system must then be replaced if the airbag has been deployed.
- The airbag system needs no maintenance during its working life.
- If you sell your vehicle, provide the complete vehicle documentation to the new owner. Please note that the information relating to the possibility of deactivating the front passenger airbag must be included!
- When disposing of vehicle or parts of the airbag system, it is important to comply with the national legal requirements.

When are the airbags deployed?

The airbag system is only functional when the ignition is switched on.

In certain accident situations, the several airbags may be deployed simultaneously.

The airbags **are not deployed** in the case of **minor** frontal and side collisions, rear-end collisions, tilting of the vehicle and vehicle rollover. ►

Deployment factors

It is not possible to generally determine which deployment conditions apply to the airbag system in every situation. An important role is played by factors such as the type of object that the vehicle hits (hard, soft), the impact angle, vehicle speed, etc.

A decisive factor for the deployment of the airbags is the deceleration which occurs. The control unit analyses the nature of the collision and activates the relevant restraint system. If the vehicle deceleration which occurs and is measured during the collision remains below the prescribed reference values specified in the control unit, the airbags are not deployed although the vehicle may well suffer severe damage to the bodywork as a consequence of the accident.

The following will be deployed in the event of a severe frontal collision:

- driver's front airbag;
- passenger's front airbag.

The following will be deployed in the event of a severe side collision:

- front side airbag on the side of the accident;
- head airbags on the side of the accident.

In the event of an accident in which the airbags are deployed:

- the interior lighting comes on (if the switch for the interior light is in the door contact position),
- the hazard warning light is switched on;
- all the doors are unlocked;
- the fuel supply to the engine is interrupted.

i Note

A grey white or red, non-harmful gas is released when the airbag is inflated. This is perfectly normal and is not an indication of a fire in the vehicle.

Front airbags




Fig. 102 Driver airbag in the steering wheel/front passenger airbag in the dashboard




Fig. 103 Safe distance to steering wheel/inflated airbags.

In the event of a severe frontal collision, the front airbag system offers additional protection for the head and chest area of the driver and front passenger.

The front airbag for the driver is housed in the steering wheel » Fig. 102 - [A].

The front airbag for the front seat passenger is located in the dash panel above the stowage compartment [B] - » Fig. 102.

If the airbags are deployed, the airbags are filled with a propellant gas and inflated in front of the driver and front passenger » Fig. 103 - [D]. The forward movement of the driver and of the front passenger is cushioned when they make contact with the fully inflated airbag and the risk of injury to head and chest is thus reduced.

The airbag allows the gas to flow out of the inflated airbag in a controlled manner (depending on the load of the particular car occupant) in order to cushion head and chest areas. The airbag then deflates subsequently to such an extent, after an accident, to again provide a clear view forward.

! WARNING

- For the driver and front passenger, it is important to maintain a distance of at least 25 cm to the steering wheel or dashboard **A** » Fig. 103. Not maintaining this minimum distance will mean that the airbag system will not be able to properly protect you - hazard! The front seats and the head restraints must always also be correctly adjusted to match the body size of the occupant.
- The airbag develops enormous forces when triggered, which can lead to injuries if the sitting position or seated position is not correct.
- There must not be any further persons, animals or objects positioned between the front seated occupants and the deployment area of the airbag.
- Never transport children on the front seat of a vehicle without using a proper restraint system. If airbags are deployed in the event of an accident, the child might suffer severe or even fatal injuries!
- It is essential to always switch off the front passenger airbag when attaching a child safety seat to the front passenger seat where the child is seated with its back facing in direction of travel » page 115, *Deactivating airbags*. If this is not done, there is a risk of the child suffering severe or even fatal injuries if the front passenger airbag is deployed. When transporting a child on the front passenger seat, pay attention to any relevant national regulations regarding the use of child safety seats.
- The steering wheel and the surface of the airbag module in the dash panel on the passenger side must not have stickers attached, be covered or modified in any other way. These parts should only be cleaned with a cloth that is dry or has been moistened with water. No objects such as cup holders, mobile phone mounts, etc. must be attached to the covers of the airbag modules or be located within their immediate vicinity.
- Never place objects on the surface of the front passenger airbag module in the dash panel.

Side airbags




Fig. 104 Location of the side airbag in the driver's seat/gas-filled side airbag

In the event of severe side collisions, the side airbag system provides additional protection for the upper body (chest, stomach and pelvis) of passengers in the vehicle.

The side airbags are housed in the upholstery of the seat backrests of the front seats » Fig. 104 - **A**.

When the side airbags » Fig. 104 - **B** are deployed, the head airbag and belt tensioner are also automatically deployed on the relevant side.

The load of the occupants is cushioned when plunging into the fully inflated airbag and the risk of injury to the entire upper body (chest, stomach and pelvis) is reduced on the side facing the door.

! WARNING

- Your head should never be positioned in the deployment area of the side airbag. You might suffer severe injuries in the event of an accident. This applies in particular to children who are transported without using a suitable child safety seat » page 118, *Child safety and side airbag*.
- There must not be any further persons, animals as well as objects positioned between the occupants and the deployment area of the airbag. No accessories, such as cup holders, should be attached to the doors.
- If children adopt an incorrect seated position when travelling, they may be exposed to an increased risk of injury in the event of an accident. This can result in serious injuries » page 117, *Child seat*.

! WARNING (Continued)

- Only hang light items of clothing on the hooks fitted in the vehicle. Never leave any heavy or sharp-edged objects in the pockets of the items of clothing.
- Ensure that there are no excessive forces, such as violent knocks, kicks etc., impact on the backrests of the seats otherwise the system may be damaged. The side airbags would not be deployed in such a case!
- Any seat or protective covers which you fit to the driver or front passenger seats must only be of the type expressly authorized by ŠKODA. In view of the fact that the airbag inflates out of the backrest of the seat, use of non-approved seat or protective covers would considerably impair the protective function of the side airbag.
- Any damage to the original seat covers in the area of the side airbag module must be repaired without delay by your ŠKODA specialist garage.
- The airbag modules in the front seats must not display any damage, cracks or deep scratches. It is not permissible to use force in order to open the modules.

Head airbags




Fig. 105 Location of the head airbag/gas-filled head airbag

In the event of a severe side collision, the head airbag system offers additional protection for the head and neck area of passengers.

The head airbags are positioned above the doors on both sides in the interior of the car » Fig. 105 - [A].

In the event of a **side collision** the head airbag is deployed together with the relevant side airbag and the belt tensioner on the side of the car on which the accident occurs.

When deployed, the airbag covers the windows of the front and rear doors, as well as the door pillar » Fig. 105 - [B].

Any impact of the head against parts of the interior or objects outside of the car, is cushioned by the inflated head airbag. The reduction in any impact to the head and the resultant minimizing of any movements of the head additionally reduce the risk of injuries to the neck area. The head airbag also offers additional protection in the case of an offset impact by covering the front door pillar.

! WARNING

- There must not be any objects in the deployment area of the head airbags which might prevent the airbags from inflating properly.
- Only hang light items of clothing on the hooks fitted in the vehicle. Never leave any heavy or sharp-edged objects in the pockets of the items of clothing. Additionally, clothes hangers must not be used to hang up items of clothing.
- The airbag control unit operates with sensors located in the front doors. For this reason no adjustments must be carried out to the doors and door panels (e.g. additional installation of loudspeakers). Resulting damages can have a negative affect on the operation of the airbag system. All work on the front doors and their panels must only be carried out by a ŠKODA specialist garage.
- There must no other persons (e.g. children) or animals between the passenger and the deployment area of the head airbag. In addition, none of the occupants should lean their head out of the window when driving, or extend their arms and hands out of the window.
- The sun visors must not be swivelled towards the side windows in the deployment area of the head airbags if any objects, such as ball-point pens, etc. are attached to them. This might result in injuries to the occupants if the head airbag is deployed.
- The installation of impermissible accessories in the vicinity of the head airbags can considerably impair the protection offered by the head airbag in the event of it being deployed. When the deployed head airbag is inflated, parts of the fitted accessories could be thrown into the interior of the car and injure the occupants » page 157, *Accessories, changes and replacement of parts*.

Deactivating airbags

Deactivating airbags

Deactivation of airbags is envisaged only for particular instances, such as if:

- › using a child seat on the front passenger seat, in which the child has its back to the vehicle's direction of travel (in some countries this must be in the direction of travel due to different legal regulations applying) » page 117, *Child seat*;
- › not being able to maintain a distance of at least 25 cm between the middle of the steering wheel and chest, despite the driver's seat being correctly adjusted;
- › special attachments are required in the area of the steering wheel because of a physical disability;
- › other seats have been installed (e.g. orthopaedic seats without side airbags).


The front passenger airbag can be switched off with the key-operated switch » page 115.

We recommend that you ask a ŠKODA Service Partner to switch off any other airbags.



Monitoring the airbag system

The functionality of the airbag system is also monitored electronically when one airbag has been switched off.

If the airbag was switched off using diagnostic equipment:

- › The airbag indicator light  lights up for 3 seconds after the ignition is switched on and then flashes after that for about 12 seconds.

If the airbag was switched off using the key switch on the side of the dash panel:

- › The airbag warning light  comes on for 3 seconds after the ignition has been switched on;
- › Activation of the airbag is indicated by the illumination of the yellow indicator light in display **PASSENGER AIR BAG OFF**  in the middle of the dash panel [3] » Fig. 106 on page 115.

Note

- The national regulations for switching off airbags must be observed.
- A ŠKODA Service Partner will be able to inform you which airbags in your vehicle can/must be deactivated.



Key switch for the front seat passenger airbag





Fig. 106 Key-operated switch for the front passenger airbag/warning light for front seat passenger airbag deactivation

Only the front passenger airbag is deactivated with the key switch.

Deactivating an airbag


- › Switch off the ignition.
- › Use the key to turn the slot of the key-operated switch into the position [2] » Fig. 106 OFF).
- › Check whether the airbag indicator light [3] OFF  in the display **PASSENGER AIR BAG OFF**  in the middle of the dash panel lights up when the ignition is turned on.

Activating an airbag


- › Switch off the ignition.
- › Use the key to turn the slot of the key-operated switch into the position [1] » Fig. 106 ON.
- › Check whether the airbag indicator light [3] OFF  in the display **PASSENGER AIR BAG OFF**  in the middle of the dash panel does not light up when the ignition is turned on.

Indicator light in the display **PASSENGER AIR BAG OFF** (front passenger airbag switched off)

In cases where the front passenger airbag is **switched off** the airbag indicator light comes on for a few seconds after switching on the ignition, goes out for about a second and then comes on again.

There is a system fault in the deactivated airbag »  if the airbag warning light flashes. **Seek help from a ŠKODA specialist garage.**

WARNING

- The driver is responsible for whether the airbag is switched on or switched off.
- Only switch off the airbag when the ignition is switched off! Otherwise a fault can occur in the system for deactivating the airbag.
- If the airbag warning light **OFF**  (airbag switched off) flashes, the front passenger airbag will not be deployed in the event of an accident! Have the airbag system checked by a ŠKODA specialist garage immediately.

Transporting children safely

Child seat

Introduction

This chapter contains information on the following subjects:

Use of a child seat on the front passenger seat	117
Child safety and side airbag	118
Classification of child seats	118
Suitability of child seats	119
Child seats with the ISOFIX system	119
Child seat with the TOP TETHER system	119

Children are generally safer on the rear seats than on the front passenger seat.

In contrast to adults, the muscles and bone structure of children are not yet fully developed. Thus children are exposed to increased risk of injury.

Children should be transported in accordance with the relevant statutory provisions.

Child seats that comply with the ECE-R 44 standard must be used. The ECE-R Norm stands for: Economic Commission for Europe - Regulation.

Child seats that comply with the ECE-R 44 standard have a test seal that cannot be removed: a large E within a circle with the test number below.

! WARNING

- The national legal requirements must be observed when using child seats.
- One should never carry children, and also not babies! - on one's lap.
- Never leave children unattended in the vehicle. Certain outside climatic conditions can cause life-threatening temperatures in the vehicle.
- Under no circumstances allow children to be transported without the use of a suitable restraint system. In the event of an accident the child will be thrown through the vehicle and may as a result suffer fatal injuries, and also injure other occupants.

! WARNING (Continued)

- Children are exposed to an increased risk of injury in the event of an accident if they lean forward or adopt an incorrect seated position when the vehicle is moving. This particularly applies to children who are transported on the front passenger seat as they can suffer severe, or even fatal injuries if the air-bag system is deployed!
- Pay particular attention to the information provided by the manufacturer of the child safety seat regarding the correct routing of the belt. Seat belts which are not correctly adjusted can themselves cause injuries even in minor accidents.
- Safety belts must be checked to ensure that they are running properly. One should also ensure that the belt is not damaged by sharp-edged fittings.
- It is essential to switch off the front passenger airbag if using a child seat in which the child is seated with its back facing the direction of travel on the front passenger seat. Further information » [page 117](#), *Use of a child seat on the front passenger seat.*

i Note

We recommend that you use child seats from ŠKODA Original Accessories. These child seats were developed and also tested for use in ŠKODA vehicles. They fulfil the ECE-R 44 standard.

Use of a child seat on the front passenger seat




Fig. 107
Sticker on the B column on the front passenger side.



First read and observe the introductory information and safety warnings ! on page 117.

For safety reasons, we recommend that you install child seats on the rear seats whenever possible.

The following guidelines must be observed when using a child safety seat in which the child is seated with its back facing the direction of travel on the front passenger seat.

- Switch off the front passenger airbag » [page 115](#), *Deactivating airbags*.
- Slide the front passenger seat all the way back.
- Move the front passenger seat backrest into the vertical position.
- Set the height-adjustable front passenger seat as high up as possible.
- Set the front passenger seat belt as high up as possible.
- Place and fasten the child seat on the seat and the child in the child seat according to the specifications in the manufacturer's user manual of the child seat.

! WARNING

- It is essential to always switch off the front passenger airbag when attaching a child safety seat to the front passenger seat where the child is seated with its back facing in direction of travel » [page 115](#), *Deactivating airbags*.
- **Never** use a child safety seat in which the child is seated with its back facing the direction of travel on the front passenger seat if the airbag is switched on. This child safety seat is positioned in the deployment area of the front passenger airbag. The airbag may cause the child severe, or even fatal injuries, in the event of it being deployed.
- This is also clearly stated on the sticker which is located on the B column on the front passenger side » [Fig. 107](#) or on the front passenger's sun visor.
- If a child safety seat in which the child faces in the direction of travel is used on the front passenger seat, the front passenger seat must be moved back and to the top fully. Move the backrest into the vertical position.
- The front passenger airbag must be reactivated as soon as you no longer use a child seat on the front passenger seat.

Child safety and side airbag




Fig. 108 Incorrect seated position of a child who is not properly secured - risk from the side airbag/Child properly protected by safety seat

First read and observe the introductory information and safety warnings ! on page 117.

The child must not be positioned in the deployment area of the side airbag » [Fig. 108](#) - [A](#). There must be sufficient room between the child and the deployment area of the side airbag so that the airbag can provide as much protection as possible » [Fig. 108](#) - [B](#).

! WARNING

- Children must never be seated with their head in the deployment area of the side airbag - risk of injury!
- Do not place any objects within the deployment area of the side airbags - risk of injury!

Classification of child seats

First read and observe the introductory information and safety warnings ! on page 117.






Child safety seats are classified in 5 groups:




Group	Weight of the child	Approximate age
0	0-10 kg	up to 9 months
0+	up to 13 kg	up to 18 months

Group	Weight of the child	Approximate age
1	9-18 kg	up to 4 years
2	15-25 kg	up to 7 years
3	22-36 kg	over 7 years

Suitability of child seats

 First read and observe the introductory information and safety warnings  on page 117.

Overview of the suitability of child seats according to the standard ECE-R 44	
Seat	Child seat type
Front passenger seat	
Rear seat outside	  
Rear seat middle	

-  Universal category – a child seat with the word UNIVERSAL, which is designed for fastening on the seat with the seat belt.
-  ISOFIX – a child seat which is designed for fastening on the seat with eyelets for the ISOFIX system is provided » [page 119](#).
-  TOP TETHER – a child seat which is designed for fastening on the seat with an eyelet for the TOP TETHER system is provided » [page 119](#).

Child seats with the ISOFIX system



Fig. 109
Rear seat: ISOFIX

 First read and observe the introductory information and safety warnings  on page 117.

There are two locking eyes between the rear exterior seats for fixing the ISOFIX system child seat in place. The places are marked with labels with the ISOFIX logo » [Fig. 109](#).

A child seat fitted with the ISOFIX system can only be mounted in a vehicle fitted with an ISOFIX system if the child seat has been approved for this type of vehicle. Further information is available from a ŠKODA Service Partner.

WARNING

- Always refer to the instructions from the manufacturer of the child seat when installing and removing a child seat with the ISOFIX system.
- Never attach other child seats, belts or objects to the locking eyes intended for the installation of a child seat with the ISOFIX system - hazard!

Note

Child seats with the ISOFIX system can be purchased from ŠKODA Original Accessories.

Child seat with the TOP TETHER system




Fig. 110
Rear seat: TOP TETHER

 First read and observe the introductory information and safety warnings  on page 117.

There are fixing eyes on the rear side of the rear seat backrests for attaching the fixing belt for a child seat with the TOP TETHER system » [Fig. 110](#).



WARNING

- Always refer to the instructions from the manufacturer of the child seat when installing and removing a child seat with the TOP TETHER system.
- Only use child seats with the TOP TETHER system on the seats with the locking eyes.
- Only ever attach one belt from the child seat to a locking eye.
- On no account should you equip your vehicle, e.g. mount screws or other anchorage points.

Driving Tips

Driving and the Environment

The first 1 500 km

New engine

The engine has to be run in during the first 1 500 kilometres.

Up to 1 000 kilometres

- Do not drive faster than 3/4 of the maximum speed of the gear in use, i.e. 3/4 of the maximum permissible engine speed.
- No full throttle.
- Avoid high engine speeds.
- Do not tow a trailer.

From 1 000 up to 1 500 kilometres

- **Gradually** increase the power output of the engine up to the full speed of the gear engaged, i.e. up to the maximum permissible engine speed.

During the first operating hours the engine has higher internal friction than later until all of the moving parts have harmonized. The driving style which you adopt during the first approx. 1 500 kilometres plays a decisive part in the success of running in your car.

Never drive at unnecessarily **high engine speeds** even after the running-in period is complete. The maximum permissible engine speed is marked by the start of the red scale area of the revolutions counter. On vehicles fitted with a manual gearbox, at the very latest shift up into the next gear when the red area is reached. During acceleration (depressing the accelerator) **exceptionally** high engine speeds are automatically reduced, yet the engine is not protected against too high engine speeds which are caused by incorrectly shifting down the gears resulting in a sudden increase of the engine speeds above the permitted maximum revolutions which can lead to engine damage.

For a vehicle fitted with a manual gearbox the converse situation also applies: Do not drive at an engine speed that is too **low**. Shift down a gear when the engine is no longer running smoothly. Observe the recommended gear » [page 11](#), *Recommended gear*.

CAUTION

All the speed and engine revolution figures apply only when the engine is at its normal operating temperature. Never rev up a cold engine when the vehicle is stationary or when driving in individual gears.



For the sake of the environment

Not driving at unnecessarily high engine revolutions and shifting to a higher gear as early as possible are ways to minimise fuel consumption and operating noise levels and protects the environment.

New tyres

New tyres have to be "run in" since they do not offer optimal grip at first. Drive especially carefully for the first 500 km or so.

New brake pads

New brake pads initially do not provide full braking efficiency. The brake pads must initially be "run in". Drive especially carefully for the first 200 km or so.

Catalytic converter

Proper operation of the emission control system (catalytic converter) is of major significance for driving your vehicle in an environmentally conscious way.

The following guidelines must be observed:

- Vehicles fitted with a petrol engine must always be refueled with unleaded petrol » [page 137](#), *Unleaded petrol*;
- Do not pour too much oil into the engine » [page 141](#), *Checking the engine oil level*;
- Do not switch off the ignition while driving.

If you drive your vehicle in a country in which unleaded petrol is not available, you must have the catalytic converter replaced later when driving the vehicle into a country in which use of a catalytic converter is mandatory.

! WARNING

- In view of the high temperatures which can be produced in the catalytic converter, the vehicle should be parked in such a way that the catalytic converter cannot come into contact with easily flammable materials under the vehicle - risk of fire!
- Never use additional underbody protection or anti-corrosion agents for exhaust pipes, catalytic converters or heat shields - risk of fire!

! CAUTION

- Never drive until the fuel tank is completely empty! The irregular supply of fuel can cause misfiring, which can result in considerable damage to parts of the engine and exhaust system.
- Just filling the tank with leaded petrol once will damage the exhaust system!

Economical and environmentally friendly driving

Introductory information

Your fuel consumption, any pollution of the environmental and the wear-and-tear to the engine, brakes and tyres, depend essentially on three factors:

- your personal style of driving;
- the conditions under which your vehicle is operated;
- technical aspects.

The fuel economy can be improved by 10 -15 % by always looking ahead and driving in an economical way.

Fuel consumption is also influenced by external factors which are beyond the driver's control. Consumption increases during the winter or under difficult conditions, on poor roads, etc.

Fuel consumption can vary considerably from the manufacturer's data, as a result of outside temperatures, the weather and driving style.

The technical requirements for low fuel usage and economic efficiency of the vehicle have already been built into the vehicle at the works. ŠKODA places a particular emphasis on minimising negative effects on the environment. It is necessary to take note of the guidelines given in this chapter in order to make best use of these characteristics and to maintain their effectiveness.

The optimal engine speed should be obtained when accelerating, in order to avoid a high fuel consumption and resonance of the vehicle.

Looking ahead when driving

A vehicle's highest fuel consumption occurs when accelerating, therefore unnecessary accelerating and braking should be avoided. If looking ahead when driving, less braking and consequently less accelerating are required. If possible, let your vehicle coast to a stop, or use the engine brake, if you can see that the next set of traffic lights is on red, for example.

Shifting to save energy




Fig. 111
Principle sketch: Fuel consumption in litres/100 km depending on the selected gear

Shifting up early saves on fuel.

Manual gearbox

- Drive no more than about one length of your vehicle in first gear.
- Shift up into the next gear at approx. 2 000 revolutions.

An effective way of achieving good fuel economy is to shift up **early**. Observe the recommended gear » [page 11, Recommended gear](#).

A suitably selected gear can have an effect on fuel consumption » [Fig. 111](#).

Automatic gearbox

- **Slowly** apply the accelerator pedal. However, do not depress it to the kickdown position.
- If the accelerator pedal is only depressed slowly on a vehicle fitted with an automatic gearbox, an economic driving programme is automatically selected. ▶

i Note

Observe the recommended gear » [page 11, Recommended gear.](#)

Avoiding full throttle




Fig. 112
Principle sketch: Fuel consumption in litres/100 km. and speed in km/h.

Driving more slowly means saving fuel.

Sensitive use of the accelerator will not only significantly reduce fuel consumption but also positively influence environmental pollution and wear of your vehicle.

The maximum speed of your vehicle should, as far possible, never be used. Fuel consumption, pollutant emissions and vehicle noises increase disproportionately at high speeds.

The » [Fig. 112](#) shows the ratio of fuel consumption to the speed of your vehicle. Fuel consumption will be halved if only three-quarters of the possible top speed of your vehicle is used.

Reducing idling

Idling also costs fuel.

In vehicles not equipped with the START-STOP system, turn off the engine when in a traffic jam, at a level crossing or traffic lights with longer wait times. Even after just 30 - 40 seconds you will have saved more fuel than that is needed when you start the engine up again.

If an engine is only idling it takes much longer for it to reach its normal operating temperature. Wear-and-tear and pollutant emissions, though, are particularly high in the warming-up phase. Therefore, start driving as soon as the engine has started, whereby high engine speeds should be avoided.

Regular servicing

A poorly tuned engine uses an unnecessarily high amount of fuel.

By having your vehicle regularly maintained by a ŠKODA specialist garage, you create the conditions needed for driving economically. The maintenance state of your vehicle has a positive effect on traffic safety and value retention

A poorly tuned engine can result in a fuel consumption which is 10 % higher than normal.

Also check the **oil level** when refuelling. **Oil consumption** is dependent to a considerable extent on the load and speed of the engine. Oil consumption could be as high as 0.5 litres/1 000 km depending on your style of driving.

It is quite normal that a new engine has a higher oil consumption at first, and reaches its lowest level only after a certain running in time. The oil consumption of a new vehicle can therefore only be correctly assessed after driving about 5 000 km.



For the sake of the environment

- Additional improvements to the fuel economy can be made by using synthetic high-lubricity oils.
- Regularly check the ground under the vehicle. Have your vehicle inspected by a ŠKODA specialist garage if you find any stains caused by oil or other fluids on the floor.

i Note

We recommend that your vehicle is serviced on a regular basis by a ŠKODA Service Partner.

Avoid short distances




Fig. 113
Principle sketch: Fuel consumption in l/100 km at different temperatures

Short distances result in an above-average high fuel consumption. We therefore recommend avoiding distances of less than 4 km if the engine is cold.

A cold engine consumes the most fuel immediately after the start. Fuel consumption drops to 10 litres/100 km after just 1 kilometre. The consumption stabilises once the engine and catalytic converter have reached their operating temperature.

An important factor in this connection is also the **ambient temperature**. The image » Fig. 113 shows the different levels of fuel consumption after driving a certain distance at a temperature of +20 °C and a temperature of -10 °C. Your vehicle has a higher fuel consumption in the winter than in the summer.

Checking tyre inflation pressures

Tyres which are correctly inflated save fuel.

Always ensure the tyre inflation pressure is correct. The rolling resistance will be increased if the tyre filling pressure is too low. This will not only increase fuel consumption but also tyre wear and the driving behaviour will worsen.

Always check the tyre inflation pressure when the tyres are **cold**.

Avoid unnecessary ballast

Transporting ballast costs fuel.

Each kilogramme of **weight** increases the fuel consumption. It is worth checking the boot to avoid transporting any unnecessary ballast.

It is particularly in town traffic, when one is accelerating quite often, that the vehicle weight will have a significant effect upon the fuel consumption. A rule of thumb here is that an increase in weight of 100 kilograms will cause an increase in fuel consumption of about 1 litre/100 kilometres.

At a speed of 100 - 120 km/h, a vehicle fitted with a roof rack cross member without a load will use about 10 % more fuel than normal due to the increased aerodynamic drag.

Saving electricity

When the engine is running, the alternator generates and supplies electrical power. If more electrical components of the electrical system are switched on, more fuel is needed to operate the alternator. We therefore recommend switching off electrical components if these are no longer required.

Environmental compatibility

Environmental protection has played a major role in the design, selection of materials and manufacture of your new ŠKODA. Particular emphasis has been placed on the following points:

Design measures

- › Joints designed to be easily detached.
- › Simplified disassembly due to the modular structure system.
- › Improved purity of different classes of materials.
- › Identification of all plastic parts in accordance with VDA Recommendation 260.
- › Reduced fuel consumption and exhaust emission CO₂.
- › Minimum fuel leakage during accidents.
- › Reduced noise.

Choice of materials

- › Extensive use of recyclable material.
- › Air conditioning filled with CFC-free refrigerant.
- › No cadmium.
- › No asbestos.
- › Reduction in the "vaporisation" of plastics.

Manufacture

- › Solvent-free cavity protection.
- › Solvent-free protection of the vehicle for transportation from the production plant to the customer.

- › The use of solvent-free adhesives.
- › No CFCs used in the production process.
- › Without use of mercury.
- › Use of water-soluble paints.

Trade-in and recycling of old cars

ŠKODA meets the requirements of the brand and its products with regard to protecting the environment and the preserving resources. All new ŠKODA vehicles can be utilized up to 95 % and always ¹⁾ be returned. In a lot of countries sufficient trade-in networks have been created, where you can trade-in your vehicle. After you trade-in your vehicle, you will receive a confirmation stating the recycling in accordance with environmental regulations.

i Note

Detailed information about the trade-in and recycling of old cars is available from a ŠKODA Service Partner.

Driving abroad

Introductory information

In certain countries it is also possible that the ŠKODA Service Partner network is limited or has not been established yet. This is the reason why procuring certain spare parts may be somewhat complicated and specialist garages may only be able to make limited repairs. ŠKODA in the Czech Republic and its importers are happy to provide information about technical aspects of the vehicle, required maintenance work and possibilities for getting repairs done.

Unleaded petrol

A vehicle fitted with a petrol engine must always be refuelled with unleaded petrol » [page 137](#), *Unleaded petrol*. Information regarding the locations of filling stations that offer unleaded petrol is, for example, provided by the automobile associations.

Headlights

The low beam of your headlights is set asymmetrically. It illuminates the side of the road on which the vehicle is being driven to a greater extent.

When driving in countries in which the traffic drives on the other side of the road than in your home country, the asymmetrical low beam may dazzle oncoming drivers. To prevent oncoming traffic from being dazzled, the headlights must be adjusted by a ŠKODA Service Partner.

i Note

Further information on adjusting the headlights is available from a ŠKODA Service Partner.

Avoiding damage to your vehicle

To prevent damage to your vehicle, pay special attention:

- › When driving on poorly maintained roads and lanes
- › When driving over kerb stones
- › When driving up steep ramps
- › So that any low-slung parts, such as the spoiler and exhaust, do not touch the ground and get damaged

This particularly applies to models with a sport suspension and also when your vehicle is fully laden.

¹⁾ Subject to fulfilment of the national legal requirements.

Driving through water on the street




Fig. 114
Driving through water

The following must be observed to avoid damage to the vehicle when driving through bodies of water (e.g. flooded roads):

- Therefore determine the depth of the water before driving through bodies of water. The water level must fit around the strut on the side member as a maximum » Fig. 114;
- Do not drive any faster than at a walking speed. At a higher speed, a water wave can form in front of the vehicle which can cause water to penetrate into the air induction system of the engine or into other parts of the vehicle;
- Never stop in the water, do not reverse and do not switch the engine off;
- Deactivate the START-STOP system before driving through water » page 88, START/STOP.

! WARNING

- Driving through water, mud, sludge etc. can reduce the braking power and extend the braking distance - risk of accident!
- Avoid abrupt and sudden braking immediately after water crossings.
- After driving through bodies of water, the brakes must be cleaned and dried as soon as possible by intermittent braking. Only apply the brakes for the purpose of drying and cleaning the brake discs if the traffic conditions permit this. Do not place any other road users in jeopardy.

! CAUTION

- When driving through bodies of water, parts of the vehicle such as the engine, gearbox, chassis or electrics can be severely damaged.
- Oncoming vehicles can generate water waves which can exceed the permissible water level for your vehicle.

- Potholes, mud or rocks can be hidden under the water making it difficult or impossible to drive through the body of water.
- Do not drive through salt water. The salt can lead to corrosion. Any vehicle parts that have come into contact with salt water must be rinsed immediately with fresh water.

i Note

After driving through a body of water, we recommend that the vehicle is checked by a ŠKODA specialist garage.

Towing a trailer

Towing a trailer

Technical requirements

If your vehicle has already been factory-fitted with a towing device or is fitted with a towing device from ŠKODA Original Accessories, then it meets all of the technical requirements and national legal provisions for towing a trailer.

On vehicles with a towing device, the ball rod is detachable and is stowed together with separate operating instructions in the spare wheel well or in the compartment for the spare wheel within the boot » [page 158](#), *Vehicle tool kit*.

Your vehicle is fitted with a 13-pin power socket for the electrical connection between the vehicle and trailer. If the trailer that is to be towed has a **7-pin connector**, you can use a suitable adapter from ŠKODA Original Accessories.

If a towing device is retrofitted, it must be completed in accordance with the manufacturer's specifications.

Note

If you have any questions, please contact a ŠKODA Service Partner.

Loading a trailer

Loading a trailer

The vehicle/trailer combination must be balanced, whereby the maximum permissible drawbar load must be utilised. If the drawbar load is too low, it jeopardises the performance of the vehicle/trailer combination.

Distribution of the load

Distribute the load in the trailer in such a way that heavy items are located as close to the axle as possible. Secure the items from slipping.

The distribution of the weight is very poor if your vehicle is unladen and the trailer is laden. Maintain a particularly low speed if you cannot avoid driving with this combination.

Tyre pressure

Correct the tyre inflation pressure on your vehicle for a "full load" » [page 151](#), *Service life of tyres*.

Trailer load

The permissible trailer load must not be exceeded under any circumstances » [page 177](#), *Technical data*.

The trailer loads specified apply only to **altitudes** up to 1 000 metres above mean sea level. As the engine output drops at an increasing altitude due to the declining air pressure and therefore the climbing ability is also reduced, this means that the maximum permissible towed weight must be reduced by 10 % for every further increase of 1 000 m in height. The towed weight comprises the actual weight of the (loaded) towing vehicle and the (loaded) trailer. Always drive particularly carefully with the trailer.

The trailer and drawbar load information on the type plate of the towing device are merely test data for the towing device. The vehicle-specific values are detailed in the vehicle documents.

WARNING

- If the maximum permissible axle and drawbar load and the maximum permissible total or towed weight of the vehicle and the trailer are exceeded this can cause accidents and serious injuries.
- Slipping loads can significantly affect the stability and safety of the vehicle/trailer combination, causing accidents and serious injuries.

Towing a trailer

Exterior mirrors

You have to have additional exterior mirrors fitted if you are not able to see the traffic behind the trailer with the standard rear-view mirrors. The national legal requirements must be observed.

Headlights

The headlight settings must be checked before starting a journey with a coupled trailer. If necessary, adjust the settings with the headlight beam adjustment » [page 41](#), *Headlight beam adjustment*.

Driving speed

For safety reasons, do not drive faster than the maximum permissible speed indicated on the trailer.

Immediately reduce your speed as soon as even the slightest swaying of the trailer is detected. Never attempt to stop the trailer from "swaying" by accelerating.

Brakes

Apply the brakes in good time! If the trailer is fitted with a **trailer brake**, apply the brakes gently at first, then brake firmly. This will avoid brake jolts resulting from the trailer wheels locking. On downhill sections shift down a gear in good time to also use the engine as a brake.


Trailer is connected to the anti-theft alarm system.



- If the vehicle is factory-fitted with an anti-theft alarm system and a towing device.
- If the trailer is electrically connected to the towing vehicle by means of the trailer socket.
- If the electrical system of the vehicle and trailer is fully functional.
- If the vehicle is locked with the car key and the anti-theft alarm system is activated.

When the vehicle is locked, the alarm is activated as soon as the electrical connection to the trailer is interrupted.

Always deactivate the anti-theft alarm system before a trailer is connected/disconnected. Otherwise, the anti-theft alarm system could accidentally be triggered » [page 31](#), *Anti-theft alarm system*.

Engine overheating

If the needle for the coolant temperature gauge moves into the right-hand area or the red area of the scale, the speed must be reduced immediately. Stop and switch off the engine if the warning light  in the instrument cluster starts to flash. Wait a few minutes and check the level of coolant in the coolant expansion bottle » [page 143](#), *Checking the coolant level*.

The following guidelines must be observed » [page 19](#), *Coolant temperature/coolant level*  .

The coolant temperature can be reduced by switching on the heating.

WARNING

- Adapt your speed to the conditions of the road surface and to the traffic situation.
- Improper or incorrectly connected electric cables can energise the trailer and cause functional faults to the vehicle's entire electrical system as well as accidents and severe injuries.
- Any work on the electrical system must be carried out only by ŠKODA specialist garages.
- Never directly connect the trailer's electrical system with the electrical connections for the tail lights or other current sources.

CAUTION

- Avoid abrupt and sudden driving/braking manoeuvres.
- When the ball rod is removed, the mounting shaft must be sealed with an appropriate cover. This prevents foreign matter from penetrating into the mounting shaft. See the fitting instructions for the towing device.

Note

- We recommend that you also have your vehicle inspected between service intervals if you tow a trailer frequently.
- The handbrake on the towing vehicle must be put on when coupling and decoupling the trailer.
- For technical reasons, trailers with rear LED lights cannot be connected to the anti-theft alarm system. ■

General Maintenance

Taking care of and cleaning the vehicle

Taking care of your vehicle

Introduction

This chapter contains information on the following subjects:

Washing the vehicle	130
Automatic car wash systems	130
Washing by hand	130
Washing with a high-pressure cleaner	130
Preserving and polishing the vehicle paintwork	131
Chrome parts	131
Paint damage	131
Plastic parts	131
De-icing windows and exterior mirrors	132
Radio reception and aerial	132
Headlight lenses	132
Rubber seals	132
Door lock cylinders	132
Wheels	133
Underbody protection	133
Protection of hollow spaces	133
Artificial leather and materials	134
Fabric covers on electrically heated seats	134
Natural leather	134
Seat belts	135

Regular and proper care help to retain the efficiency and **value** of your vehicle. It may also be one of the requirements for the acceptance of warranty claims relating to corrosion damage and paint defects on the bodywork.

We recommend using care products from ŠKODA Original Accessories that are available from ŠKODA Service Partners. The instructions for use on the package must be observed.

WARNING

- Care products may be harmful to your health if not used according to the instructions.
- Always store care products in a safe place, out of the reach of children - risk of poisoning!
- When washing your vehicle in the winter: Water and ice in the brake system can affect the braking efficiency - risk of accident!
- Only wash the vehicle when the ignition is switched off - risk of accident!
- Protect your hands and arms from sharp-edged metal parts when cleaning the underfloor, the inside of the wheel housings or the wheel trims - risk of cuts!
- Air fresheners and scents can be hazardous to health when the temperature inside the vehicle is high.

CAUTION

- Be sure to check clothing for colourfastness to avoid any damage or visible stains on the material (leather), panels and textiles.
- Cleaners containing solvents can damage the material being cleaned.
- Do not wash your vehicle in bright sunlight - risk of paint damage.
- If washing the vehicle in the winter using a hose or high-pressure cleaner, ensure that the jet of water is not aimed directly at the locking cylinders or the door/panel joints - risk of freezing!
- Do not use any insect sponges, rough kitchen sponges or similar cleaning products - risk of damaging the surface of paintwork.
- Do not stick any stickers on the inside of the rear windows, the rear side windows and in the vicinity of the heating elements on the windscreen or near the window aerial. These may get damaged. With regard to the antenna, they may interfere with the radio or navigation system.
- Do not clean the inside of the windows with sharp-edged objects or corrosive and acidic cleaning agents - risk of damaging the heating elements or window aerial.
- Do not attach scents and air fresheners to the dashboard - risk of damage to the dashboard.
- To avoid damaging the parking aid sensors while cleaning with high-pressure cleaners or steam jets, the sensors must only be directly sprayed for short periods while a minimum distance of 10 cm must be observed.
- Do not clean the roof trim with a brush - risk of damage to the trim surface. ►



For the sake of the environment

- Used cans of vehicle care products represent a special type of hazardous waste. These must be disposed of in accordance with national legal regulations.
- Only wash the vehicle at washing bays intended for this purpose.




Note

- Remove fresh stains such as those from ball-point pens, ink, lipstick, shoe polish, etc., from the material (leather), panels and textiles as quickly as possible.
- Due to possible issues with the cleaning and care of the interior of your vehicle, the special tools and knowledge required, we recommend that this is completed by a ŠKODA Service Partner.

Washing the vehicle



First read and observe the introductory information and safety warnings  on page 129.

The best protection for your vehicle against harmful environmental influences is **frequent** washing and wax treatment. How often the vehicle should be washed depends on a wide range of factors, such as:

- Frequency of use;
- The parking situation (garage, below trees etc.);
- Season of the year;
- Weather conditions;
- Environmental influences.

The longer insect residues, bird droppings, tree sap, road and industrial dust, tar, soot particles, road salt and other aggressive deposits remain adhering to the paintwork of your vehicle, the more detrimental their destructive effect can be. High temperatures, such as those caused by intensive sun's rays, accentuate this caustic effect.

It is essential to also thoroughly clean the **underside of the vehicle** at the end of the winter.

Automatic car wash systems



First read and observe the introductory information and safety warnings  on page 129.

Your vehicle can be washed in automatic car wash systems.


The usual precautionary measures must be taken before washing the vehicle in an automatic car wash system (closing the windows including the sliding/tilting roof, etc.).

If your vehicle is fitted with any particular attached parts, such as a spoiler, roof luggage rack, two-way radio aerial - it is best to consult the operator of the car wash system beforehand.

It is important to degrease the lips of the windscreen wiper rubbers after passing through the automatic vehicle wash system.

Washing by hand



First read and observe the introductory information and safety warnings  on page 129.

When washing by hand, first soften the dirt with plenty of water and rinse off as much as possible.

Clean the vehicle with a soft **sponge**, a **washing glove** or a **washing brush**. Work from the top to the bottom - starting with the roof. Only apply slight pressure when cleaning the vehicle's paintwork. Only use a **car shampoo** for stubborn dirt.


Wash out the sponge or washing glove thoroughly at short intervals.

Clean wheels, door sills and similar parts last. Use a second sponge for such areas.

Give the vehicle a good rinse after washing it and dry it off using a chamois leather.

Washing with a high-pressure cleaner



First read and observe the introductory information and safety warnings  on page 129.

When washing the vehicle with a high-pressure cleaner, the instructions for use of the equipment must be observed. This applies in particular to the **pressure** used and to the **spraying distance**. Maintain a sufficiently large distance to the parking aid sensors and soft materials such as rubber hoses or insulation material.

WARNING


Never use circular spray nozzles or dirt cutters!

CAUTION

The temperature of the water used for cleaning must not exceed 60 °C - risk of damaging the vehicle.

Preserving and polishing the vehicle paintwork



First read and observe the introductory information and safety warnings  on page 129.

Preserving the vehicle paintwork

Good wax treatment is an effective way of protecting the paintwork from harmful environmental influences.

The vehicle must be treated with a high-quality hard wax polish at the latest, when no more drops form on the clean paintwork.

A new layer of a high-quality hard wax polish can be applied to the clean bodywork after it has dried thoroughly. Even if you use a wax preserver regularly we still recommend that you treat the paintwork of the vehicle at least twice a year with hard wax.

Polishing

Polishing is necessary if the vehicle's paintwork has become unattractive and if it is no longer possible to achieve a gloss with wax preservatives.


If the polish does not contain any preserving elements, the paint must be treated with a preservative afterwards.

CAUTION

- Never apply wax to the windows.
- Mat painted or plastic parts must not be treated with polishing products or hard waxes.
- Do not polish the paintwork of the vehicle in a dusty environment, otherwise the paintwork can be scratched.

Chrome parts



First read and observe the introductory information and safety warnings  on page 129.

First clean the chrome parts with a damp cloth and then polish them with a soft, dry cloth. If this method does not completely clean chrome parts, use a specific chrome care product.




CAUTION

Do not polish the chrome parts in a dusty environment, otherwise they can be scratched.

Paint damage



First read and observe the introductory information and safety warnings  on page 129.

Slight damage to paintwork such as scratches, scuffs or traces of chip damage must be treated immediately.

The ŠKODA Service Partners have a range of matching **touch-up pens** or **spray cans** available in the colour of your vehicle.




Note

We recommend that any repairs to damaged paintwork are carried out by a ŠKODA Service Partner.

Plastic parts



First read and observe the introductory information and safety warnings  on page 129.

Plastic parts can be cleaned using a damp cloth. If this does not prove to be adequate, the parts can be treated with **special solvent-free plastic cleaning products**.

Paint care products are not suitable for plastic parts.

De-icing windows and exterior mirrors



First read and observe the introductory information and safety warnings  on page 129.

Use a plastic ice scraper for removing snow and ice from the windows and mirrors. The ice scraper should not be moved forward and backward but in one direction to avoid any damage to the surface of the glass.

Clean the windows from the inside on a regular basis.

Dry the glass surfaces with a clean chamois leather or a cloth intended for this purpose.

When drying the windows after washing the vehicle, do not use window leathers that have been used to polish the bodywork. Residues of preservatives in the window leather can dirty the window and reduce visibility.



CAUTION

- Never remove snow or ice from glass parts using warm or hot water - risk of formation of cracks in the glass!
- When removing snow or ice from windows and mirror lenses ensure that the paintwork of the vehicle is not damaged.
- Snow or ice that is contaminated with coarse dirt such as fine gravel, sand, and salt must not be removed from the window glass and mirrors - risk of damage to the surface of the windows and mirrors.

Radio reception and aerial



First read and observe the introductory information and safety warnings  on page 129.

Car parks, tunnels, tall buildings or mountains can disrupt the radio signal even causing it to fail completely.

With factory-fitted radios and navigation systems, the aerial for the radio reception can be installed at different locations in the vehicle:

- on the inside of the rear window along with the rear window heater;
- on the inside of the rear side windows;
- on the inside of the windscreen;
- on the roof.

Headlight lenses



First read and observe the introductory information and safety warnings  on page 129.

Use soap and clean water to clean the plastic headlight lenses.



CAUTION

- Never wipe the headlights dry and do not use any sharp objects to clean the plastic lenses, this may damage the protective paintwork and consequently cause the formation of cracks on the headlight lenses.
- Do not use any aggressive cleaning or chemical solvent products to clean the headlights - risk of damaging the headlight lenses.

Rubber seals



First read and observe the introductory information and safety warnings  on page 129.

The rubber seals on doors, the sliding roof and other windows remain smoother and last longer if the seals are treated regularly with a suitable rubber care product. This helps to prevent leakages and premature wear of the seals. Rubber seals which are well cared for also do not stick together in cold winter weather.

Door lock cylinders



First read and observe the introductory information and safety warnings  on page 129.

Specific products must be used for de-icing door lock cylinders.



Note

- When washing your vehicle, ensure as little water as possible gets into the locking cylinders.
- We recommend that suitable materials from ŠKODA Original Accessories are used for maintaining the door lock cylinders.

Wheels



First read and observe the introductory information and safety warnings  on page 129.

Wheel rims

Also thoroughly wash the wheel rims when washing the vehicle on a regular basis. Regularly remove salt and brake abrasion from the wheel rims otherwise the material will be affected. Damage to the paint layer on the wheel rims must be touched up immediately.

Light alloy wheels

After washing thoroughly and treat the wheel rims with a protective product for light alloy wheels. Products which cause abrasion must not be used to treat the wheel rims.

WARNING

Water, ice and grit in the brake system can affect the braking efficiency - risk of accident!

CAUTION

Severe layers of dirt on the wheels can also result in wheel imbalance. This may show itself in the form of a wheel vibration which is transmitted to the steering wheel which, in certain circumstances, can cause premature wear of the steering. This means it is necessary to remove the dirt.

Note

We recommend that any repairs to damaged paintwork are carried out by a ŠKODA Service Partner.

Underbody protection



First read and observe the introductory information and safety warnings  on page 129.

The underside of your vehicle is protected for life against chemical and mechanical influences.

As damage to the **protective layer** when driving cannot be ruled out completely, we recommend that you inspect the protective layer on the underside of your vehicle and on the chassis at specific intervals - preferably at the beginning and end of the winter.

ŠKODA Service Partners have suitable **spray products** and the necessary equipment available, and are familiar with the instructions for use. We therefore recommend that touch-up work or additional corrosion protection measures are carried out by a ŠKODA Service Partner.

WARNING

Never use additional underbody protection or anti-corrosion agents for exhaust pipes, catalytic converters, diesel particle filters or heat shields. When the engine reaches its operating temperature, these substances might ignite - risk of fire!

Protection of hollow spaces



First read and observe the introductory information and safety warnings  on page 129.

All the cavities of your vehicle which are at risk from corrosion are protected for life by a layer of **protective wax** applied in the factory.

This wax protection does not require to be inspected or re-treated. If any small amount of wax flow out of the cavities at high temperatures, these must be removed with a plastic scraper and the stains cleaned using a petroleum cleaner.

WARNING

Safety regulations should be observed when using petroleum cleaner to remove wax - risk of fire!

Artificial leather and materials



First read and observe the introductory information and safety warnings **I** on page 129.

The artificial leather can be cleaned using a damp cloth. If this does not prove to be adequate, these parts can only be treated with special **solvent-free plastic cleaning and care products**.

Clean upholstery cover materials and cloth trims on doors, boot cover, etc. using specific cleaning agents, e.g., dry foam. Use a soft sponge, brush, or commercially available microfibre cloth. Use a cloth and a specific cleaning agent to clean the roof trim.

Some clothing materials, such as dark denim, do, in part, not have sufficient colour fastness. This can cause damage or clearly visible discolouration to seat covers (fabric or leather) even when used correctly. This particularly applies to light seat covers (fabric or leather). This is not a defect in the seat cover, but poor colour fastness of the clothing textiles.

Fabric covers on electrically heated seats



First read and observe the introductory information and safety warnings **I** on page 129.

Do not clean the seat covers **using moisture** as this can damage the seat heating system.

Use a specific cleaning agent such as dry foam or similar to clean the covers.

Natural leather



First read and observe the introductory information and safety warnings **I** on page 129.

Depending on the amount of wear-and-tear, the leather should be cleaned on a regular basis.

Normal cleaning

Clean soiled areas of the leather with slightly moistened cotton or woollen cloth.

Severe soiling

Ensure that the leather is not soaked through at any point and that no water gets into the stitching of the seams.

Dry off the leather with a soft, dry cloth.

Removing stains

Remove fresh **water-based** stains (e.g., coffee, tea, juices, blood) with an absorbent cloth or household cleaning paper. A specific cleaning agent is required for dried-on stains.

Remove fresh **grease-based** stains (e.g. butter, mayonnaise, chocolate, etc.) with an absorbent cloth, household cleaning paper, or use a suitable cleaner if the stain has not yet penetrated into the surface.

Use a grease solvent for **grease stains which have dried in**.

Remove **specific stains** (e.g. ball-point pens, marker pen, nail varnish, dispersion paint, shoe polish, etc.) with a special stain remover suitable for leather.

Leather care

Treat the leather roughly every six months with a suitable leather care product.

Apply only a small amount of the cleaning and care product.

Dry off the leather with a soft, dry cloth.

! CAUTION

- Avoid leaving the vehicle for lengthy periods in bright sunlight to avoid the leather from bleaching. If the vehicle is parked in the open for lengthy periods, protect the leather from direct sunlight by covering it.
- Sharp-edged objects on items of clothing such as zip fasteners, rivets, sharp-edged belts, jewellery and pendants may leave permanent scratches or signs of rubbing on the surface.
- The use of a mechanical steering wheel lock may damage the leather surface of the steering wheel.

i Note

- Use a care cream with light blocker and impregnation effect on a regular basis and each time after cleaning. The cream nourishes the leather, allows it to breathe and keeps it supple and also provides moisture. It also creates surface protection.
- Clean the leather every 2 to 3 months, remove any fresh stains as they occur. ▶

- Also look after the leather dye. Refresh any areas with a special coloured leather cream as required.
- The leather is a natural material with specific properties. During the use of the vehicle, minor optical changes can occur on the leather parts of the covers (e. g wrinkles or creases as a result of the stress of the covers).

Seat belts



First read and observe the introductory information and safety warnings  on page 129.

Keep the seat belts clean!

Clean dirty seat belts using a mild soapy solution and remove coarse dirt with a soft brush!

Check the condition of all the seat belts on a regular basis.

Belt webbing which has become severely soiled may prevent the inertia reel from reeling up the belt properly.

WARNING

- The seat belts must not be removed for cleaning.
- Never clean the seat belts chemically as chemical cleaning products could destroy the fabric. The seat belts must also not be allowed to come into contact with corrosive liquids (such as acids etc.).
- Seat belts which have damage to the webbing, connections, inertia reel or lock should be replaced by a ŠKODA specialist garage.
- Inertia reel belts must be completely dried before being reeled up.

Inspecting and replenishing

Fuel

Introduction

This chapter contains information on the following subjects:

Refuelling	136
Unleaded petrol	137
Diesel fuel	138

The correct type of fuel for your vehicle and the tyre size and inflation pressure are specified on the inside of the fuel filler flap » Fig. 115 on page 136 - [B].

! WARNING

The national legal requirements must be observed if carrying a spare canister in the vehicle. We do not recommend carrying any fuel canisters in your vehicle for safety reasons. In the event of an accident, the canister might be damaged and fuel may leak out - risk of fire!

! CAUTION

- Never drive until the fuel tank is completely empty! The irregular supply of fuel can cause misfiring, which can result in considerable damage to parts of the engine and exhaust system.
- Immediately remove any fuel that has spilled onto the vehicle's paintwork - risk of paint damage!

Refuelling




Fig. 115 Right rear side of the vehicle: Fuel filler flap/fuel filler flap with cap unscrewed

! First read and observe the introductory information and safety warnings ! on page 136.

Open fuel filler flap

- Open the fuel filler flap with one hand » Fig. 115 - [A].
- Hold the fuel filler cap on the fuel filler tube with one hand and unlock it by moving it to the left with the vehicle key.
- Unscrew the filler cap by turning it to the left and place the cap onto the top of the fuel filler flap » Fig. 115 - [B].

Closing the filler cap

- Turn the filler cap to the right until it clicks into place.
- Hold the fuel filler cap on the fuel filler tube with one hand and lock it by turning the vehicle key to the right and remove the key.
- Close the filler cap.

! CAUTION

- Before refuelling it is necessary to switch off the auxiliary heating system (auxiliary heating and ventilation).
- The fuel tank is full just as soon as the pump nozzle switches off for the first time, provided the nozzle has been operated properly. Do not continue filling the fuel tank otherwise the expansion volume is filled up. ▶

Note

The fuel tank has a capacity of about **45 litres**, containing a reserve of approx. **7 litres**.

Unleaded petrol



First read and observe the introductory information and safety warnings  on page 136.

Your vehicle can only be operated with **unleaded fuel** that complies with the standard **EN 228** (in Germany: **standard DIN 51626-1** or **E10** for unleaded fuel with an octane rating of **95 RON** and **91 RON** or **DIN 51626-2** or **E5** for unleaded fuel with the octane rating **95 RON** and **98 RON**).

Prescribed fuel - unleaded fuel 95/91 RON

Use unleaded fuel with the octane rating **95 RON**. Unleaded petrol **91 RON** can also be used but results in a slight loss in performance.

If, in an emergency, the vehicle has to be refuelled with petrol of a lower octane number than the one prescribed, the journey must only be continued at medium engine speeds and a low engine load. Driving at high engine revs or a high engine load can severely damage the engine! Refuel using petrol of the prescribed octane number as soon as possible.

Prescribed fuel - unleaded petrol min. 95 RON

Use unleaded fuel with the octane rating **95 RON**.

In case of necessity, you can refuel with petrol with the octane rating **91 RON** if petrol with the octane rating **95 RON** is not available. The journey must only be continued at medium engine speeds and a minimum engine load. Driving at high engine revs or a high engine load can severely damage the engine! Refuel using petrol of the prescribed octane number as soon as possible.

Even in the event of an emergency, petrol of a lower octane number than **91 RON** must not be used, otherwise the engine can be severely damaged!

Unleaded petrol with higher octane number

Unleaded petrol that has a higher octane number than that required by the engine can be used without limitations.

On vehicles with prescribed unleaded petrol **95/91 RON**, the use of petrol with a higher octane number than **95 RON** does not result in a noticeable power increase or a lower fuel consumption.

On vehicles using prescribed unleaded petrol of **min. 95 RON**, the use of petrol with a higher octane number than **95 RON** can increase the power and reduce fuel consumption.

Prescribed fuel - unleaded petrol 98/(95) RON

Use unleaded fuel with the octane rating **98 RON**. Unleaded petrol **95 RON** can also be used but results in a slight loss in performance.

In case of necessity, you can refuel with petrol with the octane rating **91 RON** if unleaded fuel with octane rating **98 RON** or **95 RON** is not available. The journey must only be continued at medium engine speeds and a minimum engine load. Driving at high engine revs or a high engine load can severely damage the engine! Refuel using petrol of the prescribed octane number as soon as possible.

Even in the event of an emergency, petrol of a lower octane number than **91 RON** must not be used, otherwise the engine can be severely damaged!

Fuel additives

Only use unleaded petrol, which complies with the standard **EN 228** (in Germany: **standard DIN 51626-1** or **E10** for unleaded fuel with an octane rating of **95 RON** and **91 RON** or **DIN 51626-2** or **E5** for unleaded fuel with an octane rating of **95 RON** and **98 RON**), as these meet all of the requirements for fault-free engine operation. We therefore recommend that no fuel additives are used.



CAUTION

- All ŠKODA vehicles with petrol engines must only be operated with unleaded petrol. Just filling the tank with leaded petrol once will damage the exhaust system!
- Engine parts can be damaged if petrol with a lower octane number than the one prescribed is used.
- In no case may fuel additives with metal components be used, especially not with manganese and iron content. LRP (lead replacement petrol) fuels with metallic components may not be used. There is a risk of causing considerable damage to parts of the engine or exhaust system!
- Fuels with metallic content may not be used. There is a risk of causing considerable damage to parts of the engine or exhaust system!
- The use of unsuitable fuel additives can cause considerable damage to parts of the engine or the exhaust system.

Diesel fuel



First read and observe the introductory information and safety warnings  on page 136.

Your vehicle can only be operated with **diesel fuel**, which complies with the standard **EN 590** (standard **DIN 51628** in Germany, standard **ÖNORM C 1590** in Austria, **GOST R 52368-2005/EN 590:2004** in Russia).

Operation in winter - Winter-grade diesel fuel

In the winter, only use diesel fuel, which complies with the standard **EN 590** (standard **DIN 51628** in Germany, standard **ÖNORM C 1590** in Austria, **GOST R 52368-2005/EN 590:2004** in Russia). "Winter-grade diesel fuel" will still operate properly even at a temperature of -20 °C.

It is often the case in countries with different climatic conditions that diesel fuels available have a different temperature characteristic. The ŠKODA Service Partners and filling stations in the relevant country will be able to provide you with information regarding the diesel fuels available.

Preheating fuel

The vehicle is fitted with a fuel filter preheating system. This secures operation of a vehicle using diesel fuel down to an environmental temperature of -25 °C.

Fuel additives

Fuel additives, so-called "flow improvers" (petrol and similar products) must not be added to the diesel fuel.



CAUTION

- Just filling the tank once with diesel fuel that does not comply with the standard, can cause severe damage to parts of the engine, the fuel and exhaust system!
- If a different fuel other than diesel fuel, which complies to the above mentioned standards (e.g. petrol) is used by mistake do not start the engine or switch on the ignition! Extensive damage to engine parts can occur! We recommend that the fuel system is cleaned by a ŠKODA Service Partner.
- Water which has collected in the fuel filter can cause engine faults.
- Your vehicle is not adapted for use of biofuel (RME), therefore this fuel must not be refuelled and driven. The use of biofuel (RME) can cause considerable damage to parts of the engine or fuel system. ■

Engine compartment



Introduction

This chapter contains information on the following subjects:

Opening and closing the bonnet	140
Engine compartment overview	140
Checking the engine oil level	141
Replenishing the engine oil	141
Changing engine oil	142
Coolant	142
Checking the coolant level	143
Replenishing the coolant	143
Radiator fan	144
Checking the brake fluid	144
Changing the brake fluid	144
Windscreen washer system	145

There is a risk of injuries, scalding, accidents and fire when working in the engine compartment, e.g. inspecting and replenishing oil and other fluids. For this reason, it is essential to comply with the warning instructions stated below and with the general applicable rules of safety. The vehicle's engine compartment is a hazardous area.



WARNING

- Never open the bonnet if you can see steam or coolant flowing out of the engine compartment - risk of scalding! Wait until the steam or coolant has stopped escaping.
- Turn off the engine and withdraw the ignition key.
- If the vehicle is fitted with a manual gearbox, move the gearshift lever into Neutral, or if the vehicle is fitted with an automatic gearbox, move the selector lever into position **P**.
- Firmly apply the handbrake.
- Allow the engine to cool.
- For safety reasons, the bonnet must always be properly closed when driving. This is why after closing the bonnet, the lock must always be checked to ensure it has engaged properly. ▶

WARNING (Continued)

- If you notice that the lock is not properly engaged while driving, stop the vehicle immediately and close the bonnet - risk of an accident!
- Keep children clear of the engine compartment.
- Do not touch any hot engine parts - risk of burns!
- Never spill fluids on the hot engine. Such fluids (e.g. the antifreeze contained in the coolant) may ignite!
- Avoid short circuits in the electrical system - particularly on the vehicle's battery.
- Never touch the radiator fan while the engine is still warm. The fan might suddenly start running!
- Never open the end cover of the coolant expansion reservoir while the engine is still warm. The cooling system is pressurized!
- When opening the end cover of the coolant expansion reservoir, cover it with a cloth to protect your face, hands and arms from hot steam or hot coolant.
- Do not leave any items such as cloths or tools in the engine compartment.
- If you wish to work under the vehicle, you must secure the vehicle from rolling away and support it with suitable supporting blocks: the car jack is not sufficient for this - risk of injury!
- If any inspection work has to be carried out when the engine is running, there is an additional risk from rotating parts (e.g. V-belt, alternator, radiator fan) and the high-voltage ignition system. The following must also be observed:
 - Never touch the electric wiring on the ignition system.
 - Always make sure that no jewellery, loose clothing or long hair can get caught in rotating engine parts - hazard! Always remove any jewellery, tie back long hair and wear tight fitting clothing before completing any work.
- Additionally, the following warning instructions must be observed if work has to be carried out on the fuel or electrical system.
 - Always disconnect the vehicle battery from the electrical system.
 - Do not smoke.
 - Never work near open flames.
 - Always have a functioning fire extinguisher nearby.

CAUTION

- Always top up using the correct specification of fluids. This may result in major operating problems and also vehicle damage!
- Never open the bonnet using the locking lever - danger of causing damage.

For the sake of the environment

In view of the environmentally friendly disposal of fluids, the special tools and knowledge required for such work, we recommend that fluids are changed by a ŠKODA Service Partner as part of the inspection service.

Note

- If you have any questions regarding the fluids, visit a ŠKODA Service Partner.
- Fluids with the correct specifications can be purchased from ŠKODA Original Accessories. ■

Opening and closing the bonnet




Fig. 116 Bonnet/radiator grille release lever: Release lever




Fig. 117
Securing the bonnet with the
bonnet support



First read and observe the introductory information and safety warnings **1** on page 138.

Opening

➤ Pull the release lever under the dash panel **1** » Fig. 116.

Before opening the bonnet, ensure that the arms of the windscreen wipers are correctly in place against the windscreen otherwise the paintwork could be damaged.

- Press the release lever in the direction of the arrow **2** » Fig. 116 and the bonnet is unlocked.
- Grab hold of the bonnet and lift.
- Take the bonnet support out of its holder and secure the opened bonnet by inserting the end of the support in the opening **3** » Fig. 117 designed for it.

Closing

- Lift the bonnet slightly and unhook the bonnet support. Press the bonnet support into the holder designed to hold it.
- Let the bonnet drop into the lock carrier lock from a height of around 20 cm - do **not push it in**.
- Check that the bonnet is closed properly.

Engine compartment overview




Fig. 118 1.6 l/77 kW diesel engine



First read and observe the introductory information and safety warnings **1** on page 138.

1	Coolant expansion reservoir	_____	143
2	Windscreen washer fluid reservoir	_____	145
3	Engine oil filler opening	_____	141
4	Engine oil dipstick	_____	141
5	Brake fluid reservoir	_____	144
6	Battery (below a cover)	_____	145

i Note

The location of the inspection points in the engine compartment of petrol and diesel engines is practically identical.

Checking the engine oil level




Fig. 119
Dipstick



First read and observe the introductory information and safety warnings **!** on page 138.

The dipstick indicates the level of oil in the engine » Fig. 119.

Checking the oil level

- Ensure that the vehicle is positioned on a level surface and the engine has reached its operating temperature.
- Switch off the engine.
- Open the bonnet.
- Wait a few minutes until the engine oil flows back into the oil sump and remove the dipstick.
- Wipe the dipstick with a clean cloth and insert it again to the stop.
- Then pull the dipstick out again and check the oil level.

Oil level within range **A**

- No oil must be refilled.

Oil level within range **B**

- Oil can be refilled. It is possible that the oil level may then be within range **A** after doing this.


Oil level within range **C**

- Oil **must** be refilled. It is sufficient, once this is done, to keep the oil level within range **B**.

It is normal for the engine to consume oil. The oil consumption may be as much as 0.5 l/1 000 km depending on your style of driving and the conditions under which you operate your vehicle. Consumption may be slightly higher than this during the first 5 000 kilometres.

One should therefore check the oil level at regular intervals, preferably every time after the fuel tank is filled or after driving for long stretches.

We recommend maintaining the oil level within the range **A**, **but not above**, if the engine has been operating at high loads, for example, during a lengthy motorway trip during the summer months, towing a trailer or negotiating a high mountain pass.

The warning light in the instrument cluster will indicate whether the oil level is too low » page 19, *Engine oil* . In this case, check the oil level with the dipstick, as soon as possible. Add oil accordingly.



CAUTION

- Always check the oil level on vehicles with the 1.2 l/44 kW engine when the engine is cold. Otherwise the measuring result is incorrect and oil could be incorrectly replenished - risk of engine damage!
- The oil level must on no account extend beyond the range **A** » Fig. 119. Risk of damaging the exhaust system!
- If it is not possible to top up the engine oil under the prevailing conditions, **do not continue your journey! Switch off the engine** and obtain professional assistance from a ŠKODA specialist garage, otherwise it could cause severe engine damage.



Note

Engine oil specifications » page 179, *Specifications and engine oil capacity*.

Replenishing the engine oil



First read and observe the introductory information and safety warnings **!** on page 138.

- Check the engine oil level » page 141.
- Unscrew the cap of the engine oil filler opening.
- Replenish the oil in portions of 0.5 litres in accordance with the correct specifications » page 179, *Specifications and engine oil capacity*.
- Check the oil level » page 141.
- Carefully screw on the oil filler opening cap and push the dipstick in fully.

Changing engine oil



First read and observe the introductory information and safety warnings  on page 138.

The engine oil must be changed at the intervals stated in the Service schedule or according to the service interval indicator » [page 10, Service Interval Display](#).

CAUTION

Additives must not be added to the engine oil - risk of causing considerable damage to parts of the engine! Damage, which results from such product, are excluded from the warranty.

Note

If your skin has come into contact with oil, it must be washed thoroughly.

Coolant



First read and observe the introductory information and safety warnings  on page 138.

The cooling system is filled with a coolant in the factory.

The coolant consists of water with a concentration of coolant additive of 40 %. This mixture provides antifreeze protection down to -25 °C and also protects the cooling and heating system from corrosion. It also prevents the formation of scale and significantly increases the boiling point of the coolant.

The concentration of coolant must therefore not be reduced by adding water during the summer months or in countries with a warm climate. **The concentration of coolant additive in the coolant must be at least 40 %.**

If a higher concentration of antifreeze is required for climatic reasons, the amount of coolant additive can only be increased up to 60 % (antifreeze protection down to approx. -40 °C). The antifreeze protection tails off above that concentration.

Vehicles exported to countries with a cold climate are already factory-filled with a coolant which offers antifreeze protection down to about -35 °C. In these countries the concentration of coolant additive should be at least 50 %.

When refilling, we only recommend you use the same antifreeze written on the antifreeze expansion tank » [Fig. 120](#) on page 143.

Coolant capacity

Petrol engines	Capacities (in litres)
1.2 l/44 kW	5.5
1.2 l/51 kW	5.5
1.2 ltr./63 kW TSI	7.7
1.2 ltr./77 kW TSI	7.7
1.4 l/63 kW	5.5
1.4 ltr./132 kW TSI	6.6
1.6 l/77 kW	5.5

Diesel engines	Capacities (in litres)
1.2 ltr./55 kW TDI CR DPF	6.6
1.6 ltr./55 kW TDI CR DPF	8.4
1.6 ltr./66 kW TDI CR DPF	8.4
1.6 ltr./77 kW TDI CR DPF	8.4

CAUTION

- Other coolant additives that do not comply with the correct specifications can above all significantly reduce the anticorrosion effect.
- Any faults resulting from corrosion may cause a loss of coolant and can consequently result in major engine damage!

Note

On vehicles that are fitted with an auxiliary heater (auxiliary heating and ventilation), the coolant capacity is approx. 1 l larger.

Checking the coolant level








Fig. 120
Engine compartment: Coolant expansion reservoir

 First read and observe the introductory information and safety warnings  on page 138.

The coolant expansion bottle is located in the engine compartment.

- Switch off the engine.
- Open the bonnet » page 140.
- Check the level of coolant in the coolant expansion bottle » Fig. 120. The coolant level when the engine is cold must lie between the [B] (MIN) and [A] (MAX) markings. The level may also rise slightly above the [A] (MAX) marking when the engine is warm.

If the coolant level in the coolant expansion tank is too low, this is indicated by the warning light  lighting up in the instrument cluster » page 19, *Coolant temperature/coolant level* . We still recommend inspecting the coolant level directly at the reservoir from time to time.


Loss of coolant

A loss of coolant is first and foremost an **indication of a leak** in the system. Do not merely top up the coolant. Have the cooling system checked by a ŠKODA specialist garage immediately.

CAUTION

If a fault causes the engine to overheat, we recommend visiting a ŠKODA Service Partner immediately, otherwise serious engine damage may occur. ■

Replenishing the coolant

 First read and observe the introductory information and safety warnings  on page 138.

- Switch off the engine.
- Allow the engine to cool.
- Place a cloth over the cap of the coolant expansion reservoir » Fig. 120 on page 143 and unscrew the cap **carefully**.
- Replenish the coolant.
- Turn the cap until it clicks into place.

Do not use an alternative additive if the specified coolant is not available in an emergency. In this case, just use water and have the correct mixing ratio of water and the coolant additive restored by a ŠKODA specialist garage as soon as possible.


Only use new coolant to top up the system.

Do not fill the coolant above the mark [A] (max.) » Fig. 120 on page 143! Excess coolant heats up and then is forced out of the cooling system through the pressure relief valve in the cap.


WARNING

- The coolant additive and thus all of the coolant is harmful to your health. Avoid contact with the coolant. Coolant vapours are also harmful to health. Therefore always safely store the coolant additive in its original container out of the reach of children - risk of poisoning!
- If any coolant splashes into your eyes, immediately rinse out your eyes with clear water and contact a doctor as soon as possible.
- You should also consult a doctor without delay if you have inadvertently swallowed coolant.

CAUTION

Do not continue your journey, if it is not possible  to **top up the coolant under the prevailing conditions**. Contact a ŠKODA Service Partner to avoid the risk of serious engine damage. ■

Radiator fan

 First read and observe the introductory information and safety warnings  on page 138.

The radiator fan is driven by an electric motor and controlled according to the coolant temperature.

After switching off the ignition, the radiator fan can intermittently continue to operate for approx. 10 minutes.

Checking the brake fluid








Fig. 121
Engine compartment: Brake fluid reservoir

 First read and observe the introductory information and safety warnings  on page 138.


The brake fluid reservoir is located in the engine compartment.

- Switch off the engine.
- Open the bonnet » page 140.
- Check the level of brake fluid in the reservoir » Fig. 121. The level must be between the "MIN" and "MAX" markings.


When driving, a slight drop in the fluid level is caused by the wear-and-tear and automatic adjustment of the brake pads, and is therefore perfectly normal.

There may be an indication of a leak in the brake system, however, if the fluid level drops significantly within a short time or if it drops below the "MIN" marking. If the brake fluid level is too low, this is indicated by the warning light  lighting up in the instrument cluster » page 18, *Brake system* .

WARNING

If the fluid level has dropped below the MIN marking,  do not continue your journey - risk of accident! Seek help from a ŠKODA specialist garage.

Changing the brake fluid

 First read and observe the introductory information and safety warnings  on page 138.

Brake fluid absorbs moisture. Over time it therefore absorbs moisture from the environment. Excessive water in the brake fluid may be the cause of corrosion in the brake system. The water content also lowers the boiling point of the brake fluid.

The brake fluid must comply with the following standards or specifications:

- VW 50114;
- FMVSS 116 DOT4.

WARNING

Using old brake fluid can result in severe stress on the brakes because of the formation of vapour bubbles in the brake system. This greatly impairs the braking efficiency and thus also the safety of your vehicle.

CAUTION

Brake fluid damages the paintwork of the vehicle.

Windscreen washer system





Fig. 122
Engine compartment: Wind-
screen washer fluid reservoir

 **First read and observe the introductory information and safety warnings  on page 138.**

The windscreen washer fluid reservoir contains the cleaning fluid for the windscreen or rear window and for the headlight cleaning system. The windscreen washer fluid reservoir is located in the engine compartment.

The **filling level** of the container is about 3.5 litres and about 5.4 litres on vehicles that have a headlight washing system¹⁾.

Clear water is not sufficient to intensively clean the windscreen and headlights. We therefore recommend using clean water with a screen cleaner (**including anti-freeze in the winter**) that is able to remove stubborn dirt.

Antifreeze should always be added to the cleaning water in the winter even if the vehicle is fitted with heated windscreen washer nozzles.

Under exceptional circumstances, methylated spirits can also be used if no screen cleaner with antifreeze is available. The concentration of methylated spirits must not be more than 15 %. The freeze protection at this concentration is sufficient only to -5 °C.

CAUTION

- Under no circumstances must radiator antifreeze or other additives be added to the windscreen washer fluid.
- If the vehicle is fitted with a headlight cleaning system, only cleaning products which do not attack the polycarbonate coating of the headlights must be added to the windscreen washer fluid.

Note

Do not remove the filter from the windscreen washer fluid reservoir when replenishing it with liquid otherwise the liquid transportation system can be contaminated, which can cause the windscreen washer system to malfunction.






Vehicle battery

Introduction

This chapter contains information on the following subjects:

Battery cover	147
Checking the battery electrolyte level	147
Operation in winter	147
Charging a vehicle battery	148
Disconnecting and reconnecting the vehicle battery	148
Replacing the vehicle battery	148
Automatic load deactivation	149

Warning symbols on the vehicle battery

Symbol	Importance
	Always wear eye protection.
	Battery acid is severely caustic. Always wear gloves and eye protection.
	Keep fire, sparks, open flames and lit cigarettes well clear of the vehicle battery.
	When charging the vehicle battery, a highly explosive gas mixture is produced.
	Keep children away from the vehicle battery.

¹⁾ In some countries, 5.4 ltr. applies for both variants.

Improper handling of the vehicle battery can cause damage. We therefore recommend that any work on the vehicle battery is carried out by a ŠKODA Service Partner.

There is a risk of injuries, scalding, accidents and burns when carrying out any work on the battery and on the electrical system. For this reason, it is essential to comply with the warning instructions stated below and with the general applicable rules of safety.

WARNING

- The battery acid is strongly corrosive and must, therefore, be handled with the greatest of care. Always wear protective gloves, eye and skin protection when handling the vehicle battery. Corrosive fumes in the air irritate the air passages and lead to conjunctivitis and inflammation of the air passages in the lungs. They corrode tooth enamel. After contact with the skin, the acid creates deep wounds which take a long time to heal. Repeated contact with diluted acids causes skin diseases (inflammations, ulcers, skin cracks). Acids coming into contact with water are diluted accompanied by significant development of heat.
- Do not tilt the battery otherwise battery electrolyte may flow out of the battery vent openings. Protect the eyes with safety glasses or a shield! There is the danger of suffering blindness! If any battery electrolyte comes into contact with your eyes, rinse the relevant eye immediately with clear water for several minutes. Then consult a doctor immediately.
- Splashes of acid on your skin or clothes should be neutralised as soon as possible using soap suds and then rinsed with plenty of water. If acid was swallowed, seek immediate medical attention.
- Keep children away from the vehicle battery.
- When you charge a battery, hydrogen is released, and a highly explosive gas mixture is also produced. An explosion can be caused through sparking over during unclamping or loosening of the cable plug while the ignition is on.
- Bridging of the poles will create a short circuit (e.g. through metal objects, cables). Possible consequences of a short circuit: Melting of lead struts, explosion and burning of the battery, jets of acid spurting out.
- It is prohibited to work with a naked flame and light, to smoke or to carry out any activities which produce sparks. Avoid creating sparks when working with cables and electrical devices. Strong sparking represents a risk of injury.

WARNING (Continued)

- Before carrying out any work on the electrical system, switch off the engine, the ignition and all of the electrical components and disconnect the negative terminal (-) on the battery. If you wish to replace a bulb it suffices to switch off the relevant light.
- Never charge a frozen or thawed vehicle battery - risk of explosion and caustic burns! Replace a frozen vehicle battery.
- Never jump-start vehicle batteries with an electrolyte level that is too low - risk of explosion and caustic burns.
- Never use a damaged vehicle battery - risk of explosion! Replace a damaged vehicle battery immediately.

CAUTION

- The vehicle battery must only be disconnected if the ignition is switched off, otherwise the vehicle's electrical system (electronic components) can be damaged. When disconnecting the battery from the electrical system, first of all disconnect the negative terminal (-) of the battery. Then disconnect the positive terminal (+).
- When connecting the battery to the electrical system, first connect the positive terminal (+) of the battery. Then connect the negative terminal (-). Under no circumstances must the battery cables be connected incorrectly - risk of a cable fire.
- Ensure that battery acid does not come into contact with the bodywork - risk of damage to the paintwork.
- Do not place the battery in direct daylight in order to protect the vehicle battery housing from the effects of ultra-violet light.
- If the vehicle has not been driven for more than 3 to 4 weeks, the battery will discharge. This is because certain electrical components consume electricity (e.g. control units) also in idle state. Prevent the battery from discharging by disconnecting the battery's negative terminal or continuously charging the battery with a very low charging current.
- If the vehicle is frequently used for making short trips, the vehicle battery will not have time to charge up sufficiently and may discharge.

For the sake of the environment

A vehicle battery that has been removed is a special type of hazardous waste. These must be disposed of in accordance with national legal regulations.

Note

You should replace batteries older than 5 years. ■

Battery cover



Fig. 123
Vehicle battery: Open up the cover

 First read and observe the introductory information and safety warnings  on page 145.

The battery is located in the engine compartment below a plastic box.

- Push the lid in the direction of the arrow » Fig. 123.
- The installation of the battery cover on the positive terminal side takes place in the reverse order.

Checking the battery electrolyte level






Fig. 124
Vehicle battery: Electrolyte level indicator

 First read and observe the introductory information and safety warnings  on page 145.

We recommend you have the electrolyte level checked by a ŠKODA specialist garage from time to time, especially in the following cases.

- High outside temperatures.
- Long daily drives
- After each charge » page 148.

On vehicles with a vehicle battery fitted with a colour indicator, the so-called magic eye » Fig. 124, the electrolyte level can be determined by looking at the change in colour.



Air bubbles can influence the colour of the indicator. For this reason carefully knock on the indicator before carrying out the check.

- Black colour - electrolyte level is correct.
- Colourless or light yellow colour - electrolyte level too low, the battery must be replaced.

Note

- The battery electrolyte level is periodically checked by a ŠKODA Service Partner as part of the Inspection Service.
- For technical reasons, on vehicles with the description "AGM", the electrolyte level cannot be checked.
- Vehicles with a START-STOP system are fitted with a battery control unit for checking the energy level for the recurring engine start.

Operation in winter

 First read and observe the introductory information and safety warnings  on page 145.

At low temperatures, the vehicle battery only has part of the initial power output that it has at normal temperatures.

A discharged vehicle battery may already freeze at temperatures just below 0 °C.

We therefore recommend that you have the battery checked and, if necessary, recharged by a ŠKODA Service Partner before the start of the winter.

Charging a vehicle battery



First read and observe the introductory information and safety warnings  on page 145.

A properly charged vehicle battery is essential for reliably starting the engine.

- Switch off the ignition and all of the electrical components.
- Only for "quick-charging": Disconnect both battery cables (first of all "negative", then "positive").
- Attach the terminal clamps of the charger to the battery terminals (red = "positive", black = "negative").
- Only now plug the mains cable of the charger into the power socket and switch on the device.
- When charging is completed: Switch off the charger and remove the mains cable from the power socket.
- Only then disconnect the charger's terminal clamps.
- Reconnect the cables to the battery, if necessary (first of all "positive", then "negative").

It is not normally necessary to disconnect the cables of the battery if you recharge the vehicle battery using low amperages (as for example from a **mini-charger**). Refer to the instructions of the charger manufacturer.

A charging current of 0.1 multiple of the total vehicle battery capacity (or lower) must be used until full charging is achieved.

It is, however, necessary to disconnect both cables before charging the battery with high amperages, so-called "quick-charging".

"Quick-charging" the vehicle battery is **dangerous** and requires a special charger and specialist knowledge. We therefore recommend having the quick charging of vehicle batteries undertaken by a ŠKODA specialist garage.


The vent plugs of the vehicle battery should not be opened for charging.

CAUTION

On vehicles with the START/STOP system, the pole terminal of the charger must not be connected directly to the negative terminal of the vehicle battery, but only to the engine earth » page 166, *Jump-starting in vehicles with the START-STOP system*.

Disconnecting and reconnecting the vehicle battery



First read and observe the introductory information and safety warnings  on page 145.

On disconnecting and reconnecting the vehicle battery the following functions are initially deactivated or are no longer able to operate fault-free.


Operation	Operating measure
Electrical power window (operational faults)	» page 35
Enter the radio/navigation system code number	» <i>User manual of the radio or » user manual of the navigation system</i>
Setting the clock	» page 11
Data in the multifunction display are deleted.	» page 12

Note

We recommend having the vehicle checked by a ŠKODA Service Partner to ensure the full functionality of all electrical systems.

Replacing the vehicle battery




First read and observe the introductory information and safety warnings  on page 145.

When replacing a battery, the new vehicle battery must have the same capacity, voltage, amperage and be the same size. Suitable types of vehicle batteries can be purchased from a ŠKODA Service Partner.

We recommend that the battery is replaced by a ŠKODA Service Partner, where the new vehicle battery will be installed properly and the original battery will be disposed of in accordance with national regulations.

Automatic load deactivation



First read and observe the introductory information and safety warnings  on page 145.

An intelligent vehicle power management system automatically takes various measures at high loads on the vehicle battery to prevent discharging of the battery: This manifests itself by the following:

- The idling speed is raised to allow the generator to deliver more electricity to the electrical system.
- Where appropriate large consumers of power, e.g. seat heaters, rear window heaters, voltage supply to the 12V power socket, have their power limited or in case of emergency shut off completely.



Note

Despite such intervention by the vehicle electric system management, the vehicle battery may be drained. For example, when the ignition is switched on a long time with the engine turned off or the side or parking lights are turned on during longer parking. Driving comfort is not put at risk by any shutting off of consumers. Often the driver is not aware of it having taken place. ■

Wheels and Tyres

Tyres

Introduction

This chapter contains information on the following subjects:

Service life of tyres _____	151
Handling wheels and tyres _____	152
New wheels and tyres _____	152
Unidirectional tyres _____	153
Spare wheel _____	153
Full wheel trim _____	154
Wheel bolts _____	154
Wheel trim caps _____	154
Tyre control display _____	155
Wheel bolts _____	156
Winter tyres _____	156
Snow chains _____	156

WARNING

- During the first 500 km, new tyres do not offer optimum grip and appropriate care should therefore be taken when driving - risk of accident!
- Never drive with damaged tyres - risk of accident!
- Only use those tyres or wheel rims which have been approved by ŠKODA for your model of vehicle. Failure to observe this instruction will adversely affect the road safety of your vehicle - risk of accident!
- The maximum permissible speed for your tyres must not be exceeded under any circumstances - risk of an accident resulting from tyre damage and loss of control of the vehicle.
- If the inflation pressure is too low, the tyre must perform a higher rolling resistance. At higher speeds the tyre will warm up as a result of this. This can result in tread separation and a tyre blowout.

WARNING (Continued)

- Do not, where possible, replace individual tyres but at least replace them on both wheels of a given axle at the same time. Always fit the tyres with the deeper tread depth to the front wheels.
- Never use tyres if you do not know anything about the condition and age.
- You must have your tyres replaced with new ones at the latest when the wear indicators have been worn down.
- Worn tyres do not provide the necessary adhesion to the road surface at high speeds on wet roads. One could experience "aquaplaning" (uncontrolled movements of the vehicle - "swimming" on a wet road surface).
- Immediately replace damaged wheel rims or tyres.
- Do not use summer or winter tyres that are older than 6 years or 4 years respectively.
- The wheel bolts must be clean and must turn easily. However, they must never be treated with grease or oil.
- If the wheel bolts are tightened to a too low tightening torque, the rim can come loose when the car is moving - risk of accident! A tightening torque which is too high can damage the bolts and threads and this can result in permanent deformation of the contact surfaces on the rim.
- In case of incorrect treatment of the wheel bolts, the wheel can loosen when the car is moving - risk of accident!
- Observe the national legal regulations relating to the use of tyres and snow chains.

CAUTION

- If a spare wheel is used that is not identical to the fitted tyres, the following must be observed » [page 153](#), *Spare wheel*.
- The prescribed tightening torque of the wheel bolts for steel and light alloy wheels is 120 Nm.
- Protect the tyres from contact with oil, grease and fuel.
- Replace any lost valve caps immediately.

For the sake of the environment

Tyres which are insufficiently inflated increase your fuel consumption. ▶

i Note

- We recommend that any work on the wheels or tyres is carried out by a ŠKODA Service Partner.
- We recommend that you use wheel rims, tyres, full wheel trims and snow chains from ŠKODA Original Accessories.

Service life of tyres




Fig. 125 Tyre tread with wear indicators/Open fuel filler flap with a table detailing the tyre size and tyre inflation pressure



First read and observe the introductory information and safety warnings **i** on page 150.

Wear indicators

The base of the tread of the tyres has 1.6 mm high wear indicators installed. These wear indicators are located multiple times depending on the make and are evenly spaced around the circumference of the tyre » Fig. 125 - [A]. Markings on the walls of the tyres through the letters "TWI", triangular symbols or other symbols identify the position of the wear indicators.

The life of your tyres very much depends on the following points:

Tyre pressure

The working life of tyres will be shortened considerably if the tyres are insufficiently or over-inflated and this will have an adverse effect on the handling of your vehicle. Therefore check the tyre pressure, including that of the spare wheel, at least once a month and also before setting off on a long journey.

The tyre inflation pressures for **summer tyres** are indicated on the inside of the fuel filler flap » Fig. 125 - [B]. The inflation pressures for **winter tyres** are 20 kPa (0.2 bar) higher than those for summer tyres.

Always check the inflation pressure when the tyres are cold. Do not reduce the higher pressure of warm tyres. If the load varies greatly, adjust the tyre inflation pressure accordingly.

Tyre inflation pressure - Tyre size 185/55 R15

The same inflation pressure values apply to tyres of the tyre size 195/55 R15 as to tyres of the tyre size 185/55 R15 which are intended to be used with snow chains.

The tyres of the tyre size 185/55 R15, which are intended to be used with snow chains and are fitted on the Fabia Estate Scout, have the following inflation pressure values in kPa.

Engine	Half payload	Full payload
1.2/63 kW TSI	220/230	220/290
1.4/63 kW		220/290
1.2/77 kW TSI		230/300
1.6/77 kW		230/300
1.2/55 kW TDI CR		230/300
1.6/66 kW TDI CR		220/290
1.6/77 kW TDI CR		220/290

Driving style

Fast cornering, sharp acceleration and braking increase the wear of your tyres.

Balancing wheels

The wheels of a new vehicle are balanced. There are a wide range of influences when driving which may result in an imbalance and which makes themselves felt through vibration in the steering.

Have the wheels rebalanced after replacing the tyres.

Wheel alignment errors

Incorrect wheel alignment at the front and rear will not only increase wear-and-tear on the tyres but will also has an adverse effect on vehicle safety. In the event of any unusual tyre wear, seek assistance from a ŠKODA specialist garage.

Tyre damage

Drive over curbs on the side of the road and other such obstacles slowly and, where possible, at a right angle in order to avoid damage to tyres and wheel trims.

We recommend checking your tyres and wheel rims for damage (punctures, cuts, splits and bulges, etc.) on a regular basis. Remove foreign bodies from the tyre profile.

Unusual vibrations or pulling of the vehicle to one side could be a sign of tyre damage. **If there is any doubt that a wheel is damaged, immediately reduce your speed and stop!** Check the tyres for signs of damage (bulges, splits, etc.). If no external damage is evident, drive slowly and carefully to the nearest ŠKODA specialist garage to have the vehicle checked.

Handling wheels and tyres




Fig. 126
Changing wheels around

First read and observe the introductory information and safety warnings on page 150.

Changing wheels around

If significantly greater wear is present on the front tyres, we recommend changing the front wheels around with the rear wheels as shown in the diagram » Fig. 126. You will then obtain approximately the same life for all the tyres.

We recommend that you change the wheels around every 10 000 km in order to achieve even wear on all wheels and to obtain optimal tyre life.

Storing tyres

Mark wheels before removing them so that their previous direction of running can be maintained when mounted them again.

Always store wheels or tyres which been removed in a cool, dry and, where possible, dark place. Tyres which are not fixed to a wheel trim should be stored upright.

New wheels and tyres

First read and observe the introductory information and safety warnings on page 150.

Only fit tyres of the same type, size (rolling circumference) and the same tread pattern on one axle on all 4 wheels.

The tyre/wheel combinations which are approved for your vehicle are indicated in your vehicle documents.

Proper knowledge of the tyre data makes it easier for you to select the correct type of tyre. Tyres, for example, have the following inscription on their walls.

185/65 R 14 86 T

What this means is:

185	Tyre width in mm
65	Height/width ratio in %
R	Code letter for the type of tyre - Radial
14	Diameter of wheel in inches
86	Load index
T	Speed symbol

The following speed restrictions apply to tyres.

Speed symbol	Permissible maximum speed
Q	160 km/h
R	170 km/h
S	180 km/h
T	190 km/h
U	200 km/h
H	210 km/h
V	240 km/h
W	270 km/h

The **date of manufacture** is also stated on the tyre wall (possibly only on the *inside of wheel*): e.g.

DOT ... 20 12...

means, for example, that the tyre was manufactured in the 20th week of 2012. ▶

The following must be observed if only one temporary spare wheel is available » [page 153](#).

Unidirectional tyres



First read and observe the introductory information and safety warnings  on page 150.

The direction of rotation of the tyres is marked by **arrows on the wall of the tyre**. The so specified running direction must absolutely be complied with. Only then are the tyres able to provide the optimal properties in terms of grip, low noise, wear-and-tear and aquaplaning.

If, in the event of a puncture, it is necessary to fit a spare wheel with a tyre without a dedicated running direction or the opposite running direction, drive carefully as the optimum characteristics of the tyre are no longer applicable in this situation.

Spare wheel





Fig. 127
Boot: Spare wheel




First read and observe the introductory information and safety warnings  on page 150.

The spare wheel is located in a well under the floor covering in the boot and is fixed in place with a special bolt » [Fig. 127](#).

Before removing the spare wheel, the box containing the vehicle tool kit must be removed.

It is important to check the inflation pressure in the spare wheel (preferably every time the tyre air pressure is checked - see sticker on the fuel filler flap » [page 151](#)) to ensure it is always ready to use.

If the dimensions or design of the spare wheel differ from the tyres fitted to the vehicle (e.g. winter tyres or low-profile tyres), it must only be used briefly in the event of a puncture and if an appropriately cautious style of driving is adopted » .

Replace it with a wheel having the appropriate mode and dimensions as soon as possible

Temporary spare wheel

A warning label is displayed on the wheel rim of the spare wheel to indicate that your vehicle is equipped with a temporary spare wheel.

Please observe the following when driving with a temporary spare wheel.

- ▶ The warning label must not be covered after installing the wheel.
- ▶ Do not drive faster than 80 km/h with the temporary spare wheel and pay particular attention while driving. Avoid accelerating at full throttle, sharp braking and fast cornering.
- ▶ The inflation pressure for this spare wheel is identical to the maximum inflation pressure of the standard tyres.
- ▶ Only use this temporary spare wheel to reach the nearest ŠKODA specialist garage as it is not intended for continuous use.



WARNING

- Never use the temporary spare wheel if it is damaged.
- If the dimensions or design of the temporary spare wheel differ from the fitted tyres, never drive faster than 80 km/h (or 50 mph). Avoid accelerating at full throttle, sharp braking and fast cornering.



CAUTION

Observe the instructions on the sticker on the temporary spare wheel.



Note

The tyre pressure should be at the highest pressure specified for your vehicle at all times.

Full wheel trim

 First read and observe the introductory information and safety warnings  on page 150.

Pulling off

- Hook the clamp found in the vehicle tool kit into the reinforced edge of the wheel trim.
- Push the wheel wrench through the clamp, support on the tyre and pull off the wheel trim.

Install

- First press the full wheel trim onto the wheel rim at the valve opening provided. Then press the full wheel trim into the wheel rim until its entire circumference locks correctly in place.

CAUTION


- Use the pressure of your hand, do not knock the full wheel trim! Heavy knocks mainly on the points where the full wheel trim has not been inserted into the wheel, can result in damage to the guide and centring elements of the full wheel trim.
- First of all check that the theft-deterrent wheel bolt is located in the hole near the valve before fitting the full wheel trim onto a steel wheel which is attached with a theft-deterrent wheel bolt » page 162, *Securing wheels against theft*.
- If **wheel trims** are retrofitted it must be ensured that an adequate flow of air is assured to cool the brake system.

Wheel bolts



Fig. 128
Remove the cap



First read and observe the introductory information and safety warnings  on page 150.

Pulling off

- Push the plastic clip sufficiently far onto the cap until the inner catches of the clip are positioned at the collar of the cap and detach the cap » Fig. 128.

Install

- Push the caps onto the wheel bolts up to the stop.

The wheel bolt caps are housed in a plastic box in the spare wheel or in the storage space for the spare wheel.

Wheel trim caps





Fig. 129
Pull off the wheel trim cap on light alloy wheels



First read and observe the introductory information and safety warnings  on page 150.

Pulling off


- Carefully remove the wheel trim cap using the wire clamp from the vehicle tool kit » Fig. 129.

Tyre control display



Fig. 130
Button for setting the tyre inflation pressure control value

 First read and observe the introductory information and safety warnings  on page 150.

The tyre control display compares the speed and thus the rolling circumference of the individual wheels with the help of the ABS sensors. If the rolling circumference of a wheel is changed, the warning light  in the instrument cluster [» page 23, Tyre control display !\[\]\(bbb3388d591ef640dd8a8c4262f2866a_img.jpg\)](#) and an audible signal sounds.





The rolling circumference of the tyre can change if:

- the tyre inflation pressure is too low;
- the structure of the tyre is damaged;
- the vehicle is loaded on one side;
- the wheels of an axle are loaded heavily (e.g. when towing a trailer or when driving uphill or downhill);
- snow chains are mounted;
- the temporary spare wheel is mounted;
- one wheel per axle was changed.



Basic setting of the system

After changing the tyre inflation pressure, after changing one or several wheels, the position of a wheel on the vehicle (e.g. exchanging the wheels between the axles) or when the warning light lights up while driving, a basic setting of the system must be carried out as follows:

- Inflate all of the tyres to the specified inflation pressure [» page 151, Service life of tyres.](#)
- Switch on the ignition.

- Press and hold the button  [» Fig. 130](#) for longer than 2 seconds. While pressing the button, the warning light  illuminates. At the same time the system memory is erased and the new calibration is started, which is confirmed with an audible signal and then the warning light  goes out.
- If the warning light  does not go out after the basic setting, this indicates a system fault. Seek help from a ŠKODA specialist garage.



The warning light is lit

If the tyre inflation pressure of at least one wheel is insufficiently inflated in comparison to the stored basic value, the warning light   lights up.

The warning light flashes

If the warning light flashes, there is a system fault. Seek help from a ŠKODA specialist garage to correct the fault.

WARNING

- When the warning light  illuminates, immediately reduce the speed and avoid sudden steering and brake manoeuvres. Stop the vehicle as soon as possible and inspect the tyres and their inflation pressure.
- Under certain circumstances (e.g. sporty style of driving, wintry or unpaved roads) the warning light  can be delayed or does not light up at all.
- The tyre control display does not absolve the driver of the responsibility to ensure the correct tyre inflation pressure. For this reason, the tyre inflation pressure must be checked regularly.

Note

- The tyre control display does therefore not replace the regular tyre inflation pressure control, as the system cannot detect an even loss of pressure.
- The tyre control display cannot provide a warning in the event of very rapid tyre inflation pressure loss, e.g. in the case of sudden tyre damage. In this case carefully bring the vehicle to a standstill without sudden steering movements or sharp braking.
- To ensure a proper functioning of the tyre control display, it is necessary to repeat the basic setting every 10 000 km or once a year.

Wheel bolts



First read and observe the introductory information and safety warnings  on page 150.

Wheels and **wheel bolts** are matched to each other in terms of design. Each time you fit other wheels, e.g. light alloy wheels or wheels with winter tyres, you must therefore also use the matching wheel bolts of the correct length and shape of spherical cap. This is essential to ensure that the wheels are tightly fitted and that the brake system operates properly.

Winter tyres



First read and observe the introductory information and safety warnings  on page 150.

The handling of your vehicle will be significantly improved when driving on wintry roads if you fit winter tyres. Summer tyres do not offer the same grip on ice, snow and at temperatures below 7 °C because of their construction (width, rubber blend, tread pattern). This particularly applies to vehicles which are equipped with **low-profile tyres** or **high-speed tyres** (code index H or V on wall of tyre).

To achieve the best possible handling properties, winter tyres must be fitted on all 4 wheels, the minimum tread depth must be 4 mm and tyres must be no older than 4 years.

Winter tyres of a lower speed category can be used provided that the permissible maximum speed of these tyres is not exceeded even if the possible maximum speed of the vehicle is higher.



For the sake of the environment

Fit the summer tyres on again in good time as they provide better handling properties, a shorter braking distance, less tyre noise, and reduced tyre wear on roads which are free of snow and ice as well as at temperatures above 7 °C. The fuel consumption is also lower.

Snow chains



First read and observe the introductory information and safety warnings  on page 150.

Snow chains must only be mounted on the front wheels.

When driving on wintry roads, snow chains improve not only traction, but also the braking performance.

For technical reasons, it is only permissible to fit snow chains with the following wheel/tyre combinations.

Wheel size	Depth (D)	Tyre size
5J x 14	35 mm	165/70
6J x 14	37 mm	185/60
6J x 15	43 mm	185/55

Only fit snow chains with links and locks not larger than **12 mm**.

Remove the **full wheel trims** before installing the snow chains.

Observe the national legal regulations relating to the use of snow chains and the maximum vehicle speed with snow chains.


CAUTION

The chains must be removed when driving on roads which are free of snow. They adversely affect the handling of your vehicle, damage the tyres and are rapidly destroyed.

Accessories, changes and replacement of parts

Introductory information

If you want to retrofit the vehicle with accessories, if a vehicle part is to be replaced with a new one, or when needing to make technical changes, the following instructions must be observed.

- Always seek advice from a ŠKODA Service Partner **before** purchasing any accessories or parts and **before** making any technical changes » .
- The guidelines and instructions issued by ŠKODA must be observed when making technical changes.

Adhering to the prescribed procedures will prevent any kind of damage to the vehicle, and its travelling and operating safety will be maintained. The vehicle also complies with German road transport regulations (StVZO). More information is available from a ŠKODA Service Partner who can also perform the necessary work correctly.

Vehicles with special built-on types

Technical documents regarding changes carried out on the vehicle must be kept by the vehicle user, in order to hand over later to the old car user. This ensures the recycling in accordance with environmental regulations.

Interference on the electronic components and their software can lead to operational faults. This interference can also impair not directly affected systems because of the networking of the electronic components. In other words, the vehicle's roadworthiness may be put at risk and increased wear on parts may arise.

Any damage caused by technical changes made without consent by ŠKODA is excluded from the warranty – see the warranty certificate.

WARNING

- Work or modifications on your vehicle, which have been carried out unprofessionally, can cause operational faults - risk of accident!
- We advise you, in your own interest, to only use ŠKODA Original Accessories and ŠKODA Original Parts which have been expressly approved for use on your vehicle. Reliability, safety and suitability have been established for ŠKODA Original Accessories and ŠKODA Original Parts.
- Although we constantly monitor the market, we are not able to assess or warrant the parts even though in some instances such parts may have a type approval or may have been approved by a nationally recognised testing laboratory.

Note

ŠKODA Original Accessories and ŠKODA Original Parts can be purchased from ŠKODA Service Partners who will also professionally undertake the assembly of the purchased parts.

Changes and impairments of the airbag system

Repairs and technical modifications must comply with ŠKODA guidelines.

We recommend that any modifications and repairs to the front bumper, doors, front seats, headliner or bodywork be carried out by a ŠKODA Service Partner. These vehicle parts may include system components for the airbag system.

WARNING

- Airbag modules can not be repaired, but must be replaced.
- Never install any airbag parts into the vehicle that have been removed from old cars or have been recycled.
- A modification to the suspension of the vehicle including the use of non-approved rim-tyre combinations can alter the functioning of the airbag and increase the risk of serious or fatal injuries in an accident.
- Parts of the airbag system may be damaged when working on the airbag system or removing and installing system parts due to other repairs. This may mean that the airbags will not deploy properly or not at all in the event of an accident.

Do-it-yourself

Do-it-yourself

First-aid kit and warning triangle




Fig. 131
Placing of the warning triangle

A warning triangle with the maximum dimensions 39 x 68 x 450 mm can be attached to the trim panel of the rear wall with rubber straps » Fig. 131.

! WARNING

The first-aid kit and warning triangle must always be secured safely so that they do not come loose when making an emergency braking or in a vehicle collision which could cause injuries to occupants.

i Note

- Pay attention to the expiration date of the first-aid kit.
- We recommend using a first-aid box from ŠKODA Original Accessories available from a ŠKODA Service Partner.

Fire extinguisher

The fire extinguisher is attached with straps in a holder under the driver seat.

Please read carefully the instructions which are attached to the fire extinguisher.

The fire extinguisher must be checked by an authorised person on an annual basis (the national legal provisions must be observed).

! WARNING

The fire extinguisher must always be secured safely so that they do not come loose when making an emergency braking or in a vehicle collision which could cause injuries to occupants.

i Note

- The fire extinguisher must comply with the relevant applicable national legal requirements.
- Pay attention to the expiration date of the fire extinguisher. If the fire extinguisher is used after the expiration date, its proper function is no longer assured.
- The fire extinguisher is part of the scope of delivery in certain countries only.

Vehicle tool kit




Fig. 132
Boot: Storage compartment for vehicle tool kit

The vehicle tool kit and the lifting jack with sticker are housed in a plastic box in the spare wheel » Fig. 132 or in the storage space for the spare wheel. There is also space here for the removable ball rod for the trailer towing device. The box is attached with a strap on the spare wheel.

The vehicle tool kit contains the following parts (depending on equipment fitted):

- wire clamps for removing the full wheel trims;
- wheel wrench;
- towing eye;
- Adapter for anti-theft wheel bolts;
- Extraction pliers for wheel bolt caps;

- Replacement bulb set;
- Screwdriver.

Before placing the lifting jack back into its storage area, screw in the arm of the lifting jack fully.

WARNING

- The factory-supplied lifting jack is only intended for your model of vehicle. Under no circumstances attempt to lift heavier vehicles or other loads - risk of injury!
- Ensure that the vehicle tool kit is safely secured in the boot.

Note

Ensure that the box is always secured with the strap.

Changing a wheel

Introduction

This chapter contains information on the following subjects:

Preliminary work	159
Changing a wheel	160
Subsequent steps	160
Loosening and tightening wheel bolts	161
Raising the vehicle	161
Securing wheels against theft	162

WARNING

- If you are in flowing traffic, switch on the hazard warning light system and set up the warning triangle at the prescribed distance! The national legal requirements must be observed. In this way you are not only protecting yourself but other road users as well.
- If the wheel is damaged or in the event of a puncture, park the vehicle as far away as possible from the flow of traffic. Park on as flat and firm a surface as possible.

WARNING (Continued)

- If the wheel has to be changed on a slope, first of all block the opposite wheel with a stone or similar object to prevent the vehicle from unexpectedly rolling away.
- If the vehicle is subsequently fitted with tyres which are different to those it was fitted with at the works, follow these guidelines » [page 152, New wheels and tyres](#).
- Always raise the vehicle with the doors closed.
- Never position any body parts, such as arms or legs under the vehicle, while the vehicle is raised with a lifting jack.
- Secure the base plate of the lifting jack with suitable means to prevent possible moving. A soft and slippery ground under the base plate may move the lifting jack, causing the vehicle to fall down. It is therefore always necessary to place the lifting jack on a solid surface or use a wide and stable base. Use a non-slip base (e.g. a rubber foot mat) if the **surface is smooth**, such as cobbled stones, tiled floor, etc.
- Never start the engine with the vehicle sitting on the raised jack - danger of suffering injury.
- Only attach the lifting jack to the attachment points provided for this purpose.

CAUTION

- The prescribed tightening torque of the wheel bolts for steel and light alloy wheels is 120 Nm.
- If the anti-theft wheel bolt is fastened too tightly, it can cause damage to the anti-theft wheel bolt and adapter.

Note

- The anti-theft wheel bolt set and adapter can be purchased from a ŠKODA Service Partner.
- The national legal requirements must be observed when changing a wheel.

Preliminary work



First read and observe the introductory information and safety warnings  on page 159.

The following steps must be carried out before actually changing the wheel: ▶

- In the event of a puncture, park the vehicle as far away as possible from the flow of traffic. The place you choose should be **level**.
- Let **all of the occupants get out**. While changing a tyre, the occupants of the vehicle should not stand on the road (instead they should remain behind a crash barrier).
- Switch off the engine and move the gearshift lever into **Neutral** or move the **selector lever** for the automatic gearbox **into position P**.
- Firmly apply the **handbrake**.
- If a trailer is connected, remove it.
- Remove the **vehicle tool kit** » [page 158](#) and the **spare wheel** » [page 153](#), *Spare wheel* from the boot.

Changing a wheel



First read and observe the introductory information and safety warnings  on page 159.

Always change a wheel on a level surface as far as possible.

- Remove the full wheel trim » [page 154](#) or caps » [page 154](#).
- In the case of light alloy wheel rims remove the wheel trim cap » [page 154](#).
- First of all slacken the anti-theft wheel bolt and then the other wheel bolts » [page 161](#).
- Jack up the vehicle until the wheel that needs changing is clear of the ground » [page 161](#).
- Unscrew the wheel bolts and place them on a clean surface (cloth, paper, etc.).
- Remove the wheel.
- Attach the spare wheel and slightly screw on the wheel bolts.
- Lower the vehicle.
- Alternately tighten the wheel bolts opposite each other using the wheel wrench (crosswise) and then tighten the anti-theft wheel bolt » [page 161](#).
- Reinstall the wheel trim/wheel trim cap or the caps.



Note

- All bolts must be clean and must turn easily.
- Under no circumstances grease or oil the wheel bolts!
- When fitting unidirectional tyres, ensure that the direction of rotation is correct » [page 153](#), *Unidirectional tyres*.

Subsequent steps



First read and observe the introductory information and safety warnings  on page 159.

The following steps must also be performed after changing the wheel.

- Stow and attach the replaced wheel in the spare wheel well using a special screw » [page 153](#), *Spare wheel*.
- Stow the vehicle tool kit in the space provided.
- **Check the tyre pressure** on the installed spare wheel as soon as possible.
- Have the **tightening torque** of the wheel bolts **checked** with a torque wrench as soon as possible.
- Change the damaged wheel or consult a ŠKODA specialist garage about repair possibilities.



Note

- If it is determined that the wheel bolts are corroded and difficult to turn when changing the wheel, the bolts must be replaced before checking the tightening torque.
- Drive cautiously and only at a moderate speed until the tightening torque has been checked.

Loosening and tightening wheel bolts



Fig. 133
Changing a wheel: Loosening the wheel bolts

First read and observe the introductory information and safety warnings on page 159.

Loosening

- Push the wheel wrench onto the wheel bolt up to the stop¹⁾.
- Grasp the end of the wrench and turn the bolt about **one** turn to the left » Fig. 133.

Tightening

- Push the wheel wrench onto the wheel bolt up to the stop¹⁾.
- Grasp the end of the wrench and turn the bolt to the right until it is tight.

WARNING

Undo the wheel bolts only a little (about one turn) as long as the vehicle has not yet been jacked up - risk of an accident!

Note

If it proves difficult to undo the bolts, carefully apply pressure to the end of the wrench with your **foott**. Keep hold of the vehicle when doing so, and make sure you keep your footing.

Raising the vehicle




Fig. 134
Changing a wheel: Jacking points for positioning lifting jack




Fig. 135 Attach lifting jack

First read and observe the introductory information and safety warnings on page 159.

Position the lifting jack by selecting the jacking point that is closest to the faulty wheel » Fig. 134. The jacking point is located directly below the engraving in the lower sill.

- Position the lifting jack below the jacking point and move it up until its claw is positioned directly below the vertical web of the lower sill.
- Align the lifting jack so that its claw grasps the web » Fig. 135 - below the embossing in the side surface of the lower sill.
- Ensure that the entire surface of the lifting jack base plate rests on level ground and is located in a vertical position to the area » Fig. 135 where the claw grasps the web.

¹⁾ Use the appropriate adapter for undoing and tightening the anti-theft wheel bolts » page 162.

- Continue turning up the jack until the wheel is just about lifted off the ground. ■

Securing wheels against theft




Fig. 136
Principle sketch: Anti-theft
wheel bolt with adapter

First read and observe the introductory information and safety warnings on page 159.

The anti-theft wheel bolts on vehicles fitted with them (one anti-theft wheel bolt per wheel) can only be loosened or tightened up by using the adapter provided.

- Pull off the full wheel trim from the wheel rim or the cap from the anti-theft wheel bolt.
- Insert the adapter **B** > Fig. 136 with its toothed side fully into the inner toothing of the safety wheel bolt **A** until the stop so that only the outer hexagon is jutting out.
- Push the wheel wrench onto the adapter **B** up to the stop.
- Loosen or tighten the wheel bolt > page 161.
- After removing the adapter, reinstall the full wheel trim or place the cap onto the anti-theft wheel bolt.
- Have the **tightening torque checked** with a torque wrench as soon as possible.

It is advisable to make a note of the code number hammered into the rear side of the adapter or the rear side of the anti-theft wheel bolt. This number can be used to purchase a replacement adapter from a ŠKODA Service Partner, if necessary.

We recommend that you always carry the adapter for the wheel bolts with you in the vehicle. It should be stowed in the vehicle tool kit. ■

Breakdown kit

Introduction

This chapter contains information on the following subjects:

Components of the breakdown kit	163
Preparing to use the breakdown kit	163
Sealing and inflating tyres	164
Check after driving for 10 minutes	164

The breakdown kit is located in a box under the floor covering in the boot.

Use the breakdown kit to reliably repair tyre damage caused by foreign bodies or a puncture with diameters up to approx. 4 mm. Do not remove foreign bodies, e.g. screws or nails, from the tyre!

The repair can be undertaken on the vehicle immediately.

Repairs with the breakdown kit **do not in any way replace** a permanent repair of the tyre, it only serves to reach the next ŠKODA specialist garage.

The breakdown kit must not be used under the following circumstances:

- if there is damage to the wheels;
- in outside temperatures of less than -20 °C;
- with tears or punctures greater than 4 mm in size;
- if there is damage to the tyre wall;
- when driving with very low tyre pressure or with a completely flat tyre;
- if the use-by-date (see inflation bottle) has passed.

WARNING

- If you are in flowing traffic, switch on the hazard warning light system and set up the warning triangle at the prescribed distance! The national legal requirements must be observed. In this way you are not only protecting yourself but other road users as well.
- If the wheel is damaged or in the event of a puncture, park the vehicle as far away as possible from the flow of traffic. Park on as flat and firm a surface as possible.
- A tyre filled with sealant has the same driving characteristics as a standard tyre.

! WARNING (Continued)

- Do not drive faster than 80 km/h (50 mph).
- Avoid accelerating at full throttle, sharp braking and fast cornering.
- Check the tyre inflation pressure after driving for 10 minutes!
- The sealant is hazardous to health. Remove immediately if it comes into contact with the skin.

♻️ For the sake of the environment

Used sealant or sealant whose expiry date has passed must be disposed of in accordance with environmental protection regulations.

i Note

- Observe the manufacturer's usage instructions for the breakdown kit.
- A new bottle of sealant can be purchased from ŠKODA Original Accessories.
- Immediately replace the wheel that was repaired using the breakdown kit or consult a ŠKODA specialist garage about repair possibilities.

Components of the breakdown kit




Fig. 137 Components of the breakdown kit

📖 First read and observe the introductory information and safety warnings ! on page 162.

The breakdown kit contains the following parts:

- 1 Valve remover
- 2 Sticker with speed designation "max. 80 km/h"/"max. 50 mph"
- 3 Inflation hose with plug
- 4 Air compressor
- 5 Tyre inflation hose
- 6 Tyre inflation hose
- 7 Air release valve
- 8 ON and OFF switch
- 9 12 volt cable connector
- 10 Tyre inflator bottle with sealing agent
- 11 Replacement valve core

The valve remover [1] has a slot at its lower end which fits into the valve core. This is the only way in which you can remove and re-install the valve core from the tyre valve. The same also applies to the replacement valve core [11].

Preparing to use the breakdown kit

📖 First read and observe the introductory information and safety warnings ! on page 162.

The following preparatory work must be carried out before using the breakdown kit.

- In the event of a puncture, park the vehicle as far away as possible from the flow of traffic. Park on as flat and firm a surface as possible.
- Let **all of the occupants get out**. While changing a tyre, the occupants of the vehicle should not stand on the road (instead they should remain behind a crash barrier).
- Switch off the engine and move the gearshift lever into **Neutral** or move the **selector lever** for the automatic gearbox **into position P**.
- Firmly apply the **handbrake**.
- Check that you can carry out the repairs with the breakdown kit » [page 162](#).
- If a trailer is connected, remove it.
- Remove the **breakdown kit** from the boot.
- Stick the sticker [2] » [Fig. 137](#) on page 163 on the dash panel in view of the driver.
- Do not remove the foreign body, e.g. screw or nail, from the tyre.
- Unscrew the valve cap.

- Use the valve remover [1] to unscrew the valve core and place it on a clean surface (rag, paper, etc.).

Sealing and inflating tyres



First read and observe the introductory information and safety warnings [!] on page 162.

Sealing

- Forcefully shake the tyre inflator bottle [10] » Fig. 137 on page 163 several times.
- Firmly screw the inflation hose [3] onto the tyre inflator bottle [10] in a clockwise direction. The film on the cap is pierced automatically.
- Remove the plug from the inflation hose [3] and plug the open end fully onto the tyre valve.
- Hold the bottle [10] with the bottom facing upwards and fill all of the sealing agent from the tyre inflator bottle into the tyre.
- Remove the empty tyre inflator bottle from the valve.
- Screw the valve core back into the tyre valve using the valve remover [1].

Inflating

- Screw the tyre inflation hose [5] » Fig. 137 on page 163 of the air compressor firmly onto the tyre valve.
- Check that the air release valve [7] is closed.
- Start the engine and run it in idle.
- Plug the connector [9] into 12 Volt socket » page 65, 12-volt power socket.
- Switch on the air compressor with the ON and OFF switch [8].
- Allow the air compressor to run until a pressure of 2.0 - 2.5 bar is achieved. Maximum run time of 8 minutes » [!].
- Switch off the air compressor.
- If you cannot reach an air pressure of 2.0 - 2.5 bar, unscrew the tyre inflation hose [5] from the tyre valve.
- Drive the vehicle 10 metres forwards or backwards to allow the sealing agent to "distribute" in the tyre.
- Firmly screw the tyre inflation hose [5] back onto the tyre valve and repeat the inflation process.
- If you cannot reach the required tyre inflation pressure here either, this means the tyre has sustained too much damage. You cannot seal with tyre with the breakdown kit » [!].
- Switch off the air compressor.
- Remove the tyre inflation hose [5] from the tyre valve.

Once a tyre inflation pressure of 2.0 - 2.5 bar is achieved, continue the journey at a maximum speed of 80 km/h (50 mph).

Check the tyre inflation pressure after driving for 10 minutes » page 164.



WARNING

- During inflation, the tyre inflation hose and air compressor may get hot- risk of injury!
- Do not place the hot tyre inflation hose or hot air compressor on flammable materials - risk of fire!
- If you cannot inflate the tyre to at least 2.0 bar, this means the damage sustained was too serious. The sealing agent cannot be used to seal the tyre. [!]. Do not drive the vehicle. Get professional assistance!



CAUTION

Switch off the air compressor after running 8 minutes at the latest - danger of overheating! Allow the air compressor to cool a few minutes before switching it on again.

Check after driving for 10 minutes



First read and observe the introductory information and safety warnings [!] on page 162.

Check the tyre inflation pressure after driving for 10 minutes!

If the tyre inflation pressure is 1.3 bar or less:

- [!]. Do not drive the vehicle! You cannot properly seal with tyre with the breakdown kit.
- Get professional assistance.

If the tyre inflation pressure is 1.3 bar or more:

- Adjust the tyre inflation pressure to the correct value (see inside of fuel filler cap).
- Continue driving carefully to the nearest ŠKODA specialist garage at a maximum speed of 80 km/h (50 mph).

Jump-starting

Introduction

This chapter contains information on the following subjects:

Jump-starting	165
Jump-starting in vehicles with the START-STOP system	166

The battery of another vehicle can be used to jump-start your vehicle if the engine will not start because the battery is flat. Jump-start cables are required for this purpose.

Both batteries must have a rated voltage of 12 V. The **capacity** (Ah) of the battery supplying the power must not be significantly less than the capacity of the discharged battery in your vehicle.

Jump-start cables

Only use jump-start cables which have an adequately large cross-section and insulated terminal clamps. Observe the manufacturer's instructions.

Positive cable - colour coding in the majority of cases is red.

Negative cable - colour coding in the majority of cases is black.

! WARNING

- A discharged vehicle battery may already freeze at temperatures just below 0 °C. In case of frozen battery carry out no jump-starting - risk of explosion!
- Pay attention to the warning instructions relating to working in the engine compartment » [page 138, Engine compartment](#).
- The non-insulated parts of the terminal clamps must never make contact with each other. In addition, the jump-start cable connected to the positive terminal of the battery must not come into contact with electrically conducting parts of the vehicle - risk of short circuit!
- Do not clamp the jump-start cable to the negative terminal of the discharged battery. There is the risk of detonating gas seeping out the battery being ignited by the strong spark which results from the engine being started.
- Route the jump-start cables so that they cannot be caught by any rotating parts in the engine compartment.
- Do not bend over the battery - risk of caustic burns!
- The vent screws of the battery cells must be tightened firmly.

! WARNING (Continued)

- Keep any sources of ignition (naked flame, smouldering cigarettes, etc.) away from the battery - risk of an explosion!
- Never jump-start vehicle batteries with an electrolyte level that is too low - risk of explosion and caustic burns.

i Note

- There must not be any contact between the two vehicles otherwise current may flow as soon as the negative terminals are connected.
- The discharged battery must be properly connected to the system of the vehicle.
- We recommend you buy jump-start cables from a car battery specialist.

Jump-starting




Fig. 138
Jump-starting using the battery from another vehicle: A - flat vehicle battery, B - battery providing current

First read and observe the introductory information and safety warnings ! on page 165.

The jump-start cables must be attached in the following sequence.

Connecting positive terminals

- Attach one end [1] » Fig. 138 to the positive terminal of the discharged battery [A].
- Attach the other end [2] to the positive terminal of the battery supplying the power [B].

Connecting negative terminal and engine block

- Attach one end [3] » Fig. 138 to the negative terminal of the battery supplying the power [B].

- Attach the other end **4** to a solid metal part which is connected firmly to the engine block, or to the engine block itself.

Starting engine

- Start the engine on the vehicle providing the power and allow it to idle.
- Now start the engine of the vehicle with the discharged battery.
- If the engine does not start, terminate the attempt to start the engine after 10 seconds and wait for about 30 seconds before repeating the process.
- Disconnect the cables in exactly the **reverse order** to the one described above. ■

Jump-starting in vehicles with the START-STOP system




Fig. 139
Jump-starting - START-STOP system

First read and observe the introductory information and safety warnings **! on page 165.**

On vehicles with the START-STOP system, the jump-start cable of the charger must never be connected directly to the negative pole of the vehicle battery, but only to the engine earth » Fig. 139. ■

Towing the vehicle

Introduction

This chapter contains information on the following subjects:

Front towing eye	_____	167
Rear towing eye	_____	167

Vehicles with manual transmission can be towed in with a tow bar or a tow rope or with the front or rear wheels raised.

Vehicles with automatic transmission can be towed in with a tow bar or a tow rope or with the front wheels raised. If the vehicle is raised at rear, the automatic gearbox is damaged!

A **tow bar** is the safest way of towing a vehicle and also minimises any shocks. Only use a **tow rope** if a suitable tow bar is not available.

When towing, the following guidelines must be observed.

Driver of the tow vehicle

- Release the clutch particularly gently when starting off or depress the accelerator particularly gently if the vehicle is fitted with an automatic gearbox.
- On vehicles with a manual transmission, only push down on the accelerator pedal once the rope is taugt.

The maximum towing speed is **50 km/h**.

Driver of the towed vehicle

- Switch on the ignition so that the steering wheel is not blocked and so that the turn signal lights, horn, windscreen wipers and windscreen washer system can be switched on.
- Take the vehicle out of gear or move the selector lever into position **N** if the vehicle is fitted with an automatic gearbox.

Please note that the brake servo unit and power steering only operate if the engine is running. If the engine is not running, significantly more physical force is required to depress the brake pedal and steer the vehicle.

If using a tow rope, ensure that it is always kept taugt.

CAUTION

- Do not tow start the engine - danger of damaging the engine! On vehicles with a catalytic converter, unburnt fuel may get into the catalytic converter where it may ignite. This in turn may damage or destroy the catalytic converter. The battery from another vehicle can be used as a jump-start aid » page 165, *Jump-starting*.
- If the gearbox of your vehicle no longer contains any oil because of a defect, your vehicle must only be towed in with the driven wheels raised clear of the ground, or on a special vehicle transporter or trailer.
- The vehicle must be transported on a special vehicle or trailer if it is not possible to tow in the vehicle in the way described or if the towing distance is greater than 50 km.
- To protect both vehicles when tow-starting or towing, the tow rope should be elastic. Thus one should only use plastic fibre rope or a rope made out of a similarly elastic material. ▶

- One should be constantly vigilant not to allow impermissibly high towing forces or jerky loadings. There is always a risk of excessive stresses and damage resulting at the points to which you attach the tow rope or tow bar when you attempt to tow a vehicle which is not standing on a paved road.
- Attach the tow rope or the tow bar to the **towing eyes** or to the **detachable ball head of the towing device** » page 167 or » page 167.

i Note

- We recommend using a tow rope from ŠKODA Original Accessories available from a ŠKODA Service Partner.
- Towing another vehicle requires a certain amount of practice. Both drivers should be familiar with the particular points about towing a vehicle. Unskilled drivers should not attempt to tow in another vehicle or to be towed in.
- When towing, respect the national legal provisions, especially those which relate to the identification of the towing vehicle and the vehicle being towed.
- The tow rope must not be twisted as it may in certain circumstances result in the front towing eye being unscrewed out of your vehicle.

Front towing eye




Fig. 140 Front bumper: Cap/installing the towing eye

First read and observe the introductory information and safety warnings **i** on page 166.

Remove the cap carefully as follows.

- Press on the left half of the cap in the area of the arrow » Fig. 140 - A.
- Remove the cap from the front bumper.

- Screw in the towing eye by hand to the left up to the stop » Fig. 140 - B. For tightening purposes, we recommend, for example, using the wheel wrench, towing eye from another vehicle or a similar object that can be pushed through the eye.
- In order to reinstall the cap after screwing out the towing eye, insert it in the mounts and then press on the right side of the cap. The cap must engage firmly.

! CAUTION

The towing eye must always be screwed in fully and firmly tightened, otherwise the towing eye can tear when towing in or tow-starting.

Rear towing eye



Fig. 141
Rear towing eye

First read and observe the introductory information and safety warnings **i** on page 166.

The rear towing eye is located below the rear bumper on the right » Fig. 141.

Fuses and light bulbs

Fuses

Introduction

This chapter contains information on the following subjects:

Fuses in the dash panel _____ 169

Fuses in the engine compartment _____ 170

Individual electrical circuits are protected by fuses.

- Before replacing a fuse, switch off the ignition and the appropriate consumer
- Find out which fuse belongs to the component that is not operating » [page 169, Fuses in the dash panel](#) or » [page 170, Fuses in the engine compartment](#).
- Take the plastic clip out of its fixture in the cover of the fuse box, place it on the relevant fuse and pull it out.
- A blown fuse is recognisable by the molten metal strip. Replace the faulty fuse with a new one of the **same** amperage.

Colour coding of fuses

Colour	Maximum amperage
light brown	5
dark brown	7.5
red	10
blue	15
yellow	20
white	25
green	30

WARNING

Always read and observe the warnings before completing any work in the engine compartment » [page 138, Engine compartment](#).

CAUTION

- Never "repair" fuses and also do not replace them with a fuse of a higher amperage - risk of fire! This may also cause damage at another part of the electrical system.
- Have the electrical system checked as quickly as possible by a ŠKODA specialist garage if a newly inserted fuse blows again after a short time.

Note

- We recommend always carrying replacement fuses in the vehicle. A box of replacement fuses can be purchased from ŠKODA Original Accessories.
- Multiple fuses may exist for a single power consuming device.
- Multiple power consuming devices can share a single fuse.

Fuses in the dash panel



Fig. 142
Underside of the dash panel:
Distribution board cover.




Fig. 143 Schematic representation of the fuse box for vehicles with left-hand steering/right-hand steering

 First read and observe the introductory information and safety warnings  on page 168.

The fuses are located on the left side of the dash panel behind a cover.

- Carefully remove the cover in the direction of the arrow » Fig. 142.
- After the fuse has been replaced, replace the cover in the dash panel in the opposite direction of the arrow so that the guide lugs are guided into the openings of the dash panel. Close the cover until it clicks into place.

Fuse assignment in the dash panel

No.	Power consumer
1	S-contact
2	START-STOP, air-conditioning system
3	Instrument cluster, headlamp beam adjustment

No.	Power consumer
4	Control unit for ABS, button for START STOP
5	Petrol engine: Speed regulating system
6	Reversing light (manual gearbox)
7	Ignition, engine control unit, automatic gearbox
8	Brake pedal switch, clutch pedal switch
9	Operating controls for the heating, control unit for air conditioning system, parking aid, control unit for cornering lights, radiator fan, washing nozzles
10	Windscreen Wiper and Washer System
11	Mirror adjustment
12	Control unit for trailer detection
13	Control unit for automatic gearbox
14	Motor for halogen projector headlights with cornering light function
15	PDA navigation system
16	Electrohydraulic power steering
17	START-STOP (radio), daylight driving light
18	Mirror heater
19	S-contact
20	Alarm
21	Reversing light, fog lights with the function CORNER
22	Operating controls for the heating, control unit for air conditioning system, parking aid, mobile phone, instrument cluster, steering angle sender, ESC, vehicle voltage control unit, multifunction steering wheel
23	Interior lighting, storage compartment and luggage compartment, side lights
24	Central control unit
25	Seat heaters
26	Rear window wiper
27	Telephone preinstallation
28	Petrol engine: AKF valve, Diesel engine: Control flap
29	Injection, coolant pump
30	Fuel pump, ignition, Cruise control system, operation of PTC relay
31	Lambda probe

No.	Power consumer
32	High pressure fuel pump, pressure valve
33	Engine control unit
34	Engine control unit, vacuum pump
35	Power supply of ignition lock
36	Main beam
37	Rear fog light, DC/DC converter START-STOP
38	Fog lights
39	Air blower for heating
40-41	Not assigned
42	Rear window heater
43	Horn
44	Windscreen wipers
45	Central control unit for convenience system
46	Engine control unit, fuel pump
47	Cigarette lighter, power socket in the luggage compartment
48	ABS, START-STOP (DC/DC) converter ESP
49	Turn signal lights, brake lights
50	START-STOP (DC/DC) converter infotainment, radio
51	Electrical power window (front and rear) - left side
52	Electrical power window (front and rear) - right side
53	Parking light = left side, electrical sliding/tilting roof
54	START-STOP (instrument cluster), alarm
55	Control unit for automatic gearbox
56	Headlight cleaning system, parking light - right side
57	Left low beam, headlight range adjustment
58	Low beam on the right

Fuses in the engine compartment




Fig. 144 Vehicle battery: Distribution board cover.






Fig. 145 Schematic representation of fuse box in engine compartment

 First read and observe the introductory information and safety warnings  on page 168.

- Press together the circlips in the fuse box cover at the same time in the direction of arrow **A** » Fig. 144 and remove the cover in the direction of arrow **B**.
- Release the fixtures in the openings **C** using a flat screwdriver and fold the cover upwards in direction of arrow **D**.

Fuse assignment in engine compartment

No.	Power consumer
1	Generator
2	Not assigned
3	Interior
4	Electrical auxiliary heating system
5	Interior

No.	Power consumer
6	Glow plugs, radiator fan
7	Electrohydraulic power steering
8	ABS or TCS or ESC
9	Radiator fan
10	Automatic gearbox
11	ABS or TCS or ESC
12	Central control unit
13	Electrical auxiliary heating system

Note

Fuses 1 - 7 are replaced by a specialist ŠKODA garage.

Bulbs

Introduction

This chapter contains information on the following subjects:

Headlights	172
Replacing a bulb for low beam and main beam (halogen headlights)	172
Replacing a bulb for low beam and main beam Halogen projector headlights)	173
Replacing the bulb for the main beam (Halogen projector headlights)	173
Changing the bulb for the front turn signal light	173
Changing the light bulb for the front parking light	173
Fog lights and daytime running lights	174
Fog lights Fabia Scout, Fabia RS	174
Licence plate light	175
Tail lamp assembly	175

Some manual skills are required to change a bulb. For this reason, if uncertain, we recommend that bulbs are replaced by a ŠKODA specialist garage or other expert help is sought.

- Switch off the ignition and all of the lights before replacing a bulb.
- Faulty bulbs must only be replaced with the same type of bulbs. The designation is located on the light socket or the glass bulb.
- A stowage compartment for replacement bulbs is located in a plastic box in the spare wheel or underneath the floor covering in the boot.

WARNING

- Accidents can be caused if the road in front of the vehicle is not sufficiently illuminated and the vehicle cannot or can only be seen with difficulty by other road users.
- Always read and observe the warnings before completing any work in the engine compartment » [page 138](#), *Engine compartment*.
- Bulbs H7 and H4 are pressurised and may burst when changing the bulb - risk of injury! We therefore recommended wearing gloves and safety glasses when changing a bulb.

CAUTION

- Do not take hold of the glass bulb with naked fingers (even the smallest amount of dirt reduces the working life of the light bulb). Use a clean cloth, napkin, or similar.
- When removing and installing the tail light make sure that the paintwork of the vehicle and the tail light are not damaged.

Note

- This Owner's Manual only describes the replacement of bulbs where it is possible to replace the bulbs on your own without any complications arising. Other light bulbs should be changed by a ŠKODA specialist garage.
- We recommend that a box of replacement bulbs be always carried in the vehicle. Replacement bulbs can be purchased from ŠKODAOriginal Accessories.
- We recommend that the headlight settings are checked by a ŠKODA specialist garage after replacing a bulb in the main or low beam.
- LED diodes should be changed by a specialist ŠKODA garage.

Headlights





Fig. 146 Bulb arrangement: Halogen headlights/halogen projector headlights

 First read and observe the introductory information and safety warnings **I** on page 171.

Bulb arrangement in the Halogen headlamp

A - low beam, main beam and side lights

B - front turn signal light

Bulb arrangement in the Halogen projector headlights

1 - low beam/low and main beam

2 - Parking light/parking and main beam lights

3 - front turn signal light

Replacing a bulb for low beam and main beam (halogen headlights)





Fig. 147
Removing bulbs for low and main beam

 First read and observe the introductory information and safety warnings **I** on page 171.

- Remove the rubber cover **A** » Fig. 146 on page 172.
- Remove the connector on the bulb, unlock the circlip, and remove the light bulb » Fig. 147.
- Insert a new light bulb in such a way that the fixing lugs of the bulb socket fit in the recesses of the reflector.
- Lock the circlip and insert the connector in the bulb.
- Insert the rubber cover.

Replacing a bulb for low beam and main beam Halogen projector headlights)







Fig. 148
Removing bulbs for low beam/
low and main beam

 First read and observe the introductory information and safety warnings  on page 171.

- Remove the rubber cover  » Fig. 146 on page 172.
- Turn the connector with the bulb in **anti-clockwise** direction up to the stop » Fig. 148 and remove it.
- Replace the lamp, insert the connector with the new bulb and turn **clockwise** up to the stop.
- Insert the rubber cover.

Replacing the bulb for the main beam (Halogen projector headlights)








Fig. 149
Removing the bulb for the main
beam

 First read and observe the introductory information and safety warnings  on page 171.

- Remove the rubber cover  » Fig. 146 on page 172.
- Turn the connector with the bulb in **anti-clockwise** direction up to the stop » Fig. 149 and remove it.
- Replace the lamp, insert the connector with the new bulb and turn **clockwise** up to the stop.
- Insert the rubber cover.




Changing the bulb for the front turn signal light

 First read and observe the introductory information and safety warnings  on page 171.

- Remove the socket  » Fig. 146 on page 172 or the socket  up to the stop in an **anti-clockwise** direction and remove along with the bulb for the turn signal light.
- Replace the bulb, insert the socket with the new bulb and turn **clockwise** up to the stop.

Changing the light bulb for the front parking light

 First read and observe the introductory information and safety warnings  on page 171.

- Remove the rubber cover  » Fig. 146 on page 172 and , .
- Grasp the lamp holder and remove it from the bulb housing.
- Replace the light bulb and insert the lamp holder back into the headlamp with the bulb.
- Insert the rubber cover.

Fog lights and daytime running lights




Fig. 150 Front bumper: Protective grille/removing the fog light

First read and observe the introductory information and safety warnings on page 171.

Bulb arrangement » Fig. 150.

A - Bulb for daylight driving light

B - Light bulb for fog lights

Removing the cap

» Grasp the protective grille in the areas marked by the arrows » Fig. 150 - **A** and remove the cover.

Replacing light bulbs for fog lights/daytime running lights

- » Insert your hand into the opening in the protective grille and press the catch » Fig. 150 - **B** in the direction of the arrow.
- » Remove the front fog lamp.
- » Turn the connector with the bulb in **counter-clockwise** up to the stop and remove.
- » Replace the lamp, insert the connector with the new bulb and turn **clockwise** up to the stop.
- » To re-install the fog light, first of all place the fog light with the lug on the side opposite the licence plate.
- » Press in the fog lamp on the side closest to the licence plate.
- » Insert the cap, beginning with the lug on the side opposite the license plate.
- » Press in the cap on the side facing the license plate. The cap must engage firmly.

Fog lights Fabia Scout, Fabia RS




Fig. 151 Front bumper: Fabia Scout/Fabia RS




Fig. 152 Front bumper: Fog lights/fog lights: Replacing the light bulb

First read and observe the introductory information and safety warnings on page 171.

Removing the cap and fog light

- » Guide the wire clamp into the opening above the fog light » Fig. 151 - **A** (Fabia Scout) » page 158, *Vehicle tool kit* and remove the cover.
- » Insert a finger into the opening next to the foglight » Fig. 151 - **B** (Fabia RS) and remove the cap.
- » Use the screwdriver » page 158, *Vehicle tool kit* to remove the screws » Fig. 152 - **A**.
- » Remove the front fog lamp.


Changing light bulbs and installing fog lights

- Press the locking button **1** » Fig. 152 of the plug **A** and remove the plug from the socket **B**.
- Turn the socket **B** with the bulb counter-clockwise **up** to the stop and remove.
- Replace the bulb, insert the socket with the new bulb and turn **clockwise** up to the stop.
- Insert the plug **A** into the socket **B**.
- Retighten the screws and insert the cap. The cap must engage firmly.

Licence plate light



Fig. 153
Boot lid: Licence plate light

 First read and observe the introductory information and safety warnings **!** on page 171.

- Insert a flat screwdriver into the opening in the area of the arrow » Fig. 153 and carefully press towards the centre of the lamp, by doing so the lamp jumps out slightly.
- Remove the lamp.
- Remove the faulty bulb from the holder and insert a new one.
- Replace the glass cover and push in until the stop. Make sure that you install the glass cover in the correct position.

Tail lamp assembly




Fig. 154 Remove the rear light/install the tail light assembly:




Fig. 155
Tail light assembly: Bulb arrangement

 First read and observe the introductory information and safety warnings **!** on page 171.

Bulb arrangement in the tail light assembly » Fig. 155

- 1** - Rear fog light/Reversing light
- 2** - Turn signal lights
- 3** - Brake lights
- 4** - parking lights

Removing and installing the tail light

- Open the boot lid.
- Hold the tail light assembly in the installation position with one hand, and remove the plastic nut » Fig. 154 - **A** with the other.

- Grip the tail lamp assembly and carefully remove it by pulling it back at an angle with loosening movements. Do not pull the grommet with the cables out of the bodywork.
- To re-install the tail light assembly, first of all guide it with the screw **A** into the opening of the bodywork » Fig. 154.
- Carefully press the tail light assembly into the bodywork so that the bolts **B** latch with the mounts in the body.
- Hold the tail light assembly with one hand, and attach and tighten the nuts » Fig. 154 - **A** with the other hand.

Replacing the bulbs in the tail lamp assembly

- To replace the bulb, turn the bulb holder **anti-clockwise** up to the stop and remove it from the housing » Fig. 155.
- Replace the bulb, insert the holder with the bulb into the housing and turn in a **clockwise direction** to the the stop.

i Note

For slackening and tightening the plastic nut use a coin or similar object. ■

Technical data

Technical data

Introductory information

The details given in the vehicle's technical documentation always take precedence over the details in the Owner's Manual. Please refer to the official vehicle registration documents or consult a ŠKODA Service Partner to determine which engine your vehicle is equipped with.

The listed performance values were determined without performance-reducing equipment, e.g. air conditioning system.

Vehicle identification number (VIN)

The vehicle identification number - VIN (vehicle body number) is stamped into the engine compartment on the right hand suspension strut dome. This number is also located on a sign on the lower left hand edge below the windscreen (together with a VIN bar code).

Engine number

The engine number is stamped into the engine block.

Data on the vehicle sticker and the type plate




Fig. 156 Vehicle data sticker/type plate

Vehicle data sticker

The vehicle data sticker » Fig. 156 is located on the floor of the boot and is also stated in the service schedule.

The vehicle data sticker contains the following data:

- 1 Vehicle identification number (VIN)
- 2 Vehicle type
- 3 Gearbox code/paint number/interior equipment/engine output/engine code
- 4 Partial vehicle description
- 5 Operating weight (in kg)
- 6 Fuel consumption (in ltr./100 km) - intra-urban/extra-urban/combined
- 7 CO₂ emission levels - combined (in g/km)

Type plate

The type plate » Fig. 156 is located on the lower part of the column between the front and rear doors on the front passenger's side.

The type plate lists the following weights:

- 8 Maximum permissible gross weight
- 9 Maximum permissible towed weight (towing vehicle and trailer)
- 10 Maximum permissible front axle load
- 11 Maximum permissible rear axle load

Operating weight

The specified operating weight is for orientation purposes only. This value represents the minimum operating weight without additional weight-increasing equipment such as air conditioning system, spare wheel, or trailer hitch.

The operating weight also contains the weight of the driver (75 kg), the weight of the operating fluids, the tool kit, and a fuel tank filled to 90 % capacity.

It is possible to calculate the approximate loading capacity from the difference between the permissible total weight and the operating weight » **!**

The payload consists of the following components:

- ▶ Passengers
- ▶ All items of luggage and other loads
- ▶ Roof load including roof rack system
- ▶ Equipment not included in the operating weight
- ▶ Trailer drawbar load when towing a trailer (max. 50 kg).

Measuring fuel consumption according to ECE standards and EU guidelines

The measurement of the intra-urban cycle begins with a cold start of the engine. Afterwards urban driving is simulated.

In the extra-urban driving cycle, the vehicle is accelerated and decelerated in all gears, corresponding to daily routine driving conditions. The driving speed varies between 0 and 120 km/h.

The calculation of the combined fuel consumption considers a weighting of about 37 % for the intra-urban cycle and 63 % for the extra-urban cycle.

! WARNING

Do not exceed the specified maximum permissible weights - risk of accident and damage.

i Note

- If required, you can find out the precise weight of your vehicle by contacting a ŠKODA Service Partner.
- Depending on the range of equipment, style of driving, traffic situation, weather influences and vehicle condition, consumption values may deviate from the indicated values.

Dimensions

Dimensions (mm)

	FABIA	FABIA GreenLine	FABIA SCOUT	FABIA RS	ESTATE	ESTATE GreenLine	ESTATE SCOUT	ESTATE RS
Length	4000	4000	4032	4029	4247	4247	4275	4276
Width	1642	1642	1658	1642	1642	1642	1658	1642
Width including exterior mirror	1886	1886	1886	1886	1886	1886	1886	1886
Height	1498/1513 ^{a)} 1484 ^{b)}	1484	1498/1513 ^{a)} 1484 ^{b)}	1492	1498/1513 ^{a)} 1484 ^{b)}	1484	1498/1513 ^{a)} 1484 ^{b)}	1494
Clearance	134/149 ^{a)} /119 ^{b)}	119	134	129	135/149 ^{a)} /119 ^{b)}	119	135	129
Wheel base	2465	2465	2465	2464	2465	2465	2465	2464
Track gauge front/rear	1433/1426	1417/1410	1433/1426	1423/1415	1433/1426	1417/1410	1433/1426	1423/1415

^{a)} The value corresponds to the status with the rough road package.

^{b)} The value corresponds to the status with the sport chassis.

Specifications and engine oil capacity

The engine has been factory-filled with a high-grade oil that can be used throughout the year - except in extreme climate zones.

Various oils can be mixed together when refilling. However, this does not apply to vehicles with flexible service intervals.

Engine oils are, of course, undergoing continuous further development. Thus the information stated in this Owner's Manual is only correct at the time of publication.

ŠKODA Service Partners are informed about the latest changes by ŠKODA. We therefore recommend that the oil change is completed by a ŠKODA Service Partner.

The specifications (VW standards) stated in the following can be indicated separately or together with other specifications on the bottle.

The oil capacities include oil filter change. Check the oil level when filling; do not over fill. The oil level must be between the markings » [page 141](#).

Specifications and capacity (in l) for vehicles with flexible service intervals

Petrol engines	Specification	Filling level
1.2 l/44 kW	VW 503 00, VW 504 00	2.8
1.2 l/51 kW	VW 503 00, VW 504 00	2.8
1.4 l/63 kW	VW 503 00, VW 504 00	3.2
1.4 ltr./132 kW TSI	VW 504 00	3.6
1.2 ltr./63 kW TSI	VW 504 00	3.6
1.2 ltr./77 kW TSI	VW 504 00	3.6

Diesel engines	Specification	Filling level
1.2 ltr./55 kW TDI CR DPF	VW 507 00	4.3
1.6 ltr./55 kW TDI CR DPF	VW 507 00	4.3
1.6 ltr./66 kW TDI CR DPF	VW 507 00	4.3
1.6 ltr./77 kW TDI CR DPF	VW 507 00	4.3

Specifications and capacity (in l) for vehicles with fixed service intervals

Petrol engines	Specification	Filling level
1.2 l/44 kW	VW 501 01, VW 502 00	2.8
1.2 l/51 kW	VW 501 01, VW 502 00	2.8

Petrol engines	Specification	Filling level
1.4 l/63 kW	VW 501 01, VW 502 00	3.2
1.6 l/77 kW	VW 501 01, VW 502 00	3.6
1.4 ltr./132 kW TSI	VW 502 00	3.6
1.2 ltr./63 kW TSI	VW 502 00	3.6
1.2 ltr./77 kW TSI	VW 502 00	3.6

If the oils specified above are not available, oils according to ACEA A2 or ACEA A3 can be used once for refilling.

Diesel engines	Specification	Filling level
1.2 ltr./55 kW TDI CR DPF	VW 507 00	4.3
1.6 ltr./55 kW TDI CR DPF	VW 507 00	4.3
1.6 ltr./66 kW TDI CR DPF	VW 507 00	4.3
1.6 ltr./77 kW TDI CR DPF	VW 507 00	4.3

If the oils specified above are not available, oils according to ACEA B3 or ACEA B4 can be used once for refilling.

CAUTION

Only the above-mentioned oils can be used on vehicles with flexible service intervals. We recommend always refilling with oil of the same specification since this will maintain the properties of the oil. In exceptional cases, a maximum of 0.5 l of specification VW 502 00 (only for petrol engines) or specification VW 505 01 (only for diesel engines) engine oil can be used to refill once. Other engine oils must not be used - risk of engine damage!

Note

- Before a long drive we recommend that you purchase and carry with you engine oil which complies with the specification for your vehicle.
- We recommend that you use oils from ŠKODA Original Accessories.

Vehicle-specific details per engine type

1.2 ltr./44 kW engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
44/5200	108/3000	3/1198

Performances	FABIA	ESTATE
Top speed (km/h)	155	156
Acceleration 0 - 100 km/h (s)	16.5	16.7
Permissible trailer load, braked (kg)	800 ^{a)} /900 ^{b)}	
Permissible trailer load, unbraked (kg)	540/500 ^{c)}	550/450 ^{c)}

^{a)} Uphills up to 12 %

^{b)} Uphills up to 8 %

^{c)} Vehicles without ABS.

1.2 ltr./51 kW engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
51/5400	112/3000	3/1198

Performances	FABIA	ESTATE
Top speed (km/h)	163	164
Acceleration 0 - 100 km/h (s)	14.9	15.0
Permissible trailer load, braked (kg)	800 ^{a)} /900 ^{b)}	
Permissible trailer load, unbraked (kg)	540/500 ^{c)}	550/450 ^{c)}

^{a)} Uphills up to 12 %

^{b)} Uphills up to 8 %

^{c)} Vehicles without ABS.

1.2 ltr./63 kW TSI engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
63/4800	160/1500-3500	4/1197

Performances	FABIA	ESTATE
Top speed (km/h)	177	178
Acceleration 0 - 100 km/h (s)	11.7	11.8
Permissible trailer load, braked (kg)	1100 ^{a)} /1200 ^{b)}	
Permissible trailer load, unbraked (kg)	550/500 ^{c)}	560/450 ^{c)}

^{a)} Uphills up to 12 %

^{b)} Uphills up to 8 %

^{c)} Vehicles without ABS.

1.2 ltr./77 kW TSI engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
77/5000	175/1500-4100	4/1197

Performances	FABIA MG5	FABIA DSG7	COMBI MG5	COMBI DSG7
Top speed (km/h)	191	189	193	190
Acceleration 0 - 100 km/h (s)	10.1	10.2	10.2	10.3
Permissible trailer load, braked (kg)	1200			
Permissible trailer load, unbraked (kg)	560/500 ^{a)}	580/500 ^{a)}	570/450 ^{a)}	590/450 ^{a)}

^{a)} Vehicles without ABS.

1.4 ltr./63 kW engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
63/5000	132/3800	4/1390

Performances	FABIA	ESTATE
Top speed (km/h)	175	176
Acceleration 0 - 100 km/h (s)	12.2	12.3
Permissible trailer load, braked (kg)	1000 ^{a)} /1200 ^{b)}	
Permissible trailer load, unbraked (kg)	550/500 ^{c)}	560/450 ^{c)}

^{a)} Uphills up to 12 %

^{b)} Uphills up to 8 %

^{c)} Vehicles without ABS.

1.6 ltr./77 kW engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
77/5600	153/3800	4/1598

Performances	FABIA MG5	FABIA AG6	COMBI MG5	COMBI AG6
Top speed (km/h)	190	185	192	186
Acceleration 0 - 100 km/h (s)	10.4	11.5	10.5	11.6
Permissible trailer load, braked (kg)	1000 ^{a)} /1200 ^{b)}			
Permissible trailer load, unbraked (kg)	550/500 ^{c)}	570/500 ^{c)}	560/450 ^{c)}	580/450 ^{c)}

^{a)} Uphills up to 12 %

^{b)} Uphills up to 8 %

^{c)} Vehicles without ABS.

1.4 ltr./132 kW TSI engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
132/6200	250/2000-4500	4/1390

Performances	FABIA RS	ESTATE RS
Top speed (km/h)	224	226
Acceleration 0 - 100 km/h (s)	7.3	

1.2 ltr./55 kW TDI CR DPF engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
55/4200	180/2000	3/1199

Performances	FABIA	FABIA GreenLine	ESTATE	ESTATE GreenLine
Top speed (km/h)	166	172	167	172
Acceleration 0 - 100 km/h (s)	14.2	14.2	14.3	14.3
Permissible trailer load, braked (kg)	1000 ^{a)} /1200 ^{b)}			
Permissible trailer load, unbraked (kg)	590/500 ^{d)}		600/450 ^{d)}	

a) Uphills up to 12 %

b) Uphills up to 8 %

c) Vehicles without ABS.

1.6 ltr./55 kW TDI CR engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
55/4000	195/1500-2000	4/1598

Performances	FABIA	ESTATE
Top speed (km/h)	166	167
Acceleration 0 - 100 km/h (s)	14.1	14.2
Permissible trailer load, braked (kg)	1000 ^{a)} /1200 ^{b)}	
Permissible trailer load, unbraked (kg)	600/500 ^{c)}	610/450 ^{c)}

^{a)} Uphills up to 12 %

^{b)} Uphills up to 8 %

^{c)} Vehicles without ABS.

1.6 ltr./66 kW TDI CR engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
66/4200	230/1500-2500	4/1598

Performances	FABIA	ESTATE
Top speed (km/h)	176	177
Acceleration 0 - 100 km/h (s)	12.6	12.7
Permissible trailer load, braked (kg)	1200	
Permissible trailer load, unbraked (kg)	600/500 ^{a)}	610/450 ^{a)}

^{a)} Vehicles without ABS.

1.6 ltr./77 kW TDI CR engine

Output (kW per rpm)	Max. torque (Nm at rpm)	Number of cylinders/Displacement (cm ³)
77/4400	250/1500-2500	4/1598

Performances	FABIA	ESTATE
Top speed (km/h)	188	190
Acceleration 0 - 100 km/h (s)	10.9	11.0
Permissible trailer load, braked (kg)	1200	
Permissible trailer load, unbraked (kg)	600/500 ^{a)}	610/450 ^{a)}

^{a)} Vehicles without ABS.

Index

A

ABS	84
Warning light	21
Accessories	157
Adjusting	
Exterior mirror	48
Adjusting seats	104
Adjustment	
Seats	50
Aerial	130
see Radio reception	132
Airbag	111
Deployment	111
Front airbag	112
Head airbag	114
Side airbag	113
Airbag system	111
Air conditioning system	
Air outlet vents	71
Climatronic	76
Manual air conditioning system	73
Alarm	31
Anti-theft alarm system	31
Antilock brake system	84
Armrest	68
Ashtray	64
Assistance systems	
ESC	83
Assist systems	
ABS	21, 84
Cruise control systems (CCS)	86
EDS and XDS	84
ESC	20
Parking aid	85
START/STOP	88
TCS	21, 84

Auto Check Control	16
Automatic gearbox	90
Dynamic shift programme	93
Emergency programme	94
Information for driving	90
Kickdown	93
Manual shifting of gears on the multifunction steering wheel	92
Parking	91
Selector lever-emergency unlocking	94
Selector lever lock	93
Selector lever positions	91
Starting off	91
Stopping	91
Tiptronic	92
Automatic load deactivation	149
AUX-IN	102
Avoiding damage to your vehicle	125

B

Before setting off	103
Belts	107
Belt tensioners	110
Bicycle carrier	60
Bonnet	
Closing	140
Opening	140
Boot	
Class N1 vehicles	54
Cover	55
Emergency unlocking	33
Fastening elements	54
Fixing nets	55
foldable boot cover (Combi)	56
Folding hooks	54
Light	44
see Boot lid	33
Unlocking the boot lid	33
Boot lid	33
Automatic locking	33

Brake assist	83
Brake booster	83
Brake fluid	
Checking	144
Brakes	
Brake booster	83
Handbrake	83
Running in	121
Warning light	18

Braking	
Brake fluid	144
Breakdown kit	162
Bulbs	
Replacing	171
Button in the driver's door	
Electrical power windows	34

C

Car computer	
see Multifunction display	12
Car jack	158
Carrier	62
Catalytic converter	121
Central locking button	29
Central locking system	27
lock	28
unlock	28
Changes	157
Changing	
Engine oil	142
Wheel	159
Charging a vehicle battery	148
Checking	
Battery electrolyte level	147
Brake fluid	144
Coolant level	143
Engine oil	141
Oil level	141
Windscreen washer fluid	145

Children and safety _____	117	Counter for distance driven _____	10	Central locking system _____	35
Child safety		Cruise control system (CCS) _____	86	Operational faults _____	35
Side airbag _____	118	Cup holders _____	63	Electric sliding/tilting roof _____	36
Child safety lock _____	26			Electronic Differential Lock _____	84
Child seat		D		Electronic immobiliser _____	80
Classification _____	118	Daylight driving light _____	39	Emergency	
ISOFIX _____	119	Deactivating an airbag _____	115	Automatic gearbox _____	94
on the front passenger seat _____	117	Defrosting rear window _____	44	Changing a wheel _____	159
Suitability _____	119	Delayed locking of the boot lid		Hazard warning light system _____	42
TOP TETHER _____	119	see Boot lid _____	33	Jump-starting _____	165
Chrome parts		Diesel		locking of the doors _____	32
refer to Taking care of your vehicle _____	131	refer to Fuel _____	138	Selector lever-unlocking _____	94
Cigarette lighter _____	64	Diesel fuel		Sliding roof _____	37
Cleaning _____	129	Operation in winter _____	138	Towing the vehicle _____	166
Artificial leather _____	134	Diesel particulate filter _____	22	Tyre repair _____	162
Headlight lenses _____	132	Digital clock _____	11	Unlocking the boot lid _____	33
Material coverings _____	134	Dipstick _____	141	Emissions _____	177
Materials _____	134	Display		Engine	
Natural leather _____	134	Coolant temperature _____	9	Running in _____	121
Plastic parts _____	131	Service interval _____	10	Starting and stopping the engine _____	79
Wheels _____	133	Distance driven _____	10	Starting engine _____	81
Climatronic		Door		Switching off the engine _____	81
Recirculated air mode _____	77	Child safety lock _____	26	Engine compartment	
Clock _____	11	Doors		Brake fluid _____	144
Clothes hooks _____	69	Emergency locking _____	32	Coolant _____	142
Cockpit		Driving		Overview _____	140
12-volt power socket _____	65	Abroad _____	125	Vehicle battery _____	145
Ashtray _____	64	Driving through water on the street _____	126	Engine oil	
Cigarette lighter _____	64	Emissions _____	177	Capacity _____	179
General view _____	7	Fuel consumption _____	177	Changing _____	142
Light _____	43	Maximum speed _____	180	Checking _____	141
Storage compartments _____	65			Replenishing _____	141
Compartments _____	65			Specification _____	179
Computer				Warning light _____	19
see Multifunction display _____	12	E		Engine revolutions counter _____	9
Coolant		Economical and environmentally friendly driving _____	122	Environment _____	122
Checking _____	143	EDS _____	84	Environmental compatibility _____	124
Indicator light _____	19	Electrical power windows		Environmentally friendly driving _____	122
Replenishing _____	143	Button in the driver's door _____	34	ESC	
Temperature gauge _____	9	Button in the rear door _____	34	Function _____	83
Correct seated position _____	104			Warning light _____	20

F

Fire extinguisher	158
First-aid kit	158
Floor mats	85
Front airbag	112
Front seats	49
Fuel	136
Diesel	138
Fuel gauge	9
gauge	9
refer to Fuel	136
Refuelling	136
Unleaded petrol	137
Fuel consumption	122
Fuses	
Assignment	168
Replacing	168

G

Gear	
Recommended gear	11
General view	
Cockpit	7
Glow plug system - indicator light	22
GSM	95

H

Handbrake	83
Head airbag	114
Headlight cleaning system	
Headlight cleaning system	46
Headlights	
Driving abroad	125
Headlight cleaning system	46
Head restraint	51

Heating	71
Defrosting windows	72
Exterior mirror	48
Rear window	44
Recirculated air mode	72
Seats	50
Heating rear window	44
Horn	7

I

Ignition	81
Ignition lock	81
Immobiliser	80
Information display	
see MAXI DOT	15
Instrument cluster	8
Interior monitor	31
ISOFIX	119

J

Jacking points	
Raise vehicle	161
Jump-starting	165

L

Lever	
Main beam	42
Turn signal	42
Light	
Cockpit	43
Daylight driving light	39
Fog lights	40
Fog lights with the function CORNER	40
Halogen projector headlights with cornering light function	39
Hazard warning light system	42
Headlight beam adjustment	41
Headlight flasher	42

Low beam	38
Main beam	42
Parking light	38, 39
Rear fog light	41
Replacing bulbs	171
Tourist light	40
Turn signal	42

Lights

switching on and off	38
Warning lights	17

Loads

variable loading floor	177
Lock	
Central locking system	28

Locking

Emergency locking	32
Remote control	30
without central locking	26
Locking and unlocking from the inside	29

Luggage compartment

variable loading floor	57
------------------------	----

M

MAXI DOT	15
Main menu	15
Settings	15
Maximum speed	180
MDI	102

Mirror

Additional interior mirror	47
Exterior mirror	48
Manual dimming interior mirror	47
Vanity	44

Mobile phone

Connecting to the hands-free system	97
-------------------------------------	----

Multifunction display

Functions	12
Memory	12
Operation	13

Multimedia

	101
--	-----

N		Radio reception		Safety	103
Net partition	58	Aerial	132	Child safety	117
O		Functional fault	132	Child safety seats	117
Oil		Raise vehicle	161	Head restraints	51
refer to Engine oil	141	Rear mirror		ISOFIX	119
Onboard computer		Exterior mirror	48	TOP TETHER	119
see Multifunction display	12	Manual dimming interior mirror	47	Save electrical energy	122
Operation in winter		Recirculated air mode		Seat	
De-icing windows	132	Manual air conditioning system	75	Adjusting	50
Diesel fuel	138	Recommended gear	11	Seat belt	
Vehicle battery	147	Refuelling	136	Warning light	18
Outside temperature	13	Fuel	136	Seat belt height adjuster	110
Overview		Regulation		Seat belts	107
Engine compartment	140	Headlight beam	41	Cleaning	135
Warning lights	17	Remote control	29	fastening and unfastening	109
		Synchronisation process	30	Height adjustment	110
P		Remote control key		Seats	
Paint		Replacing the battery	25	folding forward	52
see Paint damage	131	Replacement of parts	157	Head restraints	51
Paint damage	131	Replacing		Heating	50
Parking		bulbs	171	Removing the seats	52
Parking aid	85	Fuses	168	Selector lever	
Parking ticket holder	69	Vehicle battery	148	see selector lever positions	91
Passive Safety	103	Windscreen wiper blade	46	Selector lever positions	91
Periodic wiping	45	Replenishing		Service display	10
Petrol		Coolant	143	Setting	
refer to Fuel	137	Engine oil	141	Manual air conditioning system	75
Polishing the paintwork		Windscreen washer fluid	145	Manual dimming interior mirror	47
refer to Taking care of your vehicle	131	Roof luggage rack		Steering wheel	80
Power steering	80	Attachment points	63	Setting temperature	
Preservation		Roof rack system		Heating	71
refer to Taking care of your vehicle	131	Roof load	63	Setting the clock	
R		Running in		Clock	11
Radiator fan	144	Brake pads	121	Shifting	
		Engine	121	Diving economically	122
		The first 1 500 km	121	Gearshift lever	85
		Tyres	121	Side airbag	113
		S		Sliding/tilting roof	
		Safe securing system	27	see Electric sliding/tilting roof	36
				Snow chains	156

Spare wheel	153
Speedometer	9
START/STOP	
Function	88
Starting and stopping the engine	79
Starting engine	81
Jump-starting	165
START STOP	
Jump-starting	166
Steering force assistance	80
Steering wheel	80
Storage	65
Storage compartment	
Lighting	43
Storage compartments	65
Sun visors	44
Switching lights on and off	38
Switching off the engine	81

T

Taking care of the vehicle	
Artificial leather	134
Material coverings	134
Materials	134
Natural leather	134
Seat belts	135
Taking care of your vehicle	129
Automatic car wash system	130
Chrome parts	131
Cleaning the wheels	133
Door lock cylinders	132
Headlight lenses	132
High-pressure cleaner	130
Plastic parts	131
Polishing the paintwork	131
Preservation	131
Rubber seals	132
Washing	130
Washing by hand	130
Wash system	130

TCS	84
Warning light	21
Technical data	177
Telephone	95
Tilting roof	
see Electric sliding/tilting roof	36
Tiptronic	90
see automatic gearbox	92
Tool	158
TOP TETHER	119
Towing	166
Towing a trailer	127
Towing eye	167
Towing protection	31
Traction control system (TCS)	84
Trailer	127
Towing a trailer	127
Transport	
Boot	53
Roof rack system	62
Transporting children safely	117
Two-way radio systems	95
Type plate	177
Tyre repair	162
Tyres	
see Wheels and tyres	152

U

Underbody protection	133
unlock	
Central locking system	28
Unlocking	
Remote control	30
without central locking	26
Uphill start assist	83

V

Vehicle battery	
Automatic load deactivation	149
Charging	148
Checking the electrolyte level	147
Operation in winter	147
Replacing	148
Safety instructions	145
Vehicle Condition	
see Auto Check Control	16
Vehicle data sticker	177
Vehicle dimensions	178
Vehicle key	25
Vehicle tool kit	158
Visors	44

W

Warning lights	17
Warning symbols	
see Warning lights	17
Warning triangle	158
Washing	129
Automatic car wash system	130
by hand	130
Chrome parts	131
High-pressure cleaner	130
Weights	177
Wheel bolts	
Anti-theft wheel bolt	162
Caps	154
Loosening and tightening	161
Wheels	150
Wheels and tyres	
Changing a wheel	159
Full wheel trim	154
General information	150
Handling wheels and tyres	152
new tyres	152

Service life of tyres	151
Snow chains	156
Spare wheel	153
Wheel bolts	156
Winter tyres	156
Window convenience operation	35
Windows	
De-icing	132
See Electrical power windows	34
Windscreen	
see Radio reception	132
Windscreen washer fluid	
Checking	145
Replenishing	145
Warning light	23
Winter	145
Windscreen washer system	145
Windscreen wipers	45
Windscreen wiper	
Replacing the rear window wiper blade - Version	
1	46
Replacing the rear window wiper blade - Version	
2	47
Replacing the windscreen wiper blades	46
Windscreen wipers	
Activating	45
Cleaning the windscreen wiper blades	46
Windscreen washer fluid	145
Winter operation	
Snow chains	156
Winter tyres	
see Wheels and tyres	156

X

XDS	84
-----------	----

ŠKODA pursues a policy of constant product and model development. We trust that you will understand that changes to models in terms of shape, equipment and engineering, may be introduced at any time. The information about appearance, performances, dimensions, weight, standards and functions of the vehicle is correct at the time of publication. Certain items of equipment might only be installed at a later date (information provided by your local ŠKODA Service Partner) or are only offered in particular markets. It is therefore not possible for legal claims to be made based on the data, illustrations and descriptions contained in this Owner's Manual.

Reprinting, reproduction or translation, either in whole or in part, is not permitted without the written consent of ŠKODA.

ŠKODA expressly reserves all rights relating to copyright laws.

Subject to change.

Issued by: ŠKODA AUTO a.s.

© ŠKODA AUTO a.s. 2012

Minimisation of fuel consumption and CO₂ emissions

- Start-stop system*
- Recovery*
- Indication of recommended gear*

Weight reduction

- Optimisation of high-strength panels, reduction of thickness in panels and other materials
- Replacement of spare wheel with tyre repair kit

Reduction of energy consumption

- Use of energy-saving electromechanical steering instead of hydraulic type
- Optimisation of efficiency of generators
- Optimisation of operating consumption and electrical current consumption

Optimisation of aerodynamic- and rolling resistance

- Additional aerodynamic spoilers*
- Additional covers at rack (CD covers)*
- Optimised cooling (input grid, additional seal)*
- Reduction by 15 mm* with frame
- Ro-Wi tyres (wheels with low rolling resistance)*

Recyclability

- All models currently in production homologised in conformity with the requirements for recyclability (EU Directive 2005/64/EC)
- Use of recyclable, environmentally-friendly materials
- Use of recycled materials with the parameters of the new material preferred
- Labelling of materials for the purpose of making sorting easy



* realised in the GreenLine series




www.skoda-auto.com

You also can do something for the environment!

The fuel consumption of your ŠKODA and the related pollutant emissions are determined crucially on how you drive.

The noise and the wear of the vehicle depend on the way how you deal with your vehicle.

This Owner's Manual shows you how to use your ŠKODA vehicle with utmost care for the environment while driving economically at the same time.

Also please pay attention to those parts in the Owner's Manual that are marked  below.

Work with us - for the sake of the environment.

Návod k obsluze
Fabia anglicky 11.2012
S55.5610.10.20
5J6 012 003 NR